

OWNER'S MANUAL

MINI
MINI CONVERTIBLE





CONGRATULATIONS ON YOUR NEW MINI

This Owner's Manual should be considered a permanent part of this vehicle. It should stay with the vehicle when sold to provide the next owner with important operating, safety and maintenance information.

We wish you an enjoyable driving experience.

CONTENTS

NOTES

- About this Owner's Manual 6
- Additional sources of information 6
- Symbols used 6
- Your individual vehicle 6
- Editorial notice 7
- For your own safety 7
- Symbol on vehicle parts 8
- Service and warranty 8
- Reporting safety defects 9

OVERVIEW

- Cockpit 12
- Display elements 13
- Display elements with navigation system
or Cockpit Chrono Pack 14
- Indicator and warning lamps 16
- Multifunction steering wheel 20

CONTROLS

- Opening and closing:**
 - Keys 24
 - Central locking system 24
 - Opening and closing: from outside 25
 - Opening and closing: from inside 28
 - Tailgate 29
 - Electric power windows 31
 - Glass sunroof, electric 33
 - Roller sun blind 34
 - Convertible top with integrated sliding
sunroof 35
 - Wind deflector 40
- Adjustments:**
 - Safe seating position 42
 - Seat adjustment 43
 - Head restraints 44
 - Entry to the rear 45
 - Safety belts 46
 - Seat heating 47
 - Steering wheel 47
 - Mirrors 48
 - Vehicle Memory 49
 - Transporting children safely 50

© 2006 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany
Reprinting, including excerpts, only with the
written consent of BMW AG, Munich.
Order No. 01 41 0 012 950
US English VIII/06
Printed in Germany
Printed on environmentally friendly paper,
bleached without chlorine, suitable for recycling.

Driving:

- Ignition lock 53
- Starting the engine 53
- Switching off the engine 54
- Parking brake 54
- Manual transmission 55
- Automatic transmission with Steptronic 56
- Parking lamps/Low beams 60
- Turn signal indicator/Headlamp flasher 61
- Instrument lighting 62
- Fog lamps 62
- Interior lamps 62
- Washer/wiper system 63
- Washer fluid 64
- Cruise control 65

Everything under control:

- Odometer 67
- Clock 67
- Fuel gauge 67
- Coolant temperature gauge 68
- Tachometer 69
- Service interval display 69
- Onboard computer 70

Technology for safety and driving convenience:

- Driving stability control systems 72
- Flat Tire Monitor 74
- Airbags 76
- Park Distance Control (PDC) 78

Controlling the climate for pleasant driving:

- Air conditioning system 79
- Automatic climate control 82

Interior conveniences:

- Glove compartment 85
- Center armrest 85
- Drinks holders, ashtray 86
- Cigarette lighter, 12 V power supply 87
- Integrated universal remote control 88

Loading and transporting cargo:

- Luggage compartment in the MINI 90
- Luggage compartment in the MINI Convertible 91
- Loading cargo 92
- Roof-mounted luggage rack 95

OPERATION, CARE, MAINTENANCE

Special operating instructions:

- Break-in procedures 98
- General driving notes 98
- Refueling 101

Wheels and tires:

- Tire inflation pressure 104
- Tire coding 108
- Tire condition 109
- Run-Flat Tires 111
- New wheels and tires 112
- Snow chains 113

CONTENTS

In the engine compartment:

Bonnet [114](#)

Engine compartment:

MINI COOPER and

MINI COOPER Convertible [115](#)

MINI COOPER S and

MINI COOPER S Convertible [116](#)

Engine oil [117](#)

Coolant [118](#)

Brake system [120](#)

Maintenance and care:

MINI Maintenance System [121](#)

Socket for Onboard Diagnostics

OBD [122](#)

Caring for your vehicle [122](#)

Vehicle storage [125](#)

OWNER SERVICE PROCEDURES

Replacement procedures:

Onboard tool kit [128](#)

Wiper blades [128](#)

Lamps and bulbs [129](#)

Repairing a flat tire [133](#)

Space-saver spare tire [133](#)

Changing tires [135](#)

MINI Mobility System [137](#)

Vehicle battery [140](#)

Fuses [141](#)

Giving and receiving assistance:

Jump-starting [142](#)

Towing and tow-starting [143](#)

TECHNICAL DATA

Engine data [148](#)

Dimensions:

MINI [149](#)

MINI Convertible [150](#)

Weights:

MINI [151](#)

MINI Convertible [152](#)

Capacities [153](#)

INDEX

Everything from A to Z [156](#)

NOTES

About this Owner's Manual

In compiling this Owner's Manual we have made every effort to furnish you with a convenient reference source affording quick access to all the essentials. The fastest way to find detailed information on any specific subject is to turn to the comprehensive index at the back of the manual. If you wish to gain an initial overview of your vehicle, you will find this in the first chapter.

Should you wish to sell your MINI at some time in the future, please remember to hand over this Owner's Manual to the new owner; it is an important part of the vehicle.

Additional sources of information

You can find more information about the MINI, for example on its technology, on the Internet at www.MINI.com.

If you have any additional questions, your MINI Dealer will be glad to advise you.

Symbols used



Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.



Indicates information that will assist you in gaining the optimum benefit from your vehicle and enable you to care more effectively for your vehicle.



Refers to measures that can be taken to help protect the environment.

◀ Marks the end of a specific item of information.

* Indicates special equipment, country-specific equipment and optional extras, as well as equipment and functions not yet available at the time of printing.



Vehicle Memory, refer to page 49. Identifies functions that can be specifically adapted for a particular vehicle. These adjustments can be performed by your MINI Dealer.

Your individual vehicle

The manufacturer of your MINI is the Bayerische Motoren Werke Aktiengesellschaft, BMW AG.

On purchasing your MINI, you have decided in favor of a model with individualized equipment and features. This Owner's Manual describes the entire array of options and equipment that the manufacturer of your MINI makes available with a specific model range.

We hope you will understand that equipment and features are included that you might not have chosen for your vehicle. To assist you in identifying possible variations between your own vehicle and the manual's contents, the passages describing optional accessories and special equipment are marked with an asterisk *.

If your MINI features equipment not described in this Owner's Manual, please observe the enclosed Supplementary Owner's Manuals.


NOTES

Editorial notice

The manufacturer pursues a policy of continuous, ongoing development that is conceived to ensure that MINI vehicles continue to embody the highest quality and safety standards combined with advanced, state-of-the-art technology. For this reason, the features described in this Owner's Manual could, in rare cases, differ from those in your vehicle.

For your own safety

Fuels:


 Use unleaded gasoline only. Fuels containing up to and including 10% ethanol or other oxygenates with up to 2.8% oxygen by weight, i.e. 15% MTBE or 3% methanol plus an equivalent amount of co-solvent, will not void the applicable warranties with respect to defects in materials or workmanship. Field experience has indicated significant differences in fuel quality, i.e. volatility, composition, additives, etc., among gasolines offered for sale in the United States and Canada. The use of poor-quality fuels may result in driveability, starting and stalling problems especially under certain environmental conditions, such as high ambient temperature and high altitude.

Should you encounter driveability problems which you suspect could be related to the fuel you are using, we recommend that you respond by switching to a recognized high-quality brand.

Failure to comply with these recommendations may result in unscheduled maintenance.


Obey pertinent safety rules when you are handling gasoline. ◀

Maintenance and repair:

 Advanced technology, e.g. the use of modern materials and powerful electronics, requires specially adapted maintenance and repair methods. Have the necessary work on your MINI carried out by a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer. Work that is improperly carried out could result in consequential damage and pose safety hazards. ◀

California Proposition 65 warning:


California laws require us to state the following warning.

 Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water. ◀

NOTES

Parts and accessories:

 For your own safety, use genuine parts and accessories approved by the manufacturer of the MINI.

When you purchase accessories tested and approved by the manufacturer of the MINI and Original MINI Parts, you simultaneously acquire the assurance that they have been thoroughly tested by the manufacturer of the MINI to ensure optimum performance when installed on your vehicle.

The manufacturer of the MINI warrants these parts to be free from defects in material and workmanship.


The manufacturer of the MINI will not accept any liability for damages resulting from installation of parts and accessories not approved by the manufacturer of the MINI.

The manufacturer of the MINI cannot test every product from other manufacturers to verify if it can be used on a MINI safely and without risk to either the vehicle, its operation, or its occupants.


Original MINI Parts, MINI Accessories and other products approved by the manufacturer of the MINI, together with professional advice on using these items, are available from all MINI Dealers.

Installation and operation of non-MINI

approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones, including operation of any portable cellular phone from within the vehicle without using an externally mounted antenna, or transceiver equipment, e.g. CB, walkie-talkie, ham radio or similar, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the MINI Limited Warranty. See your MINI Dealer for additional information. ◀

 Maintenance, replacement, or repair of the emission control devices and systems must be performed by an authorized MINI Dealership or individual using certified MINI parts. ◀

Symbol on vehicle parts

 Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

Service and warranty

This manual is supplemented by a Service and Warranty Information Booklet for US models or a Warranty and Service Guide Booklet for Canadian models.

We recommend that you read this publication thoroughly.

Your MINI is covered by the following warranties:

- ▷ New Vehicle Limited Warranty
- ▷ Rust Perforation Limited Warranty
- ▷ Federal Emissions System Defect Warranty
- ▷ Federal Emissions Performance Warranty
- ▷ California Emission Control System Limited Warranty.

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

NOTES

Reporting safety defects

For US customers:

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA in addition to notifying the MINI Division of BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, telephone toll-free 1-866-275-6464.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.


To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor

vehicle safety from
<http://www.safercar.gov>

For Canadian customers:

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may call 1-800-333-0510 from anywhere in Canada or 1-613-993-9851 from the Ottawa region and from other countries, or contact Transport Canada by mail at: Transport Canada, ASFAD, Place de Ville, Tower C, 330 Sparks Street, Ottawa, ON, K1A 0N5.

You can also obtain other information about motor vehicle safety from
<http://www.tc.gc.ca>



OVERVIEW

OVERVIEW

CONTROLS

CONTROLS

OPERATION, CARE, MAINTENANCE

OPERATION

OWNER SERVICE PROCEDURES

REPAIRS


TECHNICAL DATA

DATA

INDEX

INDEX

COCKPIT




- 1 ▷ Parking lamps/Low beams [60](#)
- ▷ Turn signal indicators [61](#)
- ▷ Standing lamps [60](#)
- ▷ High beams [61](#)
- ▷ Headlamp flasher [61](#)
- ▷ Onboard computer [70](#)

- 2 Washer/wiper system [63](#)
- 3 Instrument lighting [62](#)
- 4 Outside mirror adjustment [48](#)
- 5 Hazard warning flashers


- 6 Bonnet release [114](#)
- 7 Adjusting steering wheel [47](#)
- 8 Horn
- 9 Socket for Onboard Diagnostics
OBD [122](#)

DISPLAY ELEMENTS



- 1 Tachometer 69
with indicator and warning lamps,
page 16 ff
- 2 Display for onboard computer 70
without onboard computer:
Display of outside temperature and current speed
- 3 Speedometer with indicator and warning lamps, page 16 ff
- 4 Indicator for
 - ▷ Odometer 67
 - ▷ Trip odometer 67
 - ▷ Service interval 69
 - ▷ Program indicator for automatic transmission with Steptronic 57
 - ▷ Clock
- 5 Trip odometer, reset to zero 67
Setting the clock 67
- 6 Fuel gauge 68
- 7 Engine coolant temperature gauge 68

DISPLAY ELEMENTS WITH NAVIGATION SYSTEM* OR COCKPIT CHRONO PACK*




- 1 Tachometer [69](#)
with indicator and warning lamps,
page [16 ff](#)
- 2 Display for onboard computer

- 3 Speedometer with indicator and warn-
ing lamps, page [16 ff](#)
- 4 Trip odometer, reset to zero [67](#)
Setting the clock [67](#)

- 5 Indicator for
- ▷ Odometer [67](#)
 - ▷ Trip odometer [67](#)
 - ▷ Service interval [69](#)
 - ▷ Program indicator for automatic
transmission with Steptronic [57](#)
 - ▷ Clock

DISPLAY ELEMENTS WITH NAVIGATION SYSTEM* OR COCKPIT CHRONO PACK*



1 Indicator and warning lamps, page 16 ff

2 Fuel gauge 68

3 Engine oil temperature

4 Engine oil pressure

5 Coolant temperature

6 Indicator and warning lamps, page 16 ff

7 Fuel gauge 68

For more information about the navigation system, refer to the Owner's Manual for Navigation System.

INDICATOR AND WARNING LAMPS

Technology that monitors itself

The system runs a check on the indicator and warning lamps marked by ● when you turn the key in the ignition lock. They each light up once for different periods of time.

If a malfunction should occur in one of these systems, the corresponding lamp does not go out after the engine is started or it lights up while the vehicle is moving. You will see below the correct way to react to this.

Red: stop immediately



Battery charge current ●
The battery is no longer being charged. Indicates a defective alternator drive belt or a problem with the charge circuit. Please contact your MINI Dealer.



If the drive belt is defective, do not continue driving. The engine could be damaged due to overheating. When the power-assist is deactivated, increased steering effort is required. ◀



Engine oil pressure ●
The engine oil pressure is too low. Pull over immediately and switch off the engine. Please contact your MINI Dealer.



Do not continue driving; otherwise, the engine could be damaged because of inadequate lubrication. ◀



Brake warning lamp ●
Lights up although the parking brake is released. The brake fluid level is too low. Before driving further, be sure to comply with the information on page 120. Have the system checked immediately.



Canadian models display this warning lamp.

If equipped with a navigation system or Cockpit Chrono Pack:



Coolant temperature warning lamp in the navigation system or Cockpit Chrono Pack ●

Lights up while driving: engine is too hot. Pull over to the side of the road immediately, switch off the engine and allow it to cool down, refer also to page 68. Have the system checked immediately.

INDICATOR AND WARNING LAMPS

Yellow: stop immediately



Flat Tire Monitor ●

The warning lamp indicates a flat tire or a system malfunction. In the event of a flat tire, an acoustic signal also sounds.

Reduce speed immediately and stop the vehicle.

It is possible that the acoustic signal was not heard. In this case, in order to determine if there is a flat tire or a system malfunction:

1. Switch off the ignition, ignition key position 0
2. Switch the ignition back on, ignition key position 2, or start the engine.

If an acoustic signal sounds, you have a flat tire. Otherwise, the system has a malfunction or has failed.

For instructions on how to proceed further, refer to Flat Tire Monitor, page 75 ff.

Red and yellow: continue to drive, but use great caution



Brake warning lamp together with yellow indicator lamps for ABS, CBC, EBD and ASC/DSC:



driving stability control has failed. Drive cautiously and defensively.



Avoid full brake applications. Have the system checked as soon as possible.

More information on page 72.



Canadian models display these warning lamps.



Red: an important reminder



Brake warning lamp with parking brake applied.

More information on the parking brake on page 54.



Warning lamp in Canadian models.



Fasten safety belts ●

Lights up for several seconds or until the safety belt has been fastened.

A signal* also sounds depending on the version.

More information on page 46.



Bonnet/tailgate/sliding sunroof*

Comes on if the bonnet, tailgate or sliding sunroof is open.

More information on pages 29, 35, 114.

INDICATOR AND WARNING LAMPS

Red: have it checked soon



Airbags ●

There is a malfunction in the airbag system. Have the system checked as soon as possible.

More information on page [77](#).



Brake pads

The brake pads have reached the minimum safe limit for lining wear.

Have the brake pads replaced immediately.

More information on page [99](#).

Yellow: have it checked soon



Antilock Brake System (ABS) ●

The ABS has failed. Conventional braking efficiency is available. Have the system checked as soon as possible.

More information on page [72](#).



Canadian models display this warning lamp.



Automatic Stability Control plus Traction ASC/Dynamic Stability Control DSC ●

Indicator lamp flashes:

System active: drive and brake forces are regulated.

Indicator lamp lights up continuously:

ASC/DSC has been deactivated at the button or is malfunctioning.

If there is a malfunction: have the system checked as soon as possible.

More information on page [72](#).



Engine ●

The exhaust emissions have deteriorated.

Have the vehicle checked as soon as possible.



Canadian models display this warning lamp.



Engine electronics* ●

The engine electronics are malfunctioning. You can continue to drive with reduced engine output or engine speed. Have the vehicle checked as soon as possible.

INDICATOR AND WARNING LAMPS

Yellow: for your information



The warning lamp* comes on.
The gas cap is not correctly closed or missing. Check if the gas cap is correctly closed.

Green: for your information



Turn signal indicator
Flashes when turn signal indicator is on.

Rapid flashing: at least one turn signal indicator has failed.

More information on page [61](#).



Cruise control
Comes on while the system is switched on: operation via the multifunction steering wheel or the sports steering wheel with multifunction buttons.
More information on page [65](#).

Blue: for your information



High beams
Comes on when the high beams are on or the headlamp flasher is actuated.


More information on page [61](#).

MULTIFUNCTION STEERING WHEEL*

Multifunction sports steering wheel

The multifunction sports steering wheel comes with integrated control buttons enabling you to operate the following functions quickly and safely, without having to take your eyes from the road:

- ▷ Some audio source functions
- ▷ Cruise control
- ▷ Telephone.



Multifunction sports steering wheel

- 1 Call up and continue cruise control
- 2 Store speed and accelerate
- 3 Activate/interrupt/deactivate cruise control
- 4 Store speed and decelerate

- 5 Fast forward/rewind or scroll through phone book:

▷ Radio

Press button briefly: next/previous stored station

Press for longer: station search

▷ CD/MD

Press button briefly: track skip

Press for longer: search within track

▷ Cassette

Press button briefly: track skip or stop fast forward

Press for longer: fast forward



If the Wave radio is installed, the above options for cassette player operation are not available. ◀

- 6 Volume up/down

- 7 Switch between telephone and other audio sources

- 8 Accept or terminate a phone call



OVERVIEW

OVERVIEW

CONTROLS

CONTROLS

OPERATION, CARE, MAINTENANCE

OPERATION

OWNER SERVICE PROCEDURES

REPAIRS


TECHNICAL DATA

DATA

INDEX

INDEX

KEYS



Depending on your vehicle's equipment version, you will have received the following keys:

- 1 Master keys with remote control
- 2 Spare key

Master keys with remote control

In every master key with remote control, there is an extended-life battery as a power supply that is charged automatically in the ignition lock as you drive.

You should therefore use each master key at least twice a year to maintain the charge status.

Depending on which master key the vehicle detects when it is unlocked, different settings will be called up and executed inside

the vehicle, refer to Vehicle Memory on page 49.

Spare key

For keeping in a safe place, e.g. in your wallet. This key is not intended for constant use.

CENTRAL LOCKING SYSTEM

The concept

The central locking system is ready for operation whenever the driver's door is closed. The doors, the tailgate and the fuel filler door are unlocked or locked.

The central locking system locks or unlocks your vehicle:

- ▷ When operated from the outside via the remote control as well as via the door lock
- ▷ When operated from the inside via a switch
- ▷ The vehicle is unlocked automatically when the ignition key is pulled out of the ignition switch.

If operated from outside, the anti-theft system is activated at the same time. This prevents the doors from being unlocked via safety lock buttons or door handles.

In the event of a sufficiently severe accident, the central locking system unlocks automatically. The hazard warning flashers and interior lamps are also switched on.

OPENING AND CLOSING: FROM OUTSIDE

Via remote control

When the vehicle is unlocked or locked, the anti-theft system is also deactivated/activated and the interior lamp is switched on/off.



People or animals could lock the doors from the inside. Always take the vehicle keys with you so that the vehicle can be opened again from the outside at any time. ◀

For US owners only

The transmitter and receiver units comply with part 15 of the FCC, Federal Communications Commission, regulations. Operation is governed by the following:

FCC ID: LX8765S

LX8765E

LX8CAS

Compliance statement:


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- ▷ This device may not cause harmful interference, and
- ▷ this device must accept any interference received, including interference that may cause undesired operation.



Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment. ◀

OPENING AND CLOSING: FROM OUTSIDE



- 1 Unlocking and convenience opening
- 2 Locking and securing
- 3 Unlocking the tailgate

To unlock

1. Press button ①.
The driver's door is unlocked.
The interior lamps are switched on and the hazard warning flashers flash twice*.
2. Press the ② button again.
First the driver's door will unlock, then the entire vehicle.



You can have this function activated/deactivated. ◀



If none of the vehicle doors are opened within 2 minutes, the central locking system locks the vehicle automati-

cally. The anti-theft system is not activated. ◀



You can have the vehicle's automatic locking feature activated/deactivated. ◀

Convenience opening mode

Hold the ③ button pressed.

In the MINI, the windows and the glass sunroof are opened.

In the MINI Convertible, the windows and the sliding sunroof are opened.

To open the convertible top on the MINI Convertible: release the button and press it again until the convertible top is completely open.



Convenience closing is not possible by means of the remote control. ◀



You can have remote control opening of the windows, glass sunroof or convertible top activated/deactivated. ◀

Locking and securing

Press button ②.

The hazard warning flashers flash once.

Unlocking the tailgate

Press the ③ button briefly.

The rear and side turn signal indicators flash twice.

The tailgate can be unlocked separately if the vehicle has been locked via central locking.



Open the tailgate within 20 seconds, refer to page 29, or it will otherwise be locked again automatically. The rear and side turn signal indicators flash once. If the tailgate was previously locked, then it is locked again after it is closed. ◀

OPENING AND CLOSING: FROM OUTSIDE

Malfunction


Local radio waves can interfere with functions of the remote control.

If this occurs, lock and unlock the vehicle via a door lock.

In the event of a system malfunction, please contact your MINI Dealer. You can also obtain replacement keys there.



If it is no longer possible to lock the vehicle with the remote control, then the battery is discharged. Use the corresponding key for a longer journey so that its battery can be recharged. ◀



MV000455CMA

Via the door lock

1. Turn the key.
The driver's door is unlocked.
2. Turn the key again.
All other doors, the tailgate and the fuel filler door are unlocked.



You can have this function activated/deactivated. ◀

When the vehicle is locked, the hazard warning flashers flash once.

When the vehicle is unlocked, the hazard warning flashers flash twice*.

Manual operation

In the event of an electrical malfunction, the driver's door can be unlocked or locked by turning the key in the door lock to the end positions.

Convenience closing via the door lock

You can also close the power windows, glass sunroof or the convertible top via the door lock.


With the door closed, hold the key in the locking position.

In the MINI Convertible, the convertible top is closed first and then the side windows.



You can have the closing of the windows and glass sunroof via the door lock activated/deactivated. ◀

OPENING AND CLOSING: FROM INSIDE



This switch locks or unlocks the doors and tailgate when the front doors are closed, but the anti-theft system is not activated. The fuel filler door remains unlocked.

To lock

- ▷ Briefly press the switch downward or
- ▷ push down the safety lock button on the passenger door. To prevent yourself from being locked outside the vehicle accidentally, the driver's door cannot be locked with its safety lock button while it is open.



After you have driven off, the central locking system automatically locks your vehicle once a certain speed has been reached. ◀



You can have this function activated/deactivated and the speed set. ◀



People or animals inside the vehicle could lock the doors from the inside. Always take the vehicle's keys with you so that you can open the vehicle again from the outside at any time. ◀

To unlock and open the doors

1. Briefly press the switch upward
2. Pull the respective door handle above the armrest or pull the door handle twice on each door:
The first pull unlocks the door, the second opens it.

Convenience opening mode

Press the central locking switch and hold it pressed.

MINI:

Windows and glass sunroof are opened.

MINI Convertible:

Windows and sliding sunroof are opened.


To open the convertible top:

Release the switch, then press it upwards until the convertible top is completely open and the windows are again closed.

TAILGATE




To open from the outside

Press the button in the handle strip or the  button on the remote control, refer to page 26. The tailgate is unlocked and can be opened.




Tailgate on the MINI Convertible

 The maximum load that may be placed on the open tailgate is 175 lbs/80 kg. ◀




To close

 To avoid injuries, as with all closing procedures be sure that the travel path of the tailgate is clear when it is closed. ◀

Handle recesses on the MINI

The handle recesses in the interior trim panel of the tailgate make it easier to pull it down.


TAILGATE



Manual release in the MINI Convertible

In the event of an electrical malfunction, you can also unlock the tailgate manually.

1. Use a master key or ignition key to release the catches of the rear backrests, refer to Through-loading system on page [91](#)




Manual release in the MINI

In the event of an electrical malfunction, you can also unlock the tailgate manually.

1. Fold the rear seat bench upward
2. Pull the ring.
The tailgate is released.


2. Fold the rear bench seat upward and remove the hook attached to it
3. Using the hook, reach backward between the convertible top and the rear backrest to pull one of the levers for releasing the folding rear backrests, refer to page [92](#)
4. Fold rear backrests forward

TAILGATE



5. Pull the handle, see arrow.
The tailgate is released.

ELECTRIC POWER WINDOWS



To open the windows

- ▷ Press the switch downwards.
The window opens until you release the switch or
- ▷ Tap the switch downwards.
The window opens automatically.
Tapping the switch again stops the operation.

To close the windows

- ⚠ Make sure that the closing range of the windows is unobstructed, otherwise personal injury could result when the windows close. ◀

From ignition key position 1:

Press the switch upwards.

The window closes until you release the switch.

- ⚠ Watch the closing process to ensure that no one is injured. ◀

After the ignition has been switched off:

You can continue using the electric power windows for a limited period as long as no one opens either of the doors.

- ⚠ When leaving the vehicle, always take the ignition key with you. Otherwise children could operate the power windows and injure themselves. ◀

ELECTRIC POWER WINDOWS

Convenience operation

For convenience operation using the remote control refer to page 26, for operation via the door lock refer to page 27.

To initialize power windows

▶ If the battery is disconnected, e.g. for changing batteries or vehicle storage, reinitialize the power windows. Otherwise the windows will not be lowered when the convertible top or doors are opened. ◀

1. Close the doors
2. Close both windows
3. Press both switches of the power windows upwards for approx. one second.

In the event of a system malfunction, please contact your MINI Dealer.



Power windows in the MINI Convertible

To open the windows:


- ▶ Briefly press the button:
First the rear windows, then the front windows open automatically.
Tapping the switch again stops the operation.
- ▶ Press the button:
First the rear windows, then the front windows open until the button is released.

To close the windows:

Press the button.
First the rear windows, then the front windows close until the button is released.

▶ Do not close the windows until the closing procedure for the convertible top is finished. Otherwise it is not ensured that the side windows will close properly against the rubber seals of the convertible top. Convertible top, refer to page 35. While the vehicle is in motion, always close the rear windows first or all four windows at the same time. Otherwise the windows will not close tightly if the vehicle is being driven at higher speeds. ◀


GLASS SUNROOF, ELECTRIC*




To raise

Press the switch.

- ▷ The closed glass sunroof is raised.
- ▷ The closed glass sunroof automatically moves into the raised position.

 Do not use force to close the glass sunroof from its raised position, otherwise the mechanism will be damaged. ◀

To open and close

 Be sure that adequate clearance is maintained for the opening path of the glass sunroof; otherwise damage can occur. Observe the glass sunroof while it is closing, to make sure that no one is injured. ◀


- ▷ Push the switch backwards to the resistance point.
The glass sunroof opens for as long as the switch is held in this position.
- ▷ Push the switch backwards past the resistance point. The glass sunroof opens automatically. Tapping the switch again stops the operation.

The glass sunroof is closed in the same manner by pushing the switch forward.

After the ignition has been switched off

You can continue using the glass sunroof for a limited period as long as no one opens either of the doors.


If a door is opened during operation, the opening/closing process stops immediately.

 When leaving the vehicle, remove the ignition key from the lock and close the doors. Otherwise children could operate the sunroof and injure themselves. ◀

GLASS SUNROOF, ELECTRIC*

Pinch protection system

If, while closing, the glass sunroof encounters resistance within roughly the last 8 in/20 cm, the closing procedure is interrupted and the roof reopens.


 Despite the pinch protection system, make sure that the travel path of the sunroof is not obstructed whenever it is closed. Otherwise, it is not guaranteed that the closing procedure will be interrupted, for instance if the obstructions are thin. ◀

Closing without the pinch protection system:

You can disable the pinch protection system by pressing the switch past the pressure point and holding it. When closing the sunroof from the raised position, ensure that its travel path is not obstructed, since the pinch protection system is not active in this position.

Convenience operation

For convenience operation using the remote control refer to page 26, for operation via the door lock refer to page 27.



Manual opening and closing

In the event of an electrical malfunction, you can also open and close the glass sunroof manually:

1. Slide the cover panel towards the interior and remove it
2. Move the glass sunroof in the desired direction using the hexagon wrench from the onboard tool kit, refer to page 128.

ROLLER SUN BLIND*



To open

1. Press the button in the handle, see arrow 1; the cap is unlocked
2. Guide the roller sun blind towards the back.

To close

1. Use the handle to pull the roller sun blind forwards
2. Engage the handle in the device, see arrow 2.

CONVERTIBLE TOP WITH INTEGRATED SLIDING SUNROOF



- ▷ LED in button 1 flashes for a certain time and then goes out.

Opening and closing the sliding sunroof

To open:

Press button 2 until the desired sunroof position is reached.

To close:

Press button 1.

The sliding sunroof can be operated up to a road speed of 75 mph / 120 km/h.

Sliding sunroof not completely closed

If the ignition key is in position 0 or removed and the driver's door is opened, the following warnings are issued:

- ▷ bonnet/tailgate/convertible top indicator lamp*, refer to page 17, comes on
- ▷ a signal sounds

Power convertible top


So that you can get the most enjoyment out of your MINI Convertible, please observe the following tips:

- ▷ It is recommended that you close the convertible top whenever the vehicle is parked.
The closed convertible top not only protects the vehicle interior from damage due to unforeseen bad weather, but also provides a certain degree of protection against theft
- ▷ Even when the convertible top is closed, keep valuable items in the locked luggage compartment or in the lockable glove compartment
- ▷ Do not mount any roof rack systems on the convertible top
- ▷ To avoid damage, do not operate the convertible top at temperatures below 14 °F / -10 °C.




Do not leave the convertible top folded for more than one day if it is wet, to prevent permanent damage from moisture. Do not place any objects on the convertible top, as they could otherwise fall off while the convertible top is being operated and result in damage or personal injury. ◀

CONVERTIBLE TOP WITH INTEGRATED SLIDING SUNROOF

 Driving off before an opening or closing procedure is completely finished can lead to damage or personal injury. Make sure that the convertible top's travel path is clear and do not reach into the convertible top mechanism during opening or closing procedures, otherwise injuries may result. Keep children away from the swiveling area of the convertible top while it is in operation. ◀

Before closing the convertible top, remove any foreign objects from the windshield frame. They could prevent the convertible top from closing.

 To conserve battery power, if possible operate the convertible top only while the engine is running. Only operate the convertible top when the vehicle is at a standstill. Otherwise, the procedure cannot be carried out or it will be interrupted. In order to operate the convertible top, the loading aid must be locked and the luggage compartment cover must be in its lower position, refer to page 91. ◀



Opening and closing the convertible top

Observe the instructions and safety precautions described above.

To open:

While the vehicle is stationary, press button 2 to open the sliding sunroof. Pressing the button again opens the convertible top.

The side windows move down when the button for convertible top operation is pressed.

The windows close again when you keep the button pressed for more than two seconds after the opening procedure is finished and the LED has gone out.

To close:

Press button 1 until the convertible top and sliding sunroof are closed.

If the convertible top is left open for a longer period of time, it may be necessary to support the first automatic closing procedure. If the convertible top or sliding sunroof stops just before the closing procedure is finished:

1. Unlock the loading aid, refer to page 91
2. Close the convertible top and sliding sunroof completely
3. Lock the loading aid, refer to page 91.

CONVERTIBLE TOP WITH INTEGRATED SLIDING SUNROOF

Checking

- ▷ The LED lights up during convertible top operation until the opening or closing procedure is completely finished
- ▷ The LED flashes for approx. 60 seconds after the button is released. The opening or closing procedure has not yet been completed. The procedure can be continued in the desired direction by pressing the appropriate button
- ▷ The LED flashes rapidly. The convertible top cannot be operated. The luggage compartment cover is not in its lower position, refer to page 91, or the loading aid is not correctly locked, refer to page 91.


Interruption


The automatic movement is immediately interrupted when the buttons for convertible top operation are released. The procedure can be continued in the desired direction by pressing the appropriate buttons. If the opening or closing procedure is interrupted by releasing the respective button, the convertible top stays in its current position for several seconds before it slowly moves into a more stable position. The procedure can be continued by pressing the appropriate button.

Movement is also interrupted when there is a mechanical blockage. In this case, in order to operate the convertible top again:


1. Turn off the ignition and then switch it on again
2. Press the button to continue the procedure in the desired direction.

Opening and closing procedure

 Do not interrupt and restart the closing procedure several times one after another, or the convertible top mechanism could be damaged. ◀

 If the convertible top can be moved in only one direction after several con-

secutive attempts to operate it, the convertible top system has overheated. Allow the system to cool down for approx. 20 minutes. ◀


 If the battery is disconnected, e.g. for changing batteries or vehicle storage, reinitialize the power windows, refer to page 32. Otherwise the windows will not be lowered when the convertible top is opened. ◀



Convenience operation

For convenience operation using the remote control refer to page 26, for operation via the door lock refer to page 27.

CONVERTIBLE TOP WITH INTEGRATED SLIDING SUNROOF

Manual closing in the event of an electrical malfunction




 Only close the convertible top manually if it is absolutely necessary. Never open it manually. Improper handling of the convertible top can result in damage. The closing procedure must be completely finished. Otherwise, damage or injury could result. ◀




Before closing

1. Fold the rear bench seat upward and remove the special hexagon wrench attached to it
2. Open the tailgate
3. Release the loading aid, refer to page [91](#)
4. Remove the cover from the side panel on the left-hand side
5. Using the screwdriver from the onboard tool kit, refer to page [128](#), unscrew the screw, arrow, in the direction of the arrow by rotating it one and a half turns.

CONVERTIBLE TOP WITH INTEGRATED SLIDING SUNROOF




Releasing the convertible top

 Depending on the vehicle model, it may also be necessary to release the convertible top in order to close it. ◀

1. Press the lever with the hexagon wrench to release the convertible top, see arrow 1, and lift the side frame, see arrow 2. If necessary, insert an object between that side frame and the body to prevent the convertible top from locking again
2. Release the second side frame.

Closing the convertible top

 If possible, close the convertible top with the help of a second person. ◀


1. Place both hands on the convertible top on the respective side frame
2. Lift out both sides at the same time, and swing the convertible top forward onto the cowl
3. Inside the vehicle, use a screwdriver to pry out the cover in the center of the roof.

To close the sliding sunroof

1. Insert the hexagon wrench into the designated socket in the middle of the roof
2. Knock the hexagon wrench in the direction of arrow 1 to uncouple the sliding sunroof mechanism. The hexagon wrench moves upwards
3. Turn the hexagon wrench in the direction of arrow 2.


To lock the convertible top


Continue to turn the hexagon wrench until the convertible top is locked in place.

 Please contact your MINI Dealer to have the electrical malfunction repaired. ◀

WIND DEFLECTOR*

With the convertible top open, the wind deflector keeps air movement in the passenger compartment to a minimum, thus providing you with a pleasant drive, even at higher speeds. The wind deflector comes folded in a protective pouch and can be stored in the luggage compartment.

 Do not allow the wind deflector to come into contact with sharp objects, as the net could otherwise be damaged. Do not place any objects on the installed wind deflector. When storing the wind deflector in the luggage compartment, make sure that it cannot be damaged by other objects. ◀




Before installing

1. Take the wind deflector out of the pouch
2. Fold out the wind deflector, arrow 1
3. Press the locking device together until it engages, arrow 2.




Installing and folding up

1. Slide out securing pins 1 and 2 on one side until they engage
2. Insert the wind deflector with the securing pins into the designated openings on the corresponding side of the vehicle
3. Slide securing pins 1 and 2 on the other side into the designated openings until they engage
4. Fold up the upper part of the wind deflector.


 If a seat is in its rearmost position, do not recline the backrest too far, otherwise the wind deflector could be damaged. ◀

WIND DEFLECTOR*




Removing

1. Fold down the upper part of the wind deflector
2. Push back securing pin 1. To do so, turn the handle forward, see arrow 1, and push it back, see arrow 2
3. Push back securing pin 2 and remove the wind deflector.



Collapsing

1. To unlock, push the handle of the securing pin on the side into its rearmost position, see arrow 1
2. Collapse the wind deflector, see arrows 2.



Adjusting screws


The gap between the wind deflector and the side trim panel can be adjusted using the adjusting screw.

SAFE SEATING POSITION

The ideal seating position can make a vital contribution to relaxed, relatively fatigue-free driving. Together with the safety belts and airbags, the seating position also plays an important role in providing occupants with maximum levels of passive safety in an accident. To ensure that the safety systems operate with optimal efficiency, we strongly urge you to observe the instructions contained in the following section.

For additional information about transporting children safely, refer to page 50.

Airbags

 Always maintain an adequate distance between yourself and all of the airbags. Always hold the steering wheel by the rim with the hands at the 9 and 3 o'clock positions to keep any chance of injury to hands or arms to an absolute minimum, should the airbag be deployed. No one and nothing is to come between the airbags and the seat occupant. Do not use the front passenger airbag cover as a storage surface for objects of any kind. Ensure that the front passenger is correctly seated, e.g. that no feet or legs are propped against the dashboard. Otherwise, leg injury could result if the front passenger airbag suddenly deployed.


Make sure that passengers do not lean their heads against the side or head airbag, as injuries could result if the side airbags were triggered. ◀

Even if all these instructions are followed, it cannot entirely be ruled out that in some circumstances injury may result from contact with the airbags. In sensitive individuals, the ignition and inflation noise may induce a mild hearing loss that is usually temporary.

For airbag locations and additional information on airbags, refer to page 76.

Head restraint


A correctly adjusted head restraint reduces the risk of injury to the cervical spine in the event of an accident.

 Adjust the head restraint in such a way that it is centered roughly at ear level. Otherwise, there is an increased risk of injury in the event of an accident. ◀

Safety belt

Fasten your safety belt before each drive. Airbags are an additional safety device and work in conjunction with the safety belts, but do not replace them. Your vehicle is


equipped with four seats, each of which is provided with a safety belt.

 Never allow more than one person to wear a single safety belt. Never allow infants or small children to ride in a passenger's lap. Make sure that the belt in the lap area sits low across the hips and does not press against the abdomen. The safety belt must not rest against the throat, run across sharp edges, pass over hard or fragile objects or be pinched. Fasten the safety belt so that it is not twisted and sits as snugly as possible against the lap and shoulder. Otherwise the belt could slide over the hips and injure the abdomen in the event of a frontal collision. Avoid wearing bulky clothing and pull the belt in the upper-body area upward periodically to retension it. Otherwise, the restraining effect of the safety belt could be diminished. ◀

For information on using the safety belts, refer to page 46.


SEAT ADJUSTMENT

Important adjustment information

 Never try to adjust your seat while operating the vehicle. The seat could respond with an unexpected movement, and the ensuing loss of vehicle control could lead to an accident.


While driving, do not recline the backrest too far toward the rear; this especially applies to the front passenger seat. Otherwise there is a risk that you will slide under the safety belt in an accident, thus reducing the protection provided by the safety belt. ◀

Comply with the instructions on head restraint height adjustment on page 44 and on damaged safety belts on page 47.



Longitudinal adjustment


1. Lift the handle
2. Push the seat into the desired position
3. After releasing the handle, apply pressure to the seat to ensure that the latch engages securely.



Height adjustment

1. Upward:
pull the handle repeatedly, continuing until the seat reaches the desired height
2. Downward:
push the handle repeatedly, continuing until the seat reaches the desired height.

SEAT ADJUSTMENT




Lumbar support*

You can adjust the contour of the backrest for additional support in the curvature of your spine's lumbar region. The upper hips and spinal column receive supplementary support to help you maintain a relaxed, upright posture.

Turn the wheel.


The curvature is increased or decreased.



Backrest tilt

1. Pull up the lever at the inside of the seat
2. Apply weight to or remove weight from the backrest as required
3. Release the lever so that the backrest locks into place.

HEAD RESTRAINTS




Adjusting

Upward: pull the head restraint

Downward: press the button, see arrow 1, and push the head restraint downward.

A correctly adjusted head restraint reduces the risk of injury to the cervical spine in the event of an accident.

HEAD RESTRAINTS

 Adjust the head restraint in such a way that it is centered roughly at ear level. Otherwise, there is an increased risk of injury in the event of an accident. To avoid possible violation of traffic laws, never retract the head restraints unless the rear seats are empty. Always ensure that the head restraints are raised before transporting passengers in the rear seat. ◀


Removal

1. Pull up the head restraint as far as it will go
2. Press the button, see arrow 1, while pulling the head restraint all the way out.

Installation

1. Insert the head restraint into the guides
2. Adjust the head restraint.

ENTRY TO THE REAR




Easy entry


The Easy entry function includes a memory for the longitudinal seat and the backrest positions.

1. Push down the lever at the outside of the seat, see arrow 1.
The backrest folds forward automatically
2. Push the seat forward, see arrow 2.

Original position

 Slide the seat back to its home position before folding back the backrest, otherwise the seat is latched in at its current position. In this case, adjust the longitudinal position manually, refer to page 43. ◀

1. Push the seat back into its home position
2. Fold the backrest back to the home position to lock the seat.

 When sliding the seat to the rear-most position, ensure that no one is injured and that no objects are damaged. Engage and lock both seats and backrests into position prior to driving; otherwise unexpected movement could increase the risk of an accident. ◀

SAFETY BELTS



⚠ Comply with the instructions on page 42, or the occupants' personal safety will be diminished. ◀

Make sure every occupant fastens his or her safety belt. Airbags are an additional safety device and work in conjunction with the safety belts, but do not replace them.

To close

Make sure you hear the lock engage in the belt buckle.

Safety belt reminder for the front seats



The indicator lamp flashes or lights up. A signal also sounds. Check if the safety belts have been properly fastened.

The safety belt reminder is operational above a speed of approx. 5 mph / 8 km/h. The reminder can also occur if objects are on the front passenger seat.

To release

1. Press the red button in the belt buckle
2. Hold the belt
3. Guide the belt back into its reel.



Safety belt height adjustment in the MINI

Press the button and at the same time push the entire unit upwards or downwards.

Also observe the instructions on adjusting the seats on page 42.

Safety belt height in the MINI Convertible

The seat belt height is adapted to your body size if you are sitting correctly.

SAFETY BELTS

Damaged safety belts

! If the safety belts are stressed or damaged due to an accident: have the belt system, including the seat-belt tensioners, replaced and the belt anchorages inspected. Have the necessary work carried out only by a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer, otherwise correct operation of these safety systems is not ensured. ◀

SEAT HEATING*




Press once for each temperature level.

The highest preselected temperature is set when two LEDs are lit.

To switch off:

Press the button for a longer period.

STEERING WHEEL



! Do not adjust the steering wheel while the vehicle is moving; otherwise unexpected movement could increase the accident risk. ◀

Settings

1. Push the locking lever downward
2. Adjust the desired steering wheel position
3. Pull the lever back in.

MIRRORS



Press the edge of the lens.


To fold the mirrors in or out*

Press button 3.

The mirrors can be folded in or out up to a road speed of approx. 20 mph / 30 km/h. This can be useful on narrow roads, for example, or to reset the mirrors after they have been folded in.



Exterior mirrors

 The front passenger's mirror is more concave than the driver's mirror. The objects reflected in the mirror are closer than they appear. Do not gauge your distance from following traffic based on what you see in the mirrors; otherwise there is an increased risk of an accident. ◀

Adjusting

- 1 Button for 4-way adjustment
- 2 Switch for choosing between the left and right mirror
- 3 To fold the mirrors in or out*

To adjust manually

The mirrors can also be adjusted manually:

Automatic heating*

Both mirrors are heated automatically when the ignition key is in position 2.

Interior rearview mirror

To reduce glare from vehicles behind you when you are driving at night:
Turn the knob.

Illuminated vanity mirror

1. Fold down the sun visor
2. Fold up the cover panel.

Sun visors

Can be swung sideways.

An additional sun visor is provided on the driver's side to better protect the driver from being blinded.

VEHICLE MEMORY

How the system functions

No doubt you have often reflected on how great it would be if you could configure your vehicle's various adjustment settings to meet your own personal requirements. In developing this vehicle, the manufacturer of the MINI has incorporated a number of options which can be programmed specifically for your vehicle.

What the system can do

Your MINI Dealer can provide you with details on the capabilities of the Vehicle Memory system.

Examples for Vehicle Memory:

- ▷ Automatic locking if none of the vehicle doors are opened, refer to page [26](#)
- ▷ Automatic locking after starting to drive, refer to page [28](#)
- ▷ Selective central locking system, refer to pages [26, 27](#)
- ▷ Convenience operation, refer to pages [26, 27](#)
- ▷ Pathway lighting, refer to page [60](#)
- ▷ Daytime running lamps, refer to page [61](#)
- ▷ Speed-dependent windshield wipers, refer to page [63](#)
- ▷ Setting units for outside temperature and fuel consumption display, refer to page [70](#)

- ▷ Setting units for display of temperatures specified for automatic climate control system, refer to page [84](#)
- ▷ Volume control PDC, refer to page [78](#)
- ▷ Acoustic alarm for starting PDC activation, refer to page [78](#).




This symbol alerts you to Vehicle Memory functions in the Owner's Manual. ◀



After memory functions have been reconfigured, your vehicle may operate slightly differently from the descriptions used in this Owner's Manual. If you decide to sell your vehicle one day, please remember to have the memory functions reset to their default configuration. ◀


TRANSPORTING CHILDREN SAFELY

The proper place for children

 Do not leave children unattended in the vehicle; otherwise they could endanger themselves and others by opening the doors, for example. ◀

Children should always sit in the rear


Accident research shows that the safest place for children is on the rear seats.

 Only transport children under the age of 13 or smaller than 5 ft/150 cm in the rear in a child-restraint system suitable for their age, weight and size. Otherwise there is an increased risk of injury in the event of an accident. ◀

Children 13 years of age or older must wear a fastened safety belt as soon as a child-restraint system is no longer suitable due to their age, size or weight.

All of the seats in your MINI except for the driver's seat meet the recommendations of the SAE J1819 standard for securely mounting child-restraint systems in motor vehicles.


Exception for the front passenger seat

 Should it be necessary to use a child-restraint system on the front passen-


ger seat, the front and side airbags for the front passenger must be deactivated. Otherwise, there is a significant risk of injury to the child if the airbags deploy, even if the child is seated in a child-restraint system. Your MINI Dealer will be glad to advise you. ◀

For additional information on automatic deactivation of the front passenger airbags, refer to page 76.

Installing child-restraint systems

 Always follow the manufacturer's instructions when selecting, installing and using child-restraint systems; otherwise the system's protective effect could be diminished. ◀

TRANSPORTING CHILDREN SAFELY



Child seat security

All rear safety belts and the safety belt for the front passenger can be prevented from being pulled out in order to secure child-restraint systems.

To lock the safety belt

1. Secure the child-restraint system with the belt
2. Pull the belt strap all the way out
3. Allow the belt strap to retract and pull it taut against the child-restraint system. The safety belt is locked.


To unlock the safety belt

1. Open the seat belt buckle
2. Remove the child-restraint system
3. Allow the belt strap to retract all the way.



Child-restraint systems with tether strap


As an example, the illustration shows the MINI COOPER and the MINI COOPER S. There are two additional anchors for child-restraint systems with tether straps.



Guiding the tether strap

1. Slide the head restraint up
2. Guide the tether strap through the mounting for the head restraint
3. Push the head restraint into its lowermost position.

TRANSPORTING CHILDREN SAFELY



LATCH child-restraint fixing system


LATCH: Lower Anchor and Tethers for Children.

The anchor points for the LATCH child-restraint fixing system are behind the marked cover caps. Flip up the corresponding cover caps.



To mount a LATCH child-restraint system, follow the system manufacturer's operating and safety instructions. ◀

IGNITION LOCK



- 0 Steering locked
- 1 Steering unlocked
- 2 Ignition switched on
- 3 Starting the engine

Steering locked

The key can be inserted or removed in this position only.

To lock the steering:

1. Remove the key
2. Turn the steering wheel slightly to the left or right until the lock engages.

An alarm goes off if the key remains in the ignition after opening the driver's door.

Interlock for automatic transmission with Steptronic:

To turn the key back to the 0 position or to remove it, first move the selector lever to position P.

Steering unlocked


Individual electrical accessories are ready for operation.

You will find that it is often easier to turn the ignition key from position 0 to position 1 when you move the steering wheel slightly to help disengage the lock.


Ignition switched on

All electrical accessories are ready for operation.


Starting the engine

 Vehicles with manual transmission: step on the clutch when starting the vehicle. A lockout prevents the engine from starting if the clutch is not depressed. ◀

STARTING THE ENGINE

 Do not allow the engine to run in enclosed spaces. Breathing the noxious exhaust gases can lead to unconsciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless, but highly toxic gas. Do not leave the vehicle unattended with the engine running. This is a safety hazard. Before getting out of the vehicle with the engine running, put the transmission in idle or position P, and apply the parking brake. If you fail to do this, the vehicle could move. ◀

Do not let the engine warm up with the vehicle at a standstill. Move off immediately at a moderate engine speed.

 Do not stop the starting procedure too early, and do not continue it for more than approx. 20 seconds. Release the ignition key immediately when the engine starts. Extended starting attempts, characterized by excessively frequent or long periods with the starter engaged, can lead to damage in the catalytic converter. ◀

STARTING THE ENGINE

Manual transmission

1. Engage the parking brake
2. Gearshift lever in idle position
3. Depress the clutch
4. Start the engine.

Automatic transmission with Steptronic

1. Press the footbrake
2. Put the selector lever in position P or N
3. Start the engine.

Special starting conditions

In the following situations, depress the accelerator pedal halfway and continue starting the engine for up to approx.

10 seconds:

- ▷ If the engine does not start on the first attempt, for instance if the engine is very hot or cold.
- ▷ The engine is started at very low temperatures, below approx. +5 °F / -15 °C, at high altitudes above 3,300 ft/1000 m.

SWITCHING OFF THE ENGINE PARKING BRAKE



You should never remove the ignition key when the vehicle is in motion, as the steering lock could engage.

When you leave the vehicle, always remove the ignition key and engage the steering lock.


When parking on inclines, engage the parking brake, or the vehicle could roll. ◀

Manual transmission

Turn the ignition key to position 1 or 0.

Automatic transmission with Steptronic

Engage selector lever position P, turn the ignition key to position 1 or 0.



The parking brake is designed primarily to prevent the vehicle from rolling when it is parked. It operates against the rear wheels.

To engage

Lever automatically locks in position.

The indicator lamp in the instrument cluster lights up from ignition key position 2, refer to page 17.

To release

1. Pull up slightly
2. Press the button
3. Push the lever downwards.



If, in exceptional circumstances, it should be necessary to engage the parking brake while the vehicle is in motion, do not pull the lever with excessive

PARKING BRAKE


force. Keep your thumb pressed against the release button while pulling the lever up carefully.

Otherwise, excessive force could lead to overbraking and loss of traction, i.e. fish-tailing, at the rear axle. ◀



To avoid corrosion and one-sided braking, apply the parking brake lightly from time to time when coasting to a standstill, for instance at a traffic light, provided that it is safe to do so. The brake lamps do not come on when the parking brake is engaged. ◀

MANUAL TRANSMISSION



MV01863CMB

6-speed transmission*



When shifting into 5th or 6th gear, press the gearshift lever to the right. Otherwise, the engine could be damaged by accidentally engaging 3rd or 4th gear. ◀

Reverse gear

Before selecting reverse gear, ensure the vehicle is stationary; then, fully depress the clutch and pause briefly before moving the gearshift lever into position.

5-speed transmission:

Press the gearshift lever to the right and to the back.

6-speed transmission:

Press the gearshift lever towards the left. Thereby overcome the slight resistance and press forward.

AUTOMATIC TRANSMISSION WITH STEPTRONIC*

In addition to the fully automatic mode, you can shift gears manually using Steptronic, refer to page 57.

Selector lever positions

P R N D M/S + –



▶ If the engine speed is too high when the vehicle is at a standstill, the selector lever is also blocked to protect the transmission.

If the selector lever is not placed in position P when the vehicle is parked, the position display of the selector lever stays on. This can lead to battery discharge. ◀

P Park

Select only when the vehicle is completely stopped. The transmission locks to prevent the drive wheels from turning.

R Reverse

Select only when the vehicle is completely stopped.

N Neutral: idle

Select this when you are in a car wash, for example. The vehicle can roll.

D Drive: automatic driving position

This position is designed for driving under all normal operating conditions.

Under normal operation conditions, fuel consumption is lowest when you drive in position D.

Range selection

- ▶ The selector lever can be moved out of position P when the ignition is switched on or the engine is running: interlock.
- ▶ While the vehicle is stationary and before shifting out of P or N, depress the footbrake in order to disengage the selector lever's lock mechanism: shift-lock.

Keep your foot on the brake until starting off, otherwise the vehicle will start to move when a drive position is engaged.

A lock prevents the selector lever from accidentally being moved to the R or P positions. To override the lock, press the button on the front of the selector lever knob, see arrow.

AUTOMATIC TRANSMISSION WITH STEPTRONIC*


Kickdown

Kickdown can be used to achieve maximum vehicle performance. Press the accelerator pedal past the increased resistance point at the full-throttle position.



Available displays

P R N D SD M1 to M6 EP




M/S + – Manual mode and Sport program

Switch from D to M/S + –:
Sport program is activated and SD appears in the gear indicator in the speedometer.

Press selector lever once:

This switches from the Sport program to the manual mode.

 In order to accelerate rapidly in the M/S + – Manual mode and in the Sport program, e.g. when passing, shift downwards manually or by kickdown. ◀

Whenever you want to return to automatic shifting, just move the selector lever toward the left to position D.

AUTOMATIC TRANSMISSION WITH STEPTRONIC*

Switching from M/S + – Manual mode into the selector lever positions P, R and N is only possible via D.

Shifting with the selector lever

- ▷ Briefly press the selector lever in the + direction:
Transmission shifts up
- ▷ Briefly press the selector lever in the – direction:
Transmission shifts down.

M1 to M6 appear in the gear indicator.



Shifting on the steering wheel*


The shift paddles allow the gears to be changed rapidly and, above all, safely, since both hands can remain on the steering wheel.

To shift up or down with one of the two shift paddles:

- ▷ Pull the shift paddle:
Transmission shifts up
- ▷ Press the shift paddle:
Transmission shifts down.

M1 to M6 appear in the gear indicator.

The transmission will execute only gear changes that result in a plausible combination of vehicle speed and engine rpm, e.g. it will not shift down if that would result in excessive engine speed.

 In the MINI COOPER S, with the selector lever in position D, automatic mode, you can shift gears using the shift paddles on the steering wheel. The transmission automatically switches to manual mode. If you do not shift gears with the shift paddles or accelerate for a certain amount of time, the transmission automatically returns to automatic mode. ◀

Malfunction

EP appears on the display. The transmission system is malfunctioning. Avoid high loads. All selector lever positions can still be engaged; in the forward driving positions, however, the vehicle can only be driven with a limited gear selection. Have the system checked immediately. Jump-starting and towing, refer to page [142](#) ff.

AUTOMATIC TRANSMISSION WITH STEPTRONIC*




Overriding the selector lever lock

Should the selector lever remain stuck in position P even when you press the button on the selector lever, the selector lever lock can be overridden:


1. Pull the ring with the sleeve upward, see arrows 1
2. Pull the sleeve up over the selector lever so that the sleeve is inside out
3. Press release lever 2 forward in the direction of travel while engaging the desired position, such as N.

PARKING LAMPS/LOW BEAMS




- 1 Parking lamps
- 2 Low beams
- 3 Automatic headlamp control*

Parking lamps


 Turn the light switch to position 1. The front, rear and side vehicle lighting is switched on.

For the additional option of activating the lights on one side of the vehicle for parking, refer to Switching on the standing lamps, page 60.


 The parking lamps discharge the battery.

Avoid using them for longer periods of time; otherwise, you may not be able to start the engine. ◀

Low beams


 Turn the light switch to position 2. With the low beams on and with the ignition switched off, only the parking lamps will remain on.


Automatic headlamp control*

 In switch position 3, the system automatically activates and cancels the low beams in response to changes in ambient light, for example in tunnels, at dusk, and when there is precipitation.


When driving into a tunnel with bright overhead lights, there may be a delay before the low beams come on.

The low beams may also come on when the sun is sitting low on a blue sky.

 When you switch on the fog lamps, the low-beam headlamps remain on regardless of the ambient light. When the daytime running lamps are activated, refer to page 61, the low beams come on and remain lit when the switch is in position 1 and the ignition is switched on. ◀


 Automatic headlamp control cannot serve as a substitute for the driver's judgement in determining when the vehi-

cle lights should be switched on. For example, the sensors are not able to detect fog or hazy weather. To avoid safety risks, you should respond to these kinds of low-visibility situations by switching the headlamps on manually. ◀

 You can have the sensitivity of your vehicle's automatic headlamp control adjusted. ◀

Pathway lighting

If you activate the headlamp flasher after having switched off the engine and the lights, the low beams will stay lit for a preset period of time.


 You can have this function programmed. ◀

Switching on the standing lamps

For parking, you can activate lights on one side of the vehicle. Observe local laws.

In ignition key position 0:

Move the lever to the adequate turn signal indicator position.

 The standing lamps discharge the battery. Avoid using them for longer

PARKING LAMPS/LOW BEAMS TURN SIGNAL INDICATOR/HEADLAMP FLASHER

periods of time; otherwise, you may not be able to start the engine. ◀

'Lights on' warning

If the lights have not been switched off and the ignition key is in position 0, an acoustic signal sounds for a few seconds when you open the driver's door to remind you that the lights have not been switched off.


Daytime running lamps*

If convenient, the light switch can be left in position 2.

When the ignition is switched off, the external lights go out.



You can have this function activated/deactivated. ◀



- 1 Turn signal indicators
- 2 High beams/Headlamp flasher

To signal briefly

Gently push the lever up to the point of resistance and hold it there, if necessary.



The indicator lamp flashes and the relay clicks faster than normal: flashing bulb has failed. ◀

INSTRUMENT LIGHTING



To control the instrument lighting, press the button.

Brighter display


Press the button until the desired brightness is achieved.

Dimmer display

Press the button briefly.

With each brief pressing of the button, the illumination is dimmed step by step.

FOG LAMPS



With the parking lamps/low beams switched on:
Briefly press the switch upward or downward.

Tap it again to switch off.

Fog lamps*



The parking lamps or low beams must be on. The green LED in the switch lights up.

The fog lamps are on.


Rear fog lamp*



The low beams must be on. The yellow LED in the switch lights up.
The rear fog lamp is on.

Observe all legal regulations concerning the use of fog lamps.

INTERIOR LAMPS



Switching the interior light in the MINI on and off manually

Press button 1 briefly.

Permanently turn off interior light:

Press button 1 until the interior light comes on for a short while.

Press button 1 to revert to normal operation.

INTERIOR LAMPS



Switching the interior light in the MINI Convertible on and off manually

Press button 1 briefly.

Permanently turn off interior light:


Press button 1 until the interior light comes on for a short while.

Press button 1 to revert to normal operation.

Switching the reading lamps on and off

Press button 2.

WASHER/WIPER SYSTEM



- 0 Wipers parked
- 1 Intermittent operation or rain sensor
- 2 Normal wiper speed
- 3 Fast wiper speed
- 4 Brief wipe
- 5 Clean windshield and headlamps

Intermittent operation

Not on vehicles with rain sensor.

The interval time for the wipers is dependent on the vehicle speed.

Rain sensor*

The rain sensor is located on the windshield, directly in front of the interior rear-view mirror.

When the rain sensor is activated, the

windshield wipers are automatically controlled depending on the amount of moisture, including snow, on the windshield.

To activate the rain sensor:

Lever in position 1.

The wipers will move once across the windshield.

To deactivate the rain sensor:

Lever in position 0.



Switch the rain sensor off when passing through an automatic car wash. Failure to do so could result in damage caused by undesired wiper activation. ◀

Normal wiper speed

When the vehicle is stationary, the wipers switch automatically to intermittent wiping.



You can have this function activated/deactivated. ◀

Fast wiper speed

When the vehicle is stationary, the wipers switch automatically to normal wiper speed.

WASHER/WIPER SYSTEM



You can have this function activated/deactivated. ◀

Cleaning windshield and headlamps*

The system sprays washer fluid against the windshield. The wipers are automatically activated for a brief period.

When the vehicle lighting is on, the headlamps are also cleaned at appropriate intervals.




Do not use the washers if there is any danger that the fluid will freeze on the windshield. For this reason, use antifreeze, refer to page 65.

Do not use the washers if the fluid reservoir is empty, as the washer pump will otherwise be damaged. ◀

Heated windshield washer jets*

The windshield washer jets are heated automatically when the ignition key is in position 2.



Rear window wiper*

6 Intermittent mode:

Turn the cap to position 6.

The rear window wiper moves across the window a number of times before switching to intermittent operation

Cleaning the rear window*


7 During intermittent mode:

Turn the cap to position 7 and keep it there

8 Wipers in neutral position:

Turn the cap to position 8 and keep it there.

WASHER FLUID



Headlamp* and window washer systems

The capacity of the headlamp washer system is approx. 2.6 quarts/2.5 liters, that of the windshield and rear window washer system approx. 2.4 quarts/2.3 liters.

Fill with water and, if necessary, with antifreeze, according to manufacturer's recommendations.




We recommend that you mix the washer fluid before filling either reservoir. ◀



Antifreeze agent for the washer systems is flammable. Always keep it well away from sparks and open flames, and store it in tightly closed original containers well out of the reach of children.

WASHER FLUID

Always observe the instructions on the containers. ◀



Washer fluid level

The yellow LED in the wiper control lever lights up when the washer fluid level is too low.


In the following situations, the LED flashes for approx. 10 seconds when the washer fluid level has dropped to a minimum:

- ▷ When cleaning the windshield and headlamps by pulling the wiper control lever
- ▷ When the ignition is switched on
- ▷ When starting the engine


CRUISE CONTROL*

On the multifunction sports steering wheel

Above approx. 20 mph / 30 km/h the cruise control maintains and stores any desired speed.

 Do not use cruise control when unfavorable conditions make it inadvisable to drive at a constant speed. Otherwise, the vehicle could go out of control and an accident could be caused. Unfavorable conditions include, for example, twisting roads, high traffic density, or adverse road conditions such as snow, rain, ice, or loose surfaces. ◀

CRUISE CONTROL*



To activate via the multifunction sports steering wheel

1. Start the engine
2. Press button 2.

The indicator lamp in the instrument cluster lights up.

Cruise control is active.

To deactivate

Press button 2 repeatedly until the indicator lamp goes out.

The cruise control is deactivated when the ignition key is turned to position 0.

The stored speed is cleared.

To maintain, store and increase speed

Press button 3.

The system maintains and stores the current vehicle speed. Every time you tap the button, the speed increases by approx.

1 mph / 2 km/h.

Press and hold button 3.

The vehicle accelerates without pressure on the accelerator pedal. When you release the button, the system maintains and stores the current speed.



If, on a downhill grade, the engine braking effect is not sufficient, the controlled speed can be exceeded. Speed can drop on uphill grades if the engine output is insufficient. ◀

To maintain, store and decrease speed

Press button 4.

If you are already driving with active cruise control, the speed is decreased by approx. 1 mph / 2 km/h every time you tap the button.

Press and hold button 4.

With the cruise control active, the system automatically reduces the throttle opening to slow the vehicle. When you release the button, the system maintains and stores the current speed.

To cancel the cruise control

The cruise control is automatically canceled:

- ▷ When the brakes are applied
- ▷ When the clutch is depressed
- ▷ If the cruising speed is either exceeded or not met for an extended length of time, for example if you press the accelerator pedal and exceed the stored speed
- ▷ When ASC or DSC is in action.

The indicator lamp stays lit.

You can use the cruise control again as required.

On the multifunction steering wheel, the cruise control can be interrupted manually:

When the system is activated, press button 2.

To continue cruise control

Press button 1.

The vehicle accelerates to and maintains the last speed stored.

ODOMETER



- 1 Trip odometer/clock
- 2 Odometer

Trip odometer/clock

To switch between the trip odometer and the clock:

Press the button.

To reset the trip odometer to zero:

Press the button until the trip odometer shows zero.

To set the clock, refer to the information below.

Odometer

When the ignition key is not in the ignition lock, you can activate the displays shown in the illustration by pressing the button in the display elements.

CLOCK




Setting

The clock must be shown on the display.

1. If necessary, press button 1 to display the clock
2. Press button 1 for approx. 5 seconds to activate the clock-setting mode
3. Press button 1 to select 12-hour or 24-hour mode
4. Wait approx. 5 seconds until the hours display is shown
5. Press button 1 to set the hour
6. Wait approx. 5 seconds until the minutes display is shown
7. Press button 1 to set the minute.

The time entered is stored automatically after approx. 1 minute.

FUEL GAUGE



In the speedometer or Cockpit Chrono Pack*

If the LED begins to be lit continuously, there are approx. 2.1 gallons/8 liters of fuel left in the tank.

Fuel tank capacity:

Approx. 13.2 gallons/50 liters.

When you switch on the ignition, the LED lights up briefly to confirm that the system is operational.

If the angle of the vehicle varies, for example when you are driving in mountainous areas, the needle may fluctuate slightly.




Refill the gas tank early. If you drive to the last drop of fuel, engine functions are not guaranteed and damage can occur. ◀

FUEL GAUGE




In the navigation system*

 Please also comply with the instructions in the previous section. ◀

If the LED changes from orange to red, there are approx. 2.1 gallons/8 liters of fuel left in the tank.

COOLANT TEMPERATURE GAUGE



Coolant temperature gauge

Depending on the equipment version, a coolant temperature gauge is located in the speedometer or the Cockpit Chrono Pack.

Low temperature:

The engine is still cold. Drive at moderate engine and vehicle speeds.

Center position:

Normal operating temperature of the engine.

High temperature:

As soon as there is a deviation from the center position upwards or to the left:

Drive with moderation and at low engine speeds. If necessary, switch off the engine and allow it to cool down.

Checking coolant level, refer to page 118.

Temperature warning

LED 1 comes on while the vehicle is in motion: engine is too hot. Switch off the engine immediately and allow it to cool down.

When you switch on the ignition, the LED 1 lights up briefly to confirm that the system is operational.

Equipment with navigation system* or Cockpit Chrono Pack*



Coolant temperature warning lamp 2 comes on while the vehicle is in motion: engine is too hot.

Switch off the engine immediately and allow it to cool down.

TACHOMETER



Do not operate the engine with the needle in the red overspeed zone of the gauge.

To protect the engine, the power is reduced when you approach a certain engine speed in this sector.

SERVICE INTERVAL DISPLAY



Remaining distance for service


With the ignition key in position 1 or higher, the distance remaining before the next scheduled service is displayed in miles for a short period. The display also indicates whether an engine oil service and/or an inspection is due.

The remaining distance is calculated on the basis of the preceding driving style. The display counts backwards in steps of 35 miles/ 50 km to the next service. A flashing message and a minus sign in front of the display that again begins counting forwards mean that the service interval has been exceeded.

Please schedule an appointment with your MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of your MINI manufacturer.

For more information on the service interval display, refer to page [121](#).

ONBOARD COMPUTER*




Mode selection

You can use the button in the turn signal indicator lever to retrieve information from the onboard computer for display in the tachometer. By pressing the button briefly, you can call up a new function for display.

The order of the displays:

Outside temperature, range, average consumption and current consumption, average speed and current speed.

 If the vehicle is equipped with a navigation system, you will find more information on the onboard computer in the Owner's Manual for Navigation System. ◀

Outside temperature

If the vehicle is not equipped with an onboard computer, only the outside temperature is displayed.


Press the button in the turn indicator lever to switch the display from outside temperature to current speed and vice versa.



You can have the unit of measure set to °F or °C. ◀

Outside temperature warning

If the temperature falls to approx. +3 °C/37 °F, the onboard computer automatically switches to the outside temperature display. In addition, a signal sounds and the display flashes.

 Black ice can occur at temperatures above +3 °C/37 °F as well. You should therefore drive carefully on bridges and shaded roads, for example; otherwise there is an increased risk of an accident. ◀

With navigation system:

The temperature is displayed in the status line of the navigation system, refer to the Owner's Manual for Navigation System.


Current vehicle speed

If the vehicle is not equipped with an onboard computer, only the current speed is displayed.

Press the button in the turn indicator lever to switch the display from outside temperature to current speed and vice versa.

Range

The display shows a range estimate based on the available fuel. The amount of fuel remaining in the tank is measured, and the range is estimated from your driving style over the last 20 miles/30 km.

 If the range displayed is less than 35 miles/50 km, be sure to refuel; otherwise engine functions are not guaranteed and damage could occur. ◀

ONBOARD COMPUTER*

Average speed, average fuel consumption

To reset average consumption, average speed:

Press the button in the turn signal indicator lever for a long time.

The average consumption is determined for the time during which the engine is running.



If the vehicle is equipped with a navigation system, the displays are shown in the area of the navigation system. ◀



You can have a different unit of measure set. ◀

Current fuel consumption

Shows the current fuel consumption. You can check how economically and environmentally friendly you are currently driving.



You can have a different unit of measure set. ◀

DRIVING STABILITY CONTROL SYSTEMS

Your MINI or MINI Convertible is equipped with a series of systems that help maintain driving stability even in adverse driving situations.

Antilock Brake System (ABS)

ABS keeps the wheels from locking during braking. Steering stability is maintained even during full brake applications. In this way, active safety is enhanced.

ABS is operational each time the engine is started. Braking safely, refer to page 99.

Cornering Brake Control CBC

Driving stability and steering characteristics are further enhanced while braking in turns or during a lane change.

Electronic Brake Force Distribution (EBD)

The system controls brake-force application at the rear wheels in order to obtain increased stability in the vehicle's braking response.

All Season traction Control (ASC)*

ASC prevents slip at the drive wheels while starting off and accelerating the vehicle. ASC also recognizes unstable vehicle condi-

tions, such as fishtailing or nose-diving. In these cases, and subject to physical limits, ASC helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes at individual wheels. This system optimizes driving stability and traction, especially when just starting off, when accelerating or when cornering.

The ASC is operational each time you start the engine. It integrates the Antilock Brake System (ABS) and Electronic Brake Force Distribution (EBD).



The laws of physics cannot be repealed, even with ASC. An appropriate driving style always remains the responsibility of the driver. Avoid using the additional safety margin provided by the system as an excuse for taking unnecessary risks.

Do not make any modifications to the ASC system. Allow only authorized technicians to perform service procedures on the ASC. ◀

Dynamic Stability Control (DSC)*

DSC prevents slip at the drive wheels while starting off and accelerating the vehicle. DSC also recognizes unstable vehicle conditions, such as fishtailing or nose-diving. In these cases, and subject to physical limits, DSC helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes at individual wheels.


The DSC is operational every time you start the engine. It integrates All Season traction Control (ASC).



The laws of physics cannot be repealed, even with DSC. An appropriate driving style always remains the responsibility of the driver. Avoid using the additional safety margin provided by the system as an excuse for taking unnecessary risks.

Do not make any modifications to the DSC system. Allow only authorized technicians to perform service procedures on the DSC. ◀

DRIVING STABILITY CONTROL SYSTEMS



Switching off the ASC or DSC

Briefly press the switch.
The indicator lamp stays lit.

When driving with snow chains or to 'rock free' in snow, it can be helpful to switch off the ASC/DSC for a brief period.



To maintain vehicle stability, always drive with the ASC or DSC switched on whenever possible. ◀

Switching the ASC or DSC on again

Briefly press the switch once again.
The indicator lamp goes out.

Indicator lamp



The indicator lamp will go out shortly after the ignition has been switched on, refer to pages [17](#), [18](#).

The indicator lamp flashes:
ASC or DSC is regulating drive torque and braking forces.

The indicator lamp lights up continuously:
the system is malfunctioning or has been switched off at the button. Have the system checked as soon as possible.

FLAT TIRE MONITOR

The concept

As you drive, the Flat Tire Monitor keeps track of the tire inflation pressure in all four tires. The system alerts you when there is a substantial pressure loss in one of the tires relative to another.

In the event of tire pressure loss, the rolling radius of the tire changes, thereby affecting the rotational speed of the wheels. This change is detected, and a flat tire warning is issued to the driver.

System requirements

To ensure the reliability of flat tire warnings, the system must be initialized with the correct tire inflation pressures.

▶ Each time you correct the pressure in a tire, or change a wheel or tire, the system must be reinitialized. ◀

System limitations

⚠ The Flat Tire Monitor cannot alert you to severe and sudden tire damage caused by external factors, nor does it detect the gradual and minor loss of pressure in all four tires. ◀

The system could issue a false warning or function in a delayed manner in the following situations:

- ▷ System was not initialized
- ▷ You are driving on a snow-covered or slippery road surface
- ▷ Sporty driving style: slip at the drive wheels, high lateral acceleration
- ▷ You are driving with snow chains.

When driving with a space-saver spare tire, the Flat Tire Monitor cannot function.



Initializing the system

▶ Initialization is completed while you are driving, but you can stop the car at any time. Initialization is automatically continued when you continue driving. Do not initialize the system if you are driving with snow chains or a space-saver spare tire. ◀

1. Before a journey, start the engine, but do not start driving.
2. Press the button until the indicator lamp in the display elements lights up in yellow for several seconds.
3. Drive off.

Initialization is completed during the drive, without any feedback issued.

FLAT TIRE MONITOR

Flat tire warning



The warning lamp lights up in yellow. An acoustic signal also sounds. There is a flat tire or a significant loss of pressure in a tire.

1. Reduce speed and stop the vehicle with caution. Avoid hard brake applications and steering maneuvers.
2. Determine which tire is damaged.



If this cannot be determined, contact your MINI Dealer. ◀

3. Repair the flat tire, refer to page 133.

Vehicles with Run-Flat Tires:

1. Reduce vehicle speed carefully to under 50 mph / 80 km/h. Avoid hard brake applications and steering maneuvers. Do not exceed a speed of 50 mph / 80 km/h.



Do not continue driving if the vehicle is not equipped with Run-Flat Tires, refer to page 111. If you continue to drive with a flat tire, a serious accident could result. ◀

2. Check the tire inflation pressure in all four tires at the earliest opportunity.



If the tire inflation pressure is correct in all four tires, it is possible

that the Flat Tire Monitor was not initialized. In this case, initialize the system. ◀

3. If there is a total loss of tire inflation pressure, 0 psi/0 kPa, or obvious tire damage, you can gauge the mileage for continued driving on the basis of the following indications:

▷ With a light load:

1 to 2 persons without luggage:
approx. 155 miles/250 km

▷ With a medium load:

2 persons, luggage compartment full,
or 4 persons without luggage:
approx. 90 miles/150 km

▷ With a full load:

4 or more persons, luggage compartment full:
approx. 30 miles/50 km.



Drive cautiously. Do not exceed a speed of 50 mph / 80 km/h. In case of tire pressure loss you must expect changes in vehicle handling such as lower track stability during braking, longer braking distances and changes in self-steering properties when close to the handling limit.


For safety reasons, the manufacturer of your MINI recommends not having damaged Run-Flat Tires repaired, but to consult a MINI Dealer in such cases. ◀

Malfunction



The warning lamp lights up in yellow. There is a malfunction in the Flat Tire Monitor or the system has failed. Have the system checked as soon as possible.

AIRBAGS



The following airbags are located under the marked covers:


MINI

- 1 Side airbags in the backrests
- 2 Head airbags
- 3 Front airbags

MINI Convertible

- 1 Side/head airbags in the backrests
- 3 Front airbags


Protective effect

 Comply with the instructions on page 42, or the occupants' personal safety will be diminished. ◀

The front airbags supplement the safety belts by providing additional protection for the driver and front passenger in the event of a frontal collision in which the protection afforded by the belts alone may no longer be sufficient. When needed, the head and side airbags help to furnish protection in the event of side impact. Each of the side airbags is designed to help support the seat occupant's upper body. The corresponding side/head airbag in the MINI Convertible or the head airbag in the MINI supports the head.

The airbags are designed to not be triggered in certain types of collisions, e.g. not in minor accidents or rear impacts.

For information on the ideal seating position, refer to page 42.

 Do not apply adhesive materials to the cover panels of the airbags, cover them or modify them in any other way. Do not fit covers, cushions or other items to the front seats that have not been specially approved for seats with integrated side airbags. Do not hang clothing, e.g. jackets, over the backrests.


Do not attempt to remove the airbag restraint system from the vehicle. Do not touch the individual components directly

after the system has been triggered; otherwise there is a danger of burns. In the event of malfunctions, deactivation or deployment of the airbag restraint system, have the system checked, repaired or disassembled only by a MINI Dealer or a workshop with specially trained personnel working in accordance with the specifications of the MINI manufacturer and having the necessary permits for handling explosive devices. Unprofessional attempts to service the system could lead to failure in an emergency or undesired airbag activation, either of which could result in personal injury. ◀

Warning notices and information regarding airbags can also be found on the sun visors.


Automatic deactivation of the front passenger airbags

An analysis of the impression in the front passenger seat cushion determines whether and how the seat is occupied. The system correspondingly activates or deactivates the front and side airbags for the front passenger.

 The indicator lamp above the interior rearview mirror shows the current status of the front passenger airbags, deac-

AIRBAGS

tivated or activated, refer to Functional status of the front passenger airbags below. ◀

 Before transporting a child on the front passenger seat, read the safety notes and instructions under Transporting children safely, refer to page 50.

Adolescents and adults sitting in certain positions could also deactivate the front and side airbags for the front passenger; the indicator lamp for the front passenger airbags comes on. In such cases, the occupant should change his or her sitting position so that the front passenger airbags are activated and the indicator lamp goes out. If the airbags are not activated although the seat occupant has changed his or her position, have the occupant sit on a rear seat. Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically recommended by the manufacturer of your MINI. Do not place any objects under the seat which could press against the seat from below. Otherwise, a correct analysis of the seat cushion is not ensured. ◀



Functional status of the front passenger airbags

As an example, the illustration shows the indicator lamp for front passenger airbags in the MINI Convertible.

In accordance with whether and how the front passenger seat is occupied, the indicator lamp for the front passenger airbags shows the functional status of the front and side airbags for the front passenger. The indicator lamp shows whether the front passenger airbags are activated or deactivated.

▷ The indicator lamp comes on as intended when a child in a specially designated child-restraint system is detected on the front passenger's seat.

The front and side airbags for the front passenger are not activated.

- ▷ The indicator lamp does not come on when the system detects a person of sufficient size sitting correctly on the seat, for example. The front and side airbags for the front passenger are activated.
- ▷ The indicator lamp does not come on when the seat is empty. However, the front and side airbags for the front passenger are not activated.

Operational readiness of the airbag system



Starting from ignition key position 1, the warning lamp in the display elements lights up briefly for confirmation that the entire airbag system and the seat belt tensioners are operational.

Airbag system malfunctioning

- ▷ The warning lamp does not come on along with ignition key position 1
- ▷ The warning lamp stays lit continuously.




In the event of a malfunction, have the airbag system checked immediately. Otherwise, there is a risk that the system will not function as intended in an accident of sufficient severity. ◀

PARK DISTANCE CONTROL (PDC)*

The concept


The PDC assists you when you back into a parking space. A signal tone tells you the current distance to an object behind your vehicle. To do this, four ultrasonic sensors in the rear bumper measure the distance to the nearest object.

The sensors on each side have a range of approx. 2 ft/60 cm, the middle sensors one of approx. 5 ft/1.5 m.

 PDC is a parking aid that can identify objects if they are approached slowly, as is generally the case when parking. Avoid driving towards objects rapidly; due to underlying physical principles, the system may otherwise alert you too late for you to take evasive steps. ◀

Automatic function

With the ignition key in position 2, the system starts to operate automatically about one second after you select reverse gear or place the selector lever in position R.

 Wait for this one second before you drive backwards. ◀

The system is deactivated when you shift away from Reverse.



You can have a signal tone set as a confirmation that PDC has been activated. ◀

Acoustical signals

The distance to an object is indicated by a tone sounding at intervals. As the distance between vehicle and object decreases, the intervals between the tones become shorter. A continuous tone indicates the presence of an object less than 12 in/30 cm away.

The warning signal is canceled after approx. three seconds if the distance to the object remains constant during this time, for instance if you are moving parallel to a wall.

Malfunction

A continuous high-pitched tone will sound during initial activation. The system is malfunctioning. Have the system checked.


Volume control

The volume of the Park Distance Control signal can be adjusted from level 1, soft, to level 6, loud.




You can have this function set. ◀

System limitations


 Even with PDC, final responsibility for estimating the distance between the vehicle and any objects always remains with the driver.

Even when sensors are involved, there is a blind spot in which objects cannot be detected. Recognition of some objects can be beyond the limits of physical ultrasonic measurement, for example with towing bars or hitches or with thin or wedge-shaped objects. It is also possible that low objects already detected, such as a curb edge, can disappear in the blind spot of the sensors before a continuous tone is sounded, or that protruding objects higher above the ground, such as ledges, are not detected.

Loud sources of sound outside and inside your vehicle can drown the PDC signal tone. ◀

 Keep the sensors clean and free of ice or snow in order to ensure that they will continue to operate effectively. Do not apply high pressure spray to the sensors for a prolonged period of time. Always maintain a distance which is greater than 4 in/10 cm. ◀

AIR CONDITIONING SYSTEM



- 1 Air onto the windshield and onto the side windows
- 2 Air for the upper body area 81
- 3 Air for the front and rear footwells

- 4 Temperature 80
- 5 Windshield heating* 80
- 6 Air volume/Blower 80
- 7 Cooling function 80

- 8 Air distribution 80
- 9 Recirculated air mode 80
- 10 Rear window defroster 80

MV0456-ICMA

AIR CONDITIONING SYSTEM

Air volume/Blower



You can select blower speeds from 1 to 4. Position 0: blower is switched off.

The heating, ventilation and air conditioning operate in position 1 or higher.

Temperature



Turn to the right, red, to increase the temperature.

Turn to the left, blue, to decrease the temperature.

Air distribution



Air distribution towards upper body region →, upper body region and footwell ↗↘, footwell ↓, footwell and windows ↕, and windows ☼.

Intermediate positions are possible, refer to illustration and overview on page 79.

Rear window defroster



The LED is lit when the rear window defroster is on.

The heater switches off automatically after a short time.

Windshield heating*



The LED is lit when the windshield heating is on.

The windshield heating switches off automatically after a short time.

Cooling function



The LED is lit when the cooling function is on.

The air is cooled and dehumidified and, depending on the temperature setting, rewarmed.

Depending on the weather, the windshield can fog up temporarily after the engine is started.



When the cooling function is on, condensation forms which then exits under the vehicle. Traces of condensed water on the ground are therefore normal. ◀

Recirculated air mode



The LED is lit when the recirculated air mode is on. Supply of outside air into the vehicle is blocked.


blocked.

The air within the vehicle is recirculated.



If the windows fog up in the recirculated air mode, turn the recirculated air mode off and, if necessary, increase the air supply. The recirculated air mode should not be used constantly over a longer period of time; otherwise the air quality in the vehicle's interior will gradually deteriorate. ◀

AIR CONDITIONING SYSTEM



Draft-free ventilation

Button 1: air outlets can be opened and closed by turning. The points indicate the position in each case.

Nozzle 2: change the direction of the air flow by swiveling.


Microfilter

The integrated microfilter removes dust and pollen from the incoming or recirculated air.


Your MINI Dealer will replace it during routine maintenance. A substantial reduction in the air supply indicates that the filter must be replaced before scheduled maintenance.



Defrosting and demisting windows

1. Set the rotary blower speed control for the airflow rate to position 4
2. Turn the rotary temperature control completely to the right, red
3. Turn the rotary switch for air distribution to position 
By activating the cooling function, the windows are demisted more quickly
4. Turn on windshield heating if necessary
5. To defrost the rear window: switch on the rear window defroster.

AUTOMATIC CLIMATE CONTROL*




- 1 Air onto the windshield and onto the side windows
- 2 Air for the upper body area [84](#)
- 3 Air for the front and rear footwells
- 4 Rear window defroster and windshield heating* [83](#)
- 5 Interior temperature sensor, please keep clear and unobstructed
- 6 Recirculated air mode [83](#)
- 7 Cooling function [83](#)
- 8 Automatic air distribution and volume [83](#)
- 9 Defrosting and demisting the windshield and side windows [84](#)
- 10 Temperature [83](#)
- 11 Display for air temperature and air volume [83](#)
- 12 Air volume/Blower, switching air conditioner on/off [83](#)
- 13 Individual air distribution [84](#)

MV04585CMA

AUTOMATIC CLIMATE CONTROL*


Automatic air distribution and volume

 The LED is lit when the AUTO program is on.

Automatic adjustment of the air distribution and volume, and adaptation of the specified temperatures to external influences, e.g. outside temperature and insolation.

In the automatic program (AUTO), the air conditioning is activated automatically. To create a pleasant air climate, the air temperature coming from the vents in the upper body area is lower than the air temperature in the footwell.

Air volume/Blower Switching automatic climate control off/on

 Press the left or right half of the button to vary the air volume.


Automatic adjustment of the air volume is deactivated.

Switching air conditioner on/off.

Press the left half of the button while the blower is at the lowest setting. The blower, heating and air conditioning are switched off. All displays go out.

Switch the automatic climate control back on by pressing any button.


Cooling function

 The LED is lit when the cooling function is on.


The air is cooled and dehumidified and, depending on the temperature setting, rewarmed.

The cooling function is automatically activated in the AUTO program.

Depending on the weather, the windshield can fog up temporarily after the engine is started.

 When the air conditioning is on, condensation is formed which then exits under the vehicle. Traces of condensed water on the ground are therefore normal. ◀

Recirculated air mode

 The LED is lit when the recirculated air mode is on. Supply of outside air into the vehicle is blocked.

The air within the vehicle is recirculated.

In the automatic program (AUTO) in hot weather conditions, the recirculated air mode is activated temporarily to enable faster cooling.

The LED for the recirculated air button is not lit.



The recirculated air mode should not be used constantly over a longer period of time; otherwise the air quality in the vehicle's interior will gradually deteriorate. If the windows fog up in the recirculated air mode, turn the recirculated air mode off and, if necessary, increase the air supply. ◀

Rear window defroster and windshield heating*



The LED comes on when the rear window/windshield heating is on. The heater switches off automatically after a short time.

Temperature



Tap or turn the wheel in the appropriate direction to change the temperature step by step.

The figures in the display provide a general indication of interior temperature. When you start the vehicle, the system ensures that the selected temperature is achieved as quickly as possible and then maintained.



Permanent heating with maximum power output at temperature selection HI. Permanent cooling at LO. With the

AUTOMATIC CLIMATE CONTROL*

setting at HI, the recirculated air mode cannot be switched on. ◀

Defrosting and demisting windows



The LED is lit when the function is on.

Ice and condensation are rapidly removed from the rear window, windshield and side windows.

Condensation is removed from the windows more quickly when the cooling function is also activated.

The rear window defroster/windshield heating are switched on automatically. They can be switched off again via the respective button.

Individual air distribution



Combine the air distribution yourself. Automatic adjustment of the air distribution is deactivated.



It is not possible to distribute air simultaneously toward the windows and toward the upper body area.




You can switch the unit from °C to °F by pressing the buttons for the cooling function and air distribution toward the footwell at the same time. ◀

Microfilter/Activated-charcoal filter

The microfilter removes dust and pollen from the incoming or recirculated air. The activated-charcoal filter provides additional protection by filtering gaseous pollutants from the outside air.

Your MINI Dealer replaces this combined filter as a standard part of your scheduled maintenance. A substantial reduction in the air supply indicates that the filter must be replaced before scheduled maintenance.




MV00524CMA

Draft-free ventilation

Button 1: air outlets can be opened and closed by turning. The points indicate the position in each case.

Nozzle 2: change the direction of the air flow by swiveling.

GLOVE COMPARTMENT




To open

Pull the handle.
The light goes on.

To close

Fold the door up.

 To prevent injury in the event of an accident, close the glove compartment immediately after use. ◀




Ventilation


To allow ventilation:

Turn the rotary switch to the horizontal position.

To shut off ventilation:

Turn the rotary switch to the vertical position, see arrow.

 Depending on the temperature setting of the air conditioning or the automatic climate control, high temperatures may result in the glove compartment. ◀




Connection for external audio device*

- 1 Cigarette lighter socket for power supply
- 2 Socket for sound output

You can connect an external audio device such as a CD or MP3 player and play audio recordings over the vehicle loudspeakers.

To do so, open the glove compartment and connect the device's headphones or line-out terminal to socket 2.

The volume and tone settings are adjusted over the car radio, refer to the Owner's Manual for Radio.

 Shut off ventilation to the glove compartment while an audio device is connected. Otherwise the device may be damaged due to thermal exposure. ◀

CENTER ARMREST*




Storage compartments

Depending on the equipment version*, the center armrest between the front seats contains a compartment or a base plate for a mobile phone.

To open:

Slide the cover backwards.

 The cover slides along guide rails and can be opened fully by pushing it back and lifting it slightly. ◀

To close:


Push the cover forwards.

DRINKS HOLDERS, ASHTRAY



Beverage holders


Beverage holders are at the front or top of the center console. Another is located at the end of the center console in the rear.

 Do not place any glass containers in the beverage holders, as this increases the risk of injury in the event of an accident. ◀

Ashtray


The ashtray is located in one of the beverage holders in the center console.

CIGARETTE LIGHTER, 12 V POWER SUPPLY



Lighter


Press the cigarette lighter in.
Remove as soon as the lighter jumps back out.

 Hold or touch the hot cigarette lighter by the knob only. Holding or touching it in other areas could result in burns. ◀

Cigarette lighter socket, 12 V power supply

Suitable as a power socket for flashlights, car vacuum cleaners, etc., up to a rating of approx. 200 watts at 12 volts.
Avoid damaging the socket with plugs of different shapes or sizes.

If the vehicle is equipped with a MINI Mobility System, the 12 V socket is also for supplying the compressor.



12 V socket in the luggage compartment* of the MINI Convertible

The socket is located in the luggage compartment on the left-hand side of the rear panel, arrow.


INTEGRATED UNIVERSAL REMOTE CONTROL*

The concept

The integrated universal remote control takes the place of up to three different control devices for different radio-remote-controlled systems such as gate openers and household alarm systems. The integrated universal remote control detects and learns the signal transmitted by the original control device.

The signal of an original control device can be programmed onto one of the three memory buttons 1. The system in question can then be operated by means of the programmed memory button 1. Signal transmission is indicated by LED 2.

If you decide to sell your vehicle one day, in the interest of your own security, remember to delete the programs before the vehicle leaves your possession, refer to page 89.

 While programming is in progress and before operating any programmed system by remote control using the integrated universal remote control, make sure that the movement area of the system in question is clear of people, animals and inanimate obstructions, in order to avoid possible injury or damage. Also comply with the safety precautions issued for the original control device. ◀

Checking compatibility



If this symbol is shown on the packaging or in the operating instructions of the original control device, it is safe to assume that the remote-controlled system is compatible with the integrated universal remote control.




If you have any additional question, please contact your MINI Dealer or call: 1-800-355-3515.

You can find more information on the Internet at:

www.miniusa.com or
www.homelink.com.

HomeLink is a registered trademark of Johnson Controls, Inc. ◀



Programming

- 1 Memory buttons
- 2 LED

Fixed-code control device

1. Switch on the ignition
2. For first-time start-up: press both outer buttons 1 for approx. 20 seconds until LED 2 flashes. This clears all three memory buttons 1
3. Hold the original control device approx. 2 to 8 in/5 to 20 cm away from memory buttons 1.




The required distance between the control device and memory buttons 1 may vary, depending on the system of the original control device in question. ◀

INTEGRATED UNIVERSAL REMOTE CONTROL*

4. Simultaneously press the command button of the original control device and the desired memory button 1 on the integrated universal remote control. The LED 2 begins to flash slowly. Release both buttons when LED 2 starts flashing rapidly. If LED 2 does not start to flash rapidly after approx. 15 seconds, change the distance between the two devices
5. Repeat steps 3 and 4 to program other original control devices.

The corresponding memory button 1 is now programmed with the signal of the original control device.

You can operate the system with the ignition key in position 2 or 3.


 If the system cannot be operated after repeated attempts at programming, check whether the original control device is equipped with an alternating-code system. You can either check the operating instructions of the original control device for this information, or you can press and hold down the programmed memory button 1 of the integrated universal remote control. If LED 2 of the integrated universal remote control flashes rapidly for a brief period and then remains on for approx. two seconds, the original

control device is equipped with an alternating-code system. In this case, the memory buttons 1 are programmed as described for an alternating-code control device. ◀

Alternating-code control device

You will need to refer to the operating instructions of the system in question in order to program the integrated universal remote control. Read through the operating instructions for information on synchronization.

Observe the following additional instructions when you program an alternating-code control device:

 You will find programming easier if you have the assistance of a second person. ◀

1. Park your vehicle within range of the radio-remote-controlled device
2. Program the integrated universal remote control as described above in the section on fixed-code programming
3. Locate the button on the receiver of the target device, for example on the upper part of the drive
4. Press the button on the receiver of the target device. Once you have completed

step 4, you have approx. 30 seconds to complete step 5

5. Press the programmed memory button 1 of the integrated universal remote control three times.

The corresponding memory button 1 is now programmed with the signal of the original control device.

 Consult your MINI Dealer if you have any questions. ◀

Deleting memory buttons


Press both outer buttons 1 for approx. 20 seconds until LED 2 flashes: all memory buttons are cleared.

It is not possible to delete individual memory buttons 1.

LUGGAGE COMPARTMENT IN THE MINI

Luggage compartment cover

When the tailgate is opened, the luggage compartment cover is also raised.

 Never place any heavy or hard objects on the luggage compartment cover; otherwise occupants could be injured during braking maneuvers. ◀




Removal

To load bulky luggage, the compartment cover can be removed.



1. Remove the retaining straps on the tailgate
2. Pull the luggage compartment cover out towards the rear.

Foldable rear backrest

1. Pull lever
2. Fold the rear backrest forwards.

 When folding the backrest back into its original position, always ensure that the catch engages securely. A loose backrest might fail to prevent cargo from entering the passenger compartment during sudden braking or evasive maneuvers, posing a potential hazard to occupants. ◀


LUGGAGE COMPARTMENT IN THE MINI CONVERTIBLE



Loading aid

When the convertible top is closed, you can load the vehicle more easily by releasing the convertible top and folding it up.


1. Release the convertible top using the handles, see arrows 1
2. Lift the convertible top, see arrow 2
3. Fold back the handles and place them on holders 3.

 After folding the loading aid back down, lock the handles in place again completely to operate the convertible top. ◀

Expanding the luggage compartment volume

You can enlarge the luggage compartment volume when the convertible top is closed.

1. Fold the convertible top upwards, refer to Loading aid
2. Detach the luggage compartment cover from the brackets, see arrow 1, and engage it on the upper support pins, see arrow 2
3. Place the luggage compartment cover into a horizontal position.

 To operate the convertible top, move the luggage compartment cover back to its lower position. ◀

Through-loading system


To be able to transport larger objects, the rear backrest can be folded down.

1. Unlock the catch for the rear backrest with an ignition key or master key


LUGGAGE COMPARTMENT IN THE MINI CONVERTIBLE



2. Pull the lever to release the catch
3. Fold the backrest forward.

 When folding the backrest back into its original position, always ensure that the catch engages securely. A loose backrest might fail to prevent cargo from entering the passenger compartment during sudden braking or evasive maneuvers, posing a potential hazard to occupants. ◀


LOADING CARGO

 Avoid overloading the vehicle so that the permissible carrying capacity of the tires is not exceeded. Overloading can lead to overheating and damage inside the tires. Depending on the circumstances, this can result in sudden air loss. ◀


LOADING CARGO



Determining cargo limit

1. Locate the following statement on your vehicle's placard:
 The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs, as this could otherwise result in damage to the vehicle and unstable driving conditions. ◀
2. Determine the combined weight of the driver and passengers that will be riding in your vehicle
3. Subtract the combined weight of the driver and passenger from XXX kilograms or YYY pounds



4. The resulting figure equals the available amount of cargo and luggage load capacity.
For example, if the YYY amount equals 1,400 lbs. and there will be four 150-lbs. passengers in your vehicle, the amount of available cargo and luggage load capacity is 800 lbs.:
 $1,400 \text{ lbs.} - 600 \text{ lbs.} = 800 \text{ lbs.}$
5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4
6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult the manual for transporting a trailer to determine how this may reduce the available cargo and luggage load capacity of your vehicle.



Cargo and luggage load capacity

The permissible load is the sum of the occupants' weights and the weight of the cargo. The greater the weight of the occupants, the less cargo can be transported.

LOADING CARGO



Stowing cargo

- ▷ Place heavy cargo as far forward as possible, directly behind the backrests, and as low as possible
- ▷ Cover sharp edges and corners
- ▷ Do not pile objects higher than the top edges of the backrests.


For very heavy cargo when the rear seat is unoccupied, fasten each safety belt in the opposite buckle. This provides additional stabilization for the backrests.

Securing the load

As an example, the illustration shows the luggage compartment of the MINI.

- ▷ Secure smaller and lighter items using the luggage compartment net* or elastic straps
- ▷ Secure larger and heavier items with load-securing devices*. Lashing eyelets are provided at the inner corners of the luggage compartment for attaching these load-securing devices. Comply with the information enclosed with the load-securing devices.


LOADING CARGO


 Always position and secure the load as described above. If you do not, it can pose a danger to the passengers during braking and evasive maneuvers, for example.

Do not exceed the permissible gross weight and axle load, refer to page 151 ff; otherwise the vehicle's operating safety is no longer assured and it will not be in compliance with the certification regulations.

Do not stow heavy or hard objects in the passenger compartment without first securing them. Otherwise they would be thrown around during braking and evasive maneuvers and endanger the occupants. ◀

ROOF-MOUNTED LUGGAGE RACK*

 When loading a roof-mounted luggage rack on the MINI, make sure that there is sufficient space for the movement of the glass sunroof and that no objects protrude into the swiveling area of the tailgate; otherwise damage can occur. Do not secure the roof-mounted luggage rack to the MINI's trim strips or to the MINI Convertible top. Otherwise, the lack of a secure hold could lead to damage or accidents. ◀

 Special roof-mounted luggage racks for your MINI are available as accessories from your MINI Dealer. ◀



OVERVIEW

OVERVIEW

CONTROLS

CONTROLS

OPERATION, CARE, MAINTENANCE

OPERATION

OWNER SERVICE PROCEDURES

REPAIRS

TECHNICAL DATA

DATA

INDEX

INDEX

BREAK-IN PROCEDURES

Moving parts need to be given some time until they can interact smoothly with one another. To ensure that your vehicle provides maximum economy throughout a long service life, we request that you comply with the following information:

Engine

Comply with the local speed limits.

Up to 1,250 miles/2,000 km:

Drive at varying engine and road speeds, but do not exceed the following:

4,500 rpm or

95 mph / 150 km/h.

Absolutely avoid putting the accelerator in full-throttle or kickdown position.

After 1,250 miles/2,000 km:

Engine and road speeds can be gradually increased.

Tires

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial break-in period. Therefore drive carefully during the first 200 miles/300 km.

Brake system

Approx. 300 miles/500 km must be driven before the brake pads and rotors achieve the optimum pad-surface and wear patterns required for trouble-free operation and an extended service life.

Clutch

Roughly 300 miles/500 km must be driven before the clutch starts to operate at optimum efficiency. Remember to engage the clutch carefully during this initial period.

After a part replacement

You should again comply with these break-in procedures if parts mentioned above have to be replaced later in the vehicle's life.

GENERAL DRIVING NOTES



Interior mirror, automatic dimming*

While the vehicle is being driven forward, these mirrors dim light through an infinitely variable range depending on the light's incidence. Two photocells in the interior rearview mirror serve this purpose. One is positioned on the underside of the mirror frame, while the other is slightly offset on the back of the mirror.

In order for the photocells to work optimally, keep them clean and do not cover the area between the interior rearview mirror and the windshield. Do not place stickers or toll tags on the windshield in front of the mirror.

GENERAL DRIVING NOTES

Safe braking


Your vehicle is equipped with ABS as a standard feature. If you are in a situation which requires full braking, it is best to brake using maximum brake pressure. Since the vehicle remains maneuverable, you can still go around any obstacles with the smallest possible steering movements.

The pulsation of the brake pedal, together with the sound of hydraulic regulation, indicates to you that ABS is actively taking effect.

Wet roads:


It is a good idea to periodically dry the brakes with a gentle application when driving in rain and on wet roads. Monitor traffic conditions to ensure that this maneuver does not hinder other road users. The resulting heat dries brake rotors and pads. Then if the braking force is needed, it is immediately available.

Driving downhill:

 To prevent overheating and the resulting reduced efficiency of the brake system, drive down extended or steep mountain gradients in the gear which requires the least brake applications. Otherwise, even light but consistent pres-

sure on the brake can lead to high temperatures, brake wear and possibly even brake failure. ◀

The braking effect of the engine can be increased by downshifting in the manual mode of the automatic transmission, to first gear if necessary, refer to page 58. This protects the brakes from excessive loads.

 Do not coast with the clutch depressed, the transmission in idle or the engine switched off. Otherwise, the engine provides no braking effect, and there is no power-assist for braking or steering.

Make sure that there are no floor mats, floor carpets or other objects in the vicinity of the pedals; otherwise pedal function could be impeded. ◀

Corrosion on the brake rotors:

When the vehicle is driven only occasionally, during extended periods when the vehicle is not used at all, and in operating conditions where brake applications are less frequent, there is an increased tendency for corrosion of the brake rotors and accumulation of contamination on the brake pads. This occurs because the minimal pressure that must be exerted by the

pads to clean the rotors by brake applications is not reached.

Corrosion on brake rotors is signaled by a running or pulsation during braking; even extended subsequent braking will not cure this phenomenon.

Brake pads



Sensors in the left front and right rear brake pads monitor pad condition. When the brake pads have worn to the permissible limit, this is indicated by the brake wear warning light, refer to page 18.


Hydroplaning




When driving on wet or slushy roads, reduce road speed. If you do not, a wedge of water can form between tires and road surface. This phenomenon is characterized by a partial or complete loss of contact between the tires and the road surface. The ultimate results are loss of steering and braking control. ◀

GENERAL DRIVING NOTES


Mobile communications in the vehicle

 The manufacturer of your MINI recommends that you do not use mobile devices, e.g. mobile phones, inside the vehicle without directly connecting them to an outside antenna. Otherwise, interference between the vehicle electronics and the mobile device cannot be ruled out. In addition, it is not ensured that the radiation emitted during mobile transmission will be directed outside of the vehicle. ◀


Driving through water

 Do not drive through water on the road if it is deeper than 1 ft/30 cm, and then only at walking speed at the most. Otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged. ◀


Use the parking brake on inclines

 Do not hold the vehicle in place on slopes by slipping or 'riding' the clutch. Use the parking brake instead. Otherwise, a high degree of clutch wear could result. ◀

Clothes hooks

 When suspending clothing from the hooks, ensure that they will not obstruct the driver's vision. Do not hang heavy objects on the hooks. If you do, they could injure the occupants during braking or evasive maneuvers. ◀


Hot exhaust system

 High temperatures occur in every vehicle's exhaust system. Do not remove the heat protection plates fitted in the area of the exhaust system and do not apply body-cavity protectant to this area. When driving, standing at idle, and parking the vehicle, take care to avoid contact between the hot exhaust system and flammable materials, e.g. hay, grass, leaves, etc. Such contact could lead to a fire resulting in serious personal injury and property damage. Do not touch hot exhaust pipes. Otherwise there is a risk of burns. ◀

Parking the vehicle

Condensation forms in the air conditioning system during operation, and then exits under the vehicle. Traces of condensed water on the ground are therefore normal.


Close the tailgate


 Drive the vehicle only when the tailgate is completely closed. Otherwise, exhaust fumes could penetrate the interior of the vehicle. ◀

Should it be absolutely necessary to drive with the tailgate open:


1. Close all windows as well as the glass sunroof or the sliding sunroof of the MINI Convertible
2. Sharply increase the air supply for the heater, the air conditioning or the automatic climate control, refer to page [79](#) or [82](#).

REFUELING




 Always switch off the engine before refueling; otherwise no fuel can be added to the tank and the SERVICE ENGINE SOON lamp may come on. ◀

1. Open the fuel filler door
2. Turn the gas cap counterclockwise
3. Put the gas cap in the bracket attached to the fuel filler door.

 Always observe all applicable precautionary measures and regulations when handling fuels. Do not carry any spare fuel containers in the vehicle. They can leak and cause an explosion or fire in the event of an accident. ◀

Observe the following when refueling

 Always observe all safety precautions posted at the service station when handling fuel. ◀


When refueling, insert the filler nozzle completely into the filler pipe. Pulling the nozzle out of the pipe during refueling:

- ▷ Results in premature pump shutoff
- ▷ Will reduce the effect of the fuel vapor recovery system on the pump.

As long as the filler nozzle is used properly, the fuel tank is full whenever the nozzle shuts off the first time.

Closing the gas cap

1. Insert gas cap
2. Turn gas cap clockwise until it clicks
3. Close fuel filler door.

 Insert the cap and turn it clockwise until it audibly clicks. Do not jam the strap between the gas cap and the vehicle. The following message is displayed if the cap is loose or missing. ◀


US models only:




The warning lamp* comes on. The gas cap is not correctly closed or missing. Check if the gas cap is correctly closed.

Fuel tank volume

Approx. 13.2 gallons/50 liters, of which approx. 2.1 gallons/8 liters are reserve capacity.

 Do not drive until the fuel tank is totally empty. Otherwise engine operations are not guaranteed and damage could occur. ◀

Fuel quality

 Do not fill the tank with leaded gasoline; otherwise the catalytic converter will be permanently damaged. Do not fill the tank with E85, i.e. fuel containing 85 % ethanol, nor with flex fuel. Otherwise the engine and fuel supply system will be damaged. ◀

Required fuel

Super Premium gasoline/AKI 91

REFUELING


This gasoline is highly recommended.

However, you may also use gasoline with less AKI. The minimum AKI rating is 87.

If you use gasoline with this minimum AKI rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no effect on the engine life.

Use high-quality brands

Field experience has indicated significant differences in fuel quality: volatility, composition, additives, etc., among gasolines offered for sale in the United States and Canada. Fuels containing up to and including 10% ethanol or other oxygenates with up to 2.8% oxygen by weight, that is, 15% MTBE or 3% methanol plus an equivalent amount of co-solvent, will not void the applicable warranties with respect to defects in materials or workmanship.

 The use of poor-quality fuels may result in driveability, starting and stalling problems especially under certain environmental conditions such as high ambient temperature and high altitude. Should you encounter driveability problems which you suspect could be related to the fuel you are using, we recommend that

you respond by switching to a recognized high-quality brand such as gasoline that is advertised as Top Tier Detergent Gasoline. Failure to comply with these recommendations may result in unscheduled maintenance. ◀




Manual release with the MINI

In the event of an electrical malfunction, the fuel filler door can be unlocked manually.

1. Remove the side trim panel on the left-hand side of the luggage compartment
2. Pull the white lever toward the rear.
The fuel filler door is released
3. Open the fuel filler door.

REFUELING



Manual release with the MINI Convertible

In the event of an electrical malfunction, the fuel filler door can be unlocked manually.

1. Remove the cover of the side trim panel on the left-hand side, see arrow 1
2. Pull the green strap toward the rear, see arrow 2.
The fuel filler door is released
3. Open the fuel filler door.


TIRE INFLATION PRESSURE


Information for your safety

It is not merely the tire's service life, but also driving safety and driving comfort that depend on the condition of the tires and the maintenance of the specified tire pressure.

Checking tire inflation pressures

Check the tire inflation pressures only on cold tires. This means after driving a maximum of 1.25 miles/2 km or when the vehicle has been parked for at least 2 hours. Warm tires have higher pressures.

 Check the tire inflation pressures regularly and correct them, if necessary, including the space-saver spare tire: at least twice a month and before an extended trip. Otherwise, incorrect tire pressures can cause driving instability or tire damage, ultimately resulting in accidents. Do not drive with deflated, i.e. flat, tires except if Run-Flat Tires are fitted. A flat tire greatly impairs steering and braking response, and can lead to complete loss of control over the vehicle. ◀

 After correcting the tire inflation pressure, reinitialize the Flat Tire Monitor, refer to page 74. ◀





Tire inflation pressures for original tires

The tire inflation pressures for your standard tires are shown on the driver's-side door post, visible when the door is open.

Tire inflation pressures for other tire sizes

In the following tire pressure table, all pressures are given for the specified tire sizes at ambient temperature.

 In order to determine the correct inflation pressures for your tires, refer to the values for the tire size in question. ◀






Checking the inflation pressure on the space-saver spare tire

Behind the bumper there is a valve extension accessible from the outside for checking the inflation pressure.

Tire size

The tire inflation pressures apply to the tire sizes approved and the tire brands recommended by the manufacturer of your MINI. Your MINI Dealer will be glad to advise you.




TIRE INFLATION PRESSURE

Model	Tire size	Pressures specified in psi/kPa					
	All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature						
	Traveling speeds			up to 100 mph/ 160 km/h		above 100 mph/ 160 km/h	
MINI COOPER/ MINI COOPER Convertible	175/65 R 15 84 H M+S A/S 175/65 R 15 84 H 195/55 R 16 87 V M+S A/S 195/55 R 16 87 H M+S A/S, Convertible only 195/55 R 16 87 H 205/45 R 17 84 V M+S A/S 205/45 R 17 84 V	30/210	30/210	30/210	30/210	35/240	35/240
	175/60 R 15 84 H M+S 175/60 R 16 82 H M+S 195/55 R 16 87 H M+S 205/45 R 17 84 V M+S 205/40 R 18 82 W	33/230	33/230	33/230	33/230	38/260	38/260
	Space-saver spare tire: T 115/70 R 15 90 M	61/420	61/420	61/420	61/420	-	-

TIRE INFLATION PRESSURE

Model	Tire size	Pressures specified in psi/kPa					
	All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature						
	Traveling speeds			up to 100 mph/ 160 km/h		above 100 mph/ 160 km/h	
MINI COOPER S	195/55 R 16 87 V M+S A/S 195/55 R 16 87 V	30/210	30/210	30/210	30/210	35/240	35/240
	195/55 R 16 87 H M+S	33/230	33/230	33/230	33/230	38/260	38/260
	205/45 R 17 84 V M+S A/S 205/45 R 17 84 V M+S 205/45 R 17 84 V	35/240	35/240	35/240	35/240	39/270	39/270
	175/60 R 16 82 H M+S 205/40 R 18 82 W	36/250	36/250	36/250	36/250	41/280	41/280
MINI COOPER S with John Cooper Works Kit*	195/55 R 16 87 V M+S A/S 195/55 R 16 87 V	32/220	32/220	32/220	32/220	35/240	35/240
	195/55 R 16 87 H M+S	33/230	33/230	33/230	33/230	38/260	38/260
	205/45 R 17 84 V M+S A/S 205/45 R 17 84 V M+S 205/45 R 17 84 V	35/240	35/240	35/240	35/240	39/270	39/270
	175/60 R 16 82 H M+S 205/40 R 18 82 W	36/250	36/250	36/250	36/250	41/280	41/280

TIRE INFLATION PRESSURE

Model	Tire size	Pressures specified in psi/kPa					
	All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature						
	Traveling speeds			up to 100 mph/ 160 km/h		above 100 mph/ 160 km/h	
MINI COOPER S Convertible	195/55 R 16 87 V M+S A/S 195/55 R 16 87 V	30/210	30/210	30/210	30/210	35/240	35/240
	195/55 R 16 87 H M+S	33/230	33/230	33/230	33/230	38/260	38/260
	205/45 R 17 84 V M+S A/S 205/45 R 17 84 V M+S 205/45 R 17 84 V	35/240	35/240	35/240	35/240	38/260	38/260
	175/60 R 16 82 H M+S 205/40 R 18 82 W	36/250	36/250	36/250	36/250	41/280	41/280
MINI COOPER S Convertible with John Cooper Works Kit*	195/55 R 16 87 V M+S A/S 195/55 R 16 87 V	32/220	32/220	32/220	32/220	35/240	35/240
	195/55 R 16 87 H M+S	33/230	33/230	33/230	33/230	38/260	38/260
	205/45 R 17 84 V M+S A/S 205/45 R 17 84 V M+S 205/45 R 17 84 V	35/240	35/240	35/240	35/240	39/270	39/270
	175/60 R 16 82 H M+S 205/40 R 18 82 W	36/250	36/250	36/250	36/250	41/280	41/280

More information about permissible loads and weights can be found on pages [151](#), [152](#).

TIRE CODING

Knowing the tire code on the tire's sidewall makes it easier for you to choose and identify the correct tires.

Tire size

e.g. 205/45 R 17 84 V

Nominal width in mm

Cross-sectional ratio in %

Radial belt construction

Rim diameter in inches

Load index, not on ZR tires

Speed code letter, in front of the R on ZR tires

Speed code letters:

Q = up to 100 mph / 160 km/h
T = up to 118 mph / 190 km/h
H = up to 131 mph / 210 km/h
V = up to 150 mph / 240 km/h
W = up to 167 mph / 270 km/h

Tire Identification Number

Tires with DOT codes meet the guidelines of the US Department of Transportation.

DOT code:

e.g. DOT xxxx xxx 3506

Manufacturer's code for tire make

Tire size and tire version

Tire age

Tire age

The tire's date of manufacture is included in the tire coding:
DOT...3506 means that the tire was manufactured in the 35th week of the year 2006.

The manufacturer of your MINI recommends replacing all tires after 6 years at the latest, even if a tire service life of 10 years is possible.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example:

Treadwear 200 Traction AA

Temperature A

DOT quality grades

Tread wear

Traction AA A B C

Temperature A B C



All passenger car tires must conform to Federal Safety Requirements in addition to these grades. ◀

Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half, 1 ½, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

TIRE CODING

Traction

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics. ◀

Temperature

The temperature grades are A, the highest, B and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety

Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure. ◀

RSC: Run-Flat Tires

You will recognize Run-Flat Tires by a circular symbol containing the letters RSC on the side of the tire, refer to page [111](#).

M+S

Winter and all-season tires. These have better winter performance properties than summer tires.

TIRE CONDITION

Inspect your tires frequently for tread wear, signs of damage and for foreign objects lodged in the tread. Check the tread depth.

Tire tread

Tread depth should not be allowed to go below 1/8 in/3 mm even though in Europe, for example, the legally specified minimum tread depth is only 1/16 in/1.6 mm. Below 1/8 in/3 mm tread depth, there is a very high danger of hydroplaning at higher speeds, even with only small amounts of water on the road.

At tread depths below approx. 1/6 in/4 mm, the ability of winter tires to cope with winter driving conditions decreases perceptibly. For safety reasons, new tires should be mounted.

TIRE CONDITION



Wear indicators in the tread-groove base are spread around the circumference of the tire and are marked on the sidewall of the tire with TWI, Tread Wear Indicator. When tire tread is worn down to the level of the wear indicators, the remaining tread depth is 1/16 in/1.6 mm.

Wheel/tire damage



Due to low-profile tires, please note that wheels, tires and suspension parts are more susceptible to road hazards and consequential damage.

Unusual vibrations during driving may indicate tire damage or other damage to the vehicle. This may be caused, for example, by driving over a curb. This is also true for abnormalities in the vehicle's handling characteristics, such as a pronounced tendency to pull to the left or right.

In such situations, reduce your speed immediately. Drive carefully to the nearest MINI Dealer or tire dealer, or have the vehicle towed there, if necessary.

Tire damage can endanger the lives of both the vehicle occupants and other road users. ◀

RUN-FLAT TIRES*




You will recognize Run-Flat Tires by a circular symbol containing the letters RSC on the side of the tire.

Run-Flat Tires consist of conditionally self-supporting tires and special rims. The tire reinforcement ensures that driving remains possible to a restricted degree in the event of a pressure drop or even a flat tire.

For information on continuing to drive with a flat tire, refer to Flat tire warning, page 75.

Tire change set


 In case of a flat tire, the tire change set is not needed, since your vehicle has Run-Flat Tires.

When changing a tire, always observe the safety measures and the procedure for changing tires starting on page 133. ◀


Your vehicle is additionally equipped with a tire change set.

In the MINI COOPER and MINI COOPER Convertible this is located in the luggage compartment under the floor mat.

In the MINI COOPER S and MINI COOPER S Convertible, the tire change set is located in a separate bag which is attached to the lashing eyelets on the luggage compartment floor by means of tie-down straps.


 Have new wheels and tires mounted only by your MINI Dealer or a specialized tire shop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer. Work that is improperly carried out could result in consequential damage and pose safety hazards. ◀

Retreaded tires

 The manufacturer of your MINI recommends that you avoid using retreaded tires, as this could impair driving safety. This is due to possible variations in casing structures and, in some cases, to their extreme age, factors which can lead to limited durability. ◀

NEW WHEELS AND TIRES

The correct wheels and tires

 The manufacturer of your MINI recommends mounting only wheels and tires that it has specifically approved for use on your particular model. Although other wheels and tires may theoretically have the same dimensions, variations in factors such as manufacturing tolerances can result in contact between tire and bodywork, ultimately leading to serious accidents. The manufacturer of your MINI cannot evaluate non-approved wheels and tires to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are mounted. ◀


Your MINI Dealer will be glad to inform you about the correct wheel and tire combination for your vehicle.

The correct wheel and tire combination is also important for various systems that would otherwise be impaired, e.g. ABS or DSC.

To maintain good handling and vehicle response, use only tires of a single brand and tread configuration. In the event of tire damage, remount the previous wheel and tire combination as soon as possible.

Run-Flat Tires

For your own safety, use Run-Flat Tires when mounting new tires or replacing summer tires with winter tires or vice versa. Keep in mind that no spare wheel is available in the event of a flat. Your MINI Dealer will be glad to advise you.

 For safety reasons, the manufacturer of your MINI recommends having Run-Flat Tires replaced, not repaired, if they are damaged. ◀



Tire designation

For each tire size, the manufacturer of your MINI recommends certain tire brands. You can recognize these by the clearly visible designation on the tire's sidewall.

When used properly these tires meet the highest standards regarding safety and handling characteristics.

NEW WHEELS AND TIRES

Special characteristics of winter tires

The manufacturer of your MINI recommends winter tires for driving in adverse winter road conditions. While all-season tires with the M+S designation provide better winter traction than summer tires, they generally do not achieve the full performance of winter tires.

Observe speed ratings:



Never exceed the maximum speed for which the winter tires are rated. ◀

Storage

Store tires in a cool, dry place, protecting them against light whenever possible. Protect the tires against contact with oil, grease and fuel. Do not exceed the tire inflation pressure specified on the tire sidewall.

SNOW CHAINS*

Only certain types of snow chains have been tested by the manufacturer of your MINI, classified as road-safe and recommended. Contact your MINI Dealer for more details. Their use is only permitted in pairs on the front wheels on winter tires of the following types:

▷ 175/65 R 15 M+S

▷ 175/60 R 16 M+S.

When fitting, comply with the manufacturer's instructions. With chains, do not exceed a speed of 30 mph / 50 km/h.




Do not initialize the Flat Tire Monitor after attaching snow chains to the tires.

When driving with snow chains, it can be helpful to switch off the ASC or DSC for a brief period, refer to page [72](#). ◀

BONNET

! Do not attempt to service your vehicle if you do not have the required technical background. If you are not familiar with the regulations to be observed, have the necessary work on your vehicle carried out only by a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer. Work that is improperly carried out could result in consequential damage and pose safety hazards. ◀



To unlock

Pull the lever in the right door area beneath the instrument panel.



To open


1. Reach under the bonnet
2. Pull the release lever
3. Open the bonnet.

To close

Allow the bonnet to fall from a height of approx. 1 ft/30 cm.

! Make sure that the closing range of the bonnet is unobstructed, otherwise personal injury could result. If it is determined that the bonnet is not completely closed while driving, stop immediately and close it securely, also refer to page 17. ◀

ENGINE COMPARTMENT: MINI COOPER AND MINI COOPER CONVERTIBLE




- 1 Reservoir for windshield and rear window washer system* [64](#)
- 2 Vehicle identification number
- 3 Coolant expansion tank [118](#)

- 4 Engine oil filler neck [117](#)
- 5 Battery [140](#)
- 6 Brake fluid reservoir [120](#)

- 7 Reservoir for headlamp cleaning system* [64](#)
- 8 Engine oil dipstick [117](#)

MVD1870CMB

ENGINE COMPARTMENT: MINI COOPER S AND MINI COOPER S CONVERTIBLE



1 Reservoir for windshield and rear window washer system* 64

2 Vehicle identification number

3 Coolant expansion tank 118

4 Engine oil filler neck 117



5 Auxiliary terminal for jump-starting 142

6 Brake fluid reservoir 120

7 Reservoir for headlamp cleaning system* 64

8 Engine oil dipstick 117

ENGINE OIL




Measuring the oil level

1. With the vehicle's engine at normal operating temperature, i.e. after uninterrupted driving for at least 6 miles/ 10 km, park the vehicle on a level surface
2. Switch off the engine
3. Pull the dipstick out after approx. 5 minutes and wipe it off with a lint-free cloth, paper towel, or similar material
4. Carefully push the dipstick all the way into the guide tube and pull it out again.


The oil level should be between the two marks on the dipstick.


As with fuel economy, oil consumption is directly influenced by your driving style and vehicle operating conditions.


The oil volume between the two marks MIN, MAX on the dipstick corresponds to approx. 1.1 quarts/1 liter.

 Do not fill beyond the upper mark on the dipstick. Excess oil will damage the engine. ◀

Adding engine oil

 Only top up oil when the oil level has dropped to just above the lower mark of the dipstick. However, never allow the level to drop below the lower mark. ◀

 Add oil within the next 30 miles/ 50 km, otherwise the engine could be damaged. ◀

 Always store oil, grease, etc., out of reach of children. Comply with all warning labels and information on lubricant containers, otherwise health risks may result. ◀

Oil change

Have the oil changed only by a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer.


ENGINE OIL


Approved engine oils

The quality of the engine oil selected has critical significance for the operation and service life of an engine. Based on extensive testing, the manufacturer of your MINI approves only certain grades of engine oil.

Only use High Performance Synthetic Oil approved by the manufacturer of your MINI.

If MINI High Performance Synthetic Oil is not available, you can add small quantities of another synthetic oil in between oil changes. Only use oils with a specification of API SH or higher.


 If you have any further questions regarding MINI High Performance Synthetic Oil or approved synthetic oils, your MINI Dealer will be glad to advise you. ◀

 Do not use any oil additives, as they could cause engine damage under some circumstances. ◀

Viscosity grades


Viscosity is a measure of an oil's flow rating and is classified into SAE grades.

The correct SAE grade for your MINI is determined by the climatic conditions of the region in which you normally drive your MINI.


 Approved oils feature the SAE grades 5W-40 and 5W-30. ◀


These oils can be used for driving at all outside temperatures.

COOLANT


 Do not open the cooling system when the engine is hot. Escaping coolant can cause burns. ◀

Coolant consists of water and a coolant additive. Not all commercially available additives are suitable for your MINI. Your MINI Dealer knows which additives are suitable and will be glad to advise you.

 Only use suitable additives, otherwise the engine can be damaged. The additives are hazardous to your health. ◀

 Comply with the applicable environmental laws regulating the disposal of coolant additives. ◀

COOLANT



As an example, the illustration shows the coolant tank of the MINI COOPER and the MINI COOPER Convertible.

Checking coolant level

1. The engine must be at ambient temperature
2. MINI COOPER and MINI COOPER Convertible:
Slowly pull the cap of the expansion tank by the tab until the excess pressure can escape. Then remove the cap completely.
MINI COOPER S and MINI COOPER S Convertible:
Slightly unscrew the cap of the expansion tank counterclockwise until the excess pressure can escape. Then remove the cap completely

3. The coolant level is correct if it is between the MIN and MAX markings on the transparent expansion tank
4. If necessary, slowly add coolant until the correct level is reached; do not overfill
5. MINI COOPER and MINI COOPER Convertible:
Reattach the cap and press it down firmly
MINI COOPER S and MINI COOPER S Convertible:
Screw the cap back on and tighten it firmly
6. Have the cause of the coolant loss removed as soon as possible.

BRAKE SYSTEM

Brake fluid level



The warning lamp comes on although the parking brake is not engaged:

The brake fluid level in the reservoir is too low, refer to page 16. At the same time, brake pedal travel may become significantly longer.

Have the system checked immediately.

If the brake fluid level is too low and brake pedal travel has become longer, there may be a defect in one of the brake system's hydraulic circuits.



Canadian models display this warning lamp.



If you continue driving, higher brake application pressure may be necessary, and there may be a slight pull to one side. Brake pedal travel may also be longer. Adapt your driving style accordingly. ◀

MINI MAINTENANCE SYSTEM



The MINI maintenance system helps maintain your vehicle's road safety and operational safety.

Please bear in mind that regular maintenance is not only necessary for the safety of your vehicle, but also plays a significant role in maintaining the resale value of the vehicle.

Service interval display

While conventional systems determine maintenance intervals according to fixed kilometer readings, the MINI Maintenance System takes the vehicle's driving conditions into account because not every mile is the same as another in this respect.

From a maintenance standpoint, 60,000 miles/100,000 km accumulated through short-distance driving cannot be treated the same as 60,000 miles/100,000 km accumulated through long-distance highway travel.

The condition-based MINI Maintenance System includes the Engine Oil Service and Inspections I and II.

Determining the maintenance intervals according to the actual use of the vehicle covers every kind of operating situation. People who drive very little, i.e. much less than 6,000 miles/10,000 km per year, should have the engine oil changed at least every 2 years since oil deteriorates over time, regardless of use.

For more information on the service interval display, refer to page [69](#).

Service and Warranty Information Booklet for US models, Warranty and Service Guide Booklet for Canadian models

For additional information on maintenance intervals and procedures, please refer to the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

As a precaution against rust, it is advisable to have the body checked for damage from rocks or gravel at the same time, depending upon operating conditions.



The manufacturer of your MINI recommends having maintenance and repair work carried out only by a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer.

Make sure that maintenance work is confirmed with an entry in the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models. These entries are your proof that the vehicle has received regular maintenance. ◀

SOCKET FOR ONBOARD DIAGNOSTICS OBD



Primary components of exhaust emissions can be checked by a device via the OBD socket.

This socket is located to the left of the driver's side, on the bottom of the instrument panel underneath a cover.

Exhaust emission values



The warning lamp comes on. The exhaust emissions have deteriorated. Have the vehicle checked as soon as possible.



Canadian models display this warning lamp.

Under some circumstances, the lamp will flash. This indicates severe engine misfiring. In this case, you should reduce your

speed and visit your nearest MINI Dealer as soon as possible. Severe engine misfiring can quickly lead to serious damage of emissions-related components, especially the catalytic converter.

▶ If the fuel filler cap is not properly tightened, the OBD system may conclude that fuel vapors are escaping, causing an indicator to light up. If the filler cap is then tightened, the indicator should go out within a few days. ◀

CARING FOR YOUR VEHICLE

Suitable car-care products

▶ Use the cleaning and car-care products available at your MINI Dealer. ◀

Washing your vehicle

You can wash your new MINI or MINI Convertible in automatic car washes from the beginning. Preference should be for cloth car washes. If, due to lack of availability, brush car washes must be used, modern systems with soft brushes should be given preference.



When using steam cleaners or high-pressure cleaners, maintain sufficient distance to the vehicle and do not exceed a maximum temperature of 140 °F / 60 °C. If the jet is too close or the pressure is too high, this can lead to damage or initial damage that can develop into more serious damage. Water that enters vehicle components can lead to damage over the long term.

After washing the vehicle, apply the brakes briefly to dry them, otherwise water can reduce braking efficiency over the short term and the brake rotors can corrode. Switch the rain sensor off when passing through an automatic car wash, refer to page 63. Failure to do so could result in

CARING FOR YOUR VEHICLE

damage caused by undesired wiper activation. ◀

Rod antenna



If necessary, for example before entering a car wash or a garage with elevator ramp, remove the rod antenna. To do so, grip the rod antenna at the base and unscrew it from the antenna foot by turning it to the left. ◀

Headlamps



When cleaning the headlamps, please note: do not rub the headlamps dry and do not use any abrasive or caustic cleaning products. Remove dirt and contamination, such as insects, by soaking with shampoo and then rinsing with plenty of water. Always use a deicer spray to remove accumulated ice and snow; never use a scraper. ◀

Vehicle paintwork

Regular care contributes greatly to driving safety and value retention.

Environmental influences varying from one region to the next can affect the vehicle paintwork. Please base the frequency and scope of car care on these various influences.

Care of upholstery

Depressions that come about on the upholstery material of the seats in daily use can be brushed out using a slightly damp brush against the grain.

The fact that velour lays down is not a quality defect, but rather is inevitable in the case of home textiles or clothing materials.

In the case of strong sunlight and longer parking periods, cover the seats or all windows to prevent discoloration.

Care of special parts

▷ Light-alloy wheels*:

Use wheel cleaner especially during the winter months, but do not use any aggressive, acidic, strong alkali or rough cleansers or steam jets above 140 °F / 60 °C. Observe the manufacturer's instructions

▷ Chrome parts* such as the bonnet grille, door handles, and similar parts: Particularly if they were exposed to road salt, clean these parts carefully with plenty of water and shampoo additive, if necessary. For additional treatment, use chrome polish

▷ Rubber components: Treat only with water or rubber care products.



Do not use silicon sprays or other silicon-containing care products, otherwise noise and damage could occur. ◀

▷ Plastic parts, artificial leather surfaces, headliner, lamp lenses, cover glass over display elements as well as matt-black die-cast parts: Clean these parts with water and plastic care products, if necessary. Do not dampen seats and the headliner. Never use solvents such as lacquer thin-

CARING FOR YOUR VEHICLE

ner, heavy-duty grease remover, fuel or similar

▷ Fine-wood parts*:

Please clean wood paneling and other wood parts only with a damp cloth. Dry off with a soft cloth

▷ Safety belts:

Only clean using mild soap, leaving the belts installed.

Do not dry clean, as the fabric can be destroyed.

Always roll up safety belts only when dry.

Dirty safety belts prevent unrolling and thus negatively affect safety

▷ Floor carpets and floor mats*:

Use an interior cleaner to clean these items if they are heavily soiled. Floor mats can be removed to allow the interior to be cleaned

▷ Wiper blades:

Clean with soap and water. Replace wiper blades twice a year, before and after the cold season. This is particularly important on vehicles fitted with a rain sensor.

Caring for leather* and imitation leather

The leather and imitation leather used by the manufacturer of your MINI are high

quality products processed using state-of-the-art methods and will retain their quality level for many years if cared for properly.

Regular cleaning and care are necessary, as dust and road dirt scratch in pores and creases and lead to heavy wear as well as premature brittleness of the leather and imitation leather surface.

This is why you should use a cloth or vacuum cleaner to remove dust on a regular basis.

Since dirt and oil slowly destroy the protective layer of the leather and imitation leather, a treatment with a leather care product is necessary twice a year. This preserves the quality of the leather and prevents electrostatic charging.



Cleaning agents can contain hazardous or health-damaging substances. For this reason, always observe the warnings on the package. For interior cleaning, always open the doors or windows of the vehicle.

Do not use any products that are not intended for cleaning the vehicle. ◀

Care of the MINI Convertible's top

The appearance and service life of the convertible top largely depend on the proper care and operation of the convertible top.

You should therefore observe the following notes in particular:

- ▷ Whenever possible, park your vehicle in the shade to protect it from intense sunlight
- ▷ Do not fold the convertible top when it is wet, dirty or frozen; otherwise water marks, moisture stains and chafing could result
- ▷ If the vehicle is parked in an enclosed area for a longer period of time, make sure that there is sufficient ventilation
- ▷ Remove bird droppings immediately because they have corrosive properties.



Never use spot removers, paint thinner, solvents, cleaning fuel or similar since these products can destroy the rubber seals and cause leaks. ◀

CARING FOR YOUR VEHICLE

If the convertible top is very dirty, it is recommended that it be cleaned with a special convertible top cleaning agent. Your MINI Dealer will be glad to advise you.

Clean the convertible top as follows:

- ▷ Spray the convertible top with an approved convertible top cleaning agent
- ▷ Then scrub the convertible top with a wet sponge using circular motions
- ▷ Afterward, finish cleaning the vehicle in a car wash or rinse the convertible top thoroughly with plenty of water.


After washing the convertible top three to five times, it should be treated with a waterproofing agent.

Wind deflector*

- ▷ Clean the wind deflector with a soft sponge and water evenly across the entire surface so that water marks do not form
- ▷ Do not clean it with a vacuum cleaner or upholstery brush attachment, otherwise the net could be damaged.

VEHICLE STORAGE

Your MINI Dealer will be glad to advise you on what is important if the vehicle is to be decommissioned for longer than three months.



OVERVIEW

OVERVIEW

CONTROLS

CONTROLS

OPERATION, CARE, MAINTENANCE

OPERATION

OWNER SERVICE PROCEDURES

REPAIRS

TECHNICAL DATA

DATA

INDEX

INDEX

ONBOARD TOOL KIT



The picture shows as an example the tire change set with onboard tools for vehicles with the space-saver spare tire.

Depending on the equipment version, your vehicle is equipped with a special onboard tool kit stored at the locations described below:

Tire change set with onboard tools for space-saver spare tire

In the luggage compartment under the floor mat.

MINI Mobility System with tire change set and onboard tools

In the luggage compartment under the floor mat.

Tire change set and onboard tool kit with Run-Flat Tires


MINI COOPER and MINI COOPER Convertible:

▷ In the luggage compartment under the floor mat.

MINI COOPER S and MINI COOPER S Convertible:

- ▷ Tire change set:
in the luggage compartment in a separate pouch
- ▷ Onboard tool kit:
in the luggage compartment under the floor mat.


WIPER BLADES



Windshield wiper

1. Rotate the wiper arm completely out
2. Set the wiper blade at an angle
3. Press the securing spring, see arrow
4. Unhook the wiper blade towards the windshield
5. Pull the wiper blade past the wiper arm toward the top
6. Insert the new wiper blade
7. Press into position until you hear it engage.

WIPER BLADES




Rear window wiper*

1. Rotate the wiper arm completely out
2. Turn the wiper blade as far as it will go to the rear
3. Press the wiper blade against the limit and thus out of the mounting
4. Press the new wiper blade into the mounting.

LAMPS AND BULBS

Lamps and bulbs are an important component of vehicle safety. Therefore, proceed carefully when handling bulbs.

To replace bulbs which are not described here, please contact a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer.

 Do not touch the glass portion of a new bulb with your bare hands since even small amounts of impurities burn into the surface and reduce the service life of the bulb. Use a clean cloth, paper napkin, or similar material, or hold the bulb by its metallic base. ◀


A replacement bulb set can be obtained at your MINI Dealer.



Whenever working on the electrical system, switch off the electrical accessory you are working on or disconnect the cable from the negative terminal of the battery. Failure to do this could result in short circuits.

To prevent injuries and damage, comply with any instructions provided by the bulb manufacturer. ◀

LAMPS AND BULBS





1 Low beams

H7 bulb, 55 watts

2 High beams

H7 bulb, 55 watts

 The H7 bulb is pressurized. Therefore, wear safety glasses and protective gloves. If the lamp is damaged there is a risk of injury. ◀

 For checking and adjusting headlamp aim, please contact your MINI Dealer. ◀


Replacing bulbs

The headlamps are integrated into the bonnet.

1. Gently pull the retaining wire of the headlamp cover and guide it outwards
2. Fold down the headlamp cover
3. Disconnect the cable connector from the bulb socket and pull out the bulb
4. Place the bulb holder on the lower edge of the mounting and press it in until it engages in the bulb socket
5. Reconnect the cable connector and install the headlamp cover again.

Xenon lamps*

The service life of these bulbs is very long and the probability of a failure is very low, provided that they are not switched on and off an unusual number of times. If one of these bulbs should nevertheless fail, it is possible to continue driving with great caution using the fog lamps, provided traffic laws in your area do not prohibit this.

 Have any work on the xenon lamp system, including bulb replacement, carried out only by a MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of the MINI manufacturer. Due to high voltage, there is a risk of fatal injury if work on the xenon lamps is carried out improperly. ◀



Turn signal indicators, front

21 watt bulb

1. Open the bonnet
2. Reach into the opening for the turn signal indicators from above
3. Apply gentle pressure to the bulb holder while turning it to the left
4. Remove and replace the bulb.

Parking lamps and standing lamps

5 watt bulb

The parking lamps and standing lamps are integrated in the lamp housing of the turn signal indicator.

1. Turn the bulb holder to the left and pull out
2. Remove and replace the bulb.


LAMPS AND BULBS



Side turn signal indicators

5 watt bulb

1. Slide the lamp toward the rear of the vehicle and remove
2. Remove and replace the bulb.



Tail lamps

Turn signal lamp 1:

21 watts

Rear lamp 2:


21/5 watt bulb

Backup lamp 3:

16 watts

- 1 Turn signal indicator
- 2 Rear lamp/Brake lamp
- 3 Backup lamp

yellow
red
white



Replacing bulbs

To access the bulb holder, remove the cover on the side panel in the luggage compartment for MINI and MINI Convertible.

1. Unplug the power supply, arrow 1
2. Squeeze the retaining clips together, see arrows 2, and remove the bulb holder
3. Apply gentle pressure to the bulb while turning it to the left
4. Remove and replace the bulb
5. Press the bulb holder into position until you hear it engage
6. Plug in the power supply.

LAMPS AND BULBS



Rear fog lamp*

With the space-saver spare tire option:


Access to the lamp via the back or under-side of the bumper.

1. Press the clips together
2. Push the lamp out of the bumper
3. Apply gentle pressure to the bulb while turning it to the left
4. Remove and replace the bulb.

Other equipment:



In the event of a malfunction, please contact your MINI Dealer or a workshop that has specially trained personnel working in accordance with the specifications of your MINI manufacturer. ◀



License plate lamps

5 watt bulb

As an example, the illustration shows the license plate lamp of the MINI.

1. Apply a screwdriver to the recess and lever out the lamp cover
2. Replace the bulb.

Light-emitting diodes (LEDs)

Light-emitting diodes installed behind translucent lenses serve as the light sources for many of the controls and displays in your vehicle. These light-emitting diodes are related to conventional lasers, and legislation defines them as light-emitting diodes, Class 1.



Do not remove the protective lenses and avoid staring directly at the unfiltered beam for several hours, as inflammation of the retina could result. ◀

REPAIRING A FLAT TIRE



Safety measures in the event of a flat:

Park the vehicle as far away from flowing traffic as possible, and switch on the hazard warning flashers.

Turn the steering wheel to the straight-ahead wheel position and engage the steering lock. Engage the parking brake and shift into 1st or reverse gear – selector lever in P.

All passengers should be outside the vehicle and well away from your immediate working area – behind a guardrail, for instance.

If a portable hazard warning lamp is available, set it up on the roadside at an appropriate distance from the rear of the vehicle. Comply with all safety guidelines and regulations. ◀

In the event of a flat tire, different procedures should be followed depending on the equipment included in your vehicle:

- ▷ Vehicles with Run-Flat Tires, refer to page [111](#)
- ▷ Vehicles with a space-saver spare tire, refer to the following section
- ▷ Vehicles with MINI Mobility System, refer to page [137](#).

SPACE-SAVER SPARE TIRE*

To change a space-saver spare tire, proceed as follows:

- ▷ Remove space-saver spare tire, refer to the section after the next one
- ▷ Prepare for tire change, refer to page [135](#)
- ▷ Jack up the vehicle, refer to page [136](#)
- ▷ Mount the space-saver spare tire, refer to page [136](#)
- ▷ Tighten the lug bolts, refer to page [136](#)
- ▷ Drive with space-saver spare tire, refer to page [135](#).




Tire change set

On vehicles with a space-saver spare tire, the tire change set with onboard tools is stored in the luggage compartment under the floor mat.

- 1 Chock, folding
- 2 Hubcap remover
- 3 Wheel stud wrench
- 4 Jack
- 5 Special wrench for removing the space-saver spare tire
- 6 Towing eyelet
- 7 Lifting handle

The onboard tool kit includes a pouch with a plastic bag in which you can place the damaged wheel.

SPACE-SAVER SPARE TIRE*



Removing the space-saver spare tire


The screw connection of the space-saver spare tire is in the luggage compartment under the floor mat, on the base of the storage compartment for the tire change set.

1. Loosen the screw connection using the special wrench
2. Take out the cover panel
3. Screw the lifting handle from the onboard tool kit onto the thread
4. Raise the lifting handle slightly
5. Squeeze the securing spring
6. The space-saver spare tire is released and must be held by the lifting handle
7. Lower the space-saver spare tire with the lifting handle
8. Unscrew the lifting handle

SPACE-SAVER SPARE TIRE*




9. Pull out the space-saver spare tire towards the rear underneath the vehicle
10. Position the space-saver spare tire with the valve facing upwards
11. Unscrew the valve extension from the valve of the space-saver spare tire
12. Unscrew the dust cap from the extension and place it on the valve of the space-saver spare tire.


 Due to its different dimensions, the damaged wheel cannot be placed in the recess for the space-saver spare tire. ◀

Driving with the space-saver spare tire


Drive cautiously. Do not exceed a speed of 50 mph / 80 km/h.

You must expect changes in vehicle handling such as lower track stability during braking, longer braking distances and changes in self-steering properties when close to the handling limit. These effects are more pronounced when driving with winter tires.

 Only one space-saver spare tire may be mounted at one time. Reinstall a wheel and tire of the original size as soon as possible. ◀

 Check the tire inflation pressure at the earliest opportunity and correct it if necessary. Replace the defective tire as soon as possible and have the new wheel/tire assembly balanced. ◀

CHANGING TIRES

 Additional safety measures in the event of a tire change:


Change tires only on a flat, solid and non-slippery surface.

The vehicle or the jack could slip sideways on soft or slippery support surfaces, such as snow, ice, flagstones, etc..

Do not use a wooden block or similar object as a support base for the jack, as this would prevent it from extending to its full support height and reduce its load-carrying capacity.


Do not lie under the vehicle or start the engine when the vehicle is supported by the jack – risk of fatal injury. ◀

Preparing for a tire change

 Observe the safety precautions regarding flat tires on page 133. ◀


1. For vehicles with a space-saver spare tire:
Place the folding chock behind the front wheel on the other side of the vehicle; on downward inclines, place it in front of this wheel. If the wheel is changed on a surface with a more severe slope, take additional precautions to secure the vehicle from rolling
2. Loosen the lug bolts by a half turn.

CHANGING TIRES



Jacking up the vehicle

1. Place the jack at the jacking point closest to the wheel.
The jack base must be perpendicular to the surface beneath the jacking point

 The vehicle jack is designed for changing wheels only. Do not attempt to raise another vehicle model with it or to raise any load of any kind. Do so could cause accidents and personal injury. ◀



2. During jacking up, insert the jack head in the square recess of the jacking point
3. Jack the vehicle up until the wheel you are changing is raised from the ground.


Mounting a wheel

1. Unscrew the lug bolts and remove the wheel
2. Remove accumulations of mud or dirt from the mounting surfaces of the wheel and hub. Clean the lug bolts.
3. Mount the new wheel
4. Screw at least two lug bolts finger-tight into opposite bolt holes
5. Screw in the remaining bolts

6. Tighten all the lug bolts firmly in a diagonal pattern
7. Lower the vehicle
8. Remove the jack.

Tightening the lug bolts

Tighten the lug bolts in a diagonal pattern.

 As soon as possible, have the secure seating of the lug bolts, tightening torque 88.5 lb ft/120 Nm, checked using a calibrated torque wrench. Otherwise, a wheel coming loose can lead to a severe accident. ◀


Replace the defective tire as soon as possible and have the new wheel/tire assembly balanced.

MINI MOBILITY SYSTEM*

MINI Mobility System

The MINI Mobility System is provided to help you repair a flat tire. With the help of this system you can apply a liquid sealant on the inside of the tire, which seals the damaged area and enables you to continue to drive.

Preparing for tire repair

 Before using the MINI Mobility System read the warning and danger precautions on the equipment. ◀

If possible, leave objects in which have been forced into the tire.

Take off the tag regarding speed limits and stick it onto the steering wheel.

Using the MINI Mobility System

In order to repair a flat tire with the MINI Mobility System, proceed as follows:

- ▷ Pump in liquid sealant, refer to page [138](#)
- ▷ Reinflate the tire, refer to page [138](#)
- ▷ Distribute liquid sealant, refer to page [139](#)
- ▷ Check tire inflation pressure, refer to page [139](#)
- ▷ Drive on, refer to page [139](#).



MINI Mobility System with onboard tools

The MINI Mobility System with tire change set and onboard tools is located in the luggage compartment under the floor mat:

- 1 Jack
- 2 Wheel stud wrench
- 3 Hubcap remover
- 4 Wrench, screwdriver/Phillips screwdriver, towing eyelet
- 5 Compressor, hose with manometer and plug for cigarette lighter socket
- 6 Package with filling hose, valve remover and valve core
- 7 Filling canister
- 8 Hex wrench/screwdriver
- 9 Adapter for wheel lug lock


MINI MOBILITY SYSTEM*



MV00585CMA


Pumping in liquid sealant


1. Shake the filling canister
2. Screw the filling hose onto the filling canister
3. Unscrew the dust protection cap from the valve of the defective tire
4. Screw out the valve core with the valve remover. The valve remover is located in a package with the filling hose.

 Place the valve core and valve remover only on clean surfaces. ◀

5. Remove the cap from the filling hose
6. Push the filling hose onto the tire valve

7. Hold the filling canister with the cap down and squeeze. Squeeze the entire contents of the canister into the tire
8. Remove filling hose
9. Screw valve core into the tire valve with the valve remover.

 In the event of a lost or dirty valve core you will find another valve core in a package with the filling hose. Please remember that the liquid canister must be replaced every four years if the equipment has not been used. ◀




MV01426CMA


Reinflating the tire

1. Screw hose 1 with manometer onto the tire valve
2. Connect plug 3 to the cigarette lighter socket in the vehicle interior, refer to page 87
3. Ignition key in position 1: switch on compressor 2
4. Inflate the tires to at least 26 psi/ 180 kPa, but not to more than 36 psi/ 250 kPa.

To check the current air pressure, shut off the device for a short time.


 Do not run the compressor for longer than 6 minutes, otherwise the device will overheat and possibly be damaged. ◀

MINI MOBILITY SYSTEM*

 If an air pressure of 26 psi/180 kPa cannot be reached, unscrew the hose 1 and drive back and forth about 33 ft/10 m so that the liquid sealant is distributed in the tire. Afterwards repeat the procedure.


If an air pressure of 26 psi/180 kPa is still not reached, the tire is too badly damaged. Please contact the nearest MINI Dealer. ◀

5. Turn off compressor 2
6. Unscrew hose 1 from the tire valve
7. Store the MINI Mobility System back in the vehicle.

 The instructions for using the MINI Mobility System are also given on the equipment. ◀

Distributing liquid sealant


Immediately drive for approx. 10 minutes, so that the liquid sealant is uniformly distributed.

 Do not exceed a speed of 40 mph / 60 km/h.

If possible do not drive at a speed lower than 10 mph / 20 km/h. ◀


Checking tire inflation pressure

1. After driving for approx. 10 minutes, pull over at a suitable location
2. Screw hose with manometer back onto the tire valve
3. Check the tire inflation pressures.


 The tire inflation pressure must be at least 18 psi/130 kPa. If it is not, do not continue driving. ◀


If 18 psi/130 kPa are displayed:

4. Ignition key position 1: switch on compressor 2. Correct the tire inflation pressure to the specified value, refer to the tire inflation pressure table on page 105
5. Replace the tire as soon as possible.

 The use of the MINI Mobility System may be ineffective with tire damage larger than approx. 1/6 in/4 mm. Please contact the nearest MINI Dealer if the tire cannot be made drivable with the MINI Mobility System. ◀


Driving on

 Do not exceed the permitted maximum speed of 50 mph / 80 km/h; otherwise an accident could happen. ◀

 Replace the defective tire as soon as possible and have the new wheel/tire assembly balanced. Have the MINI Mobility System refilled. ◀

Tire change set

When changing a tire, always observe the safety measures and the procedure for changing tires starting on page 133.

 In case of a flat tire the tire change set is not needed due to the availability of the MINI Mobility System. ◀

VEHICLE BATTERY

Storage location

MINI COOPER and MINI COOPER Convertible:

The battery is located in the engine compartment, refer to page [115](#).

MINI COOPER S and MINI COOPER S Convertible:

The battery is located in the luggage compartment under the floor mat.

Battery care

The battery is absolutely maintenance-free, that is, the original electrolyte will normally last for the service life of the battery under moderate climatic conditions. Your MINI Dealer will be glad to advise you if you have any questions regarding the battery.

Charging the battery

Only charge the battery in the vehicle via the terminals in the engine compartment with the engine switched off, refer to 'Jump-starting', page [142](#).

Disposal




After replacing old batteries, return the used batteries to your MINI Dealer or to a recycling point. Maintain the battery in an upright position for transport and storage. Secure the battery to prevent it from tilting during transport. ◀


Power failure

After a temporary power failure, e.g. due to a discharged battery, some of your vehicle's equipment will function only to a limited extent and must be reinitialized or readjusted. Individual settings are also lost and must be reprogrammed:

- ▷ The clock must be reset, refer to page [67](#)
- ▷ The power windows must be reinitialized, refer to page [32](#)
- ▷ Radio*:
The stations must be reset, refer to the Owner's Manual for Radio
- ▷ Navigation system*:
It may take some time for its operability to be restored, refer to the Owner's Manual for Navigation System.

FUSES

 Do not attempt to repair a blown fuse or replace it with a fuse of a different color or Ampere rating. To do this could cause a fire in the vehicle resulting from a circuit overload. ◀

 If a second fuse blows in the same circuit, have the cause rectified by your MINI Dealer. ◀

A fuse allocation diagram is located on the inside of the fuse box cover panel.

Plastic tweezers and spare fuses can be found in the fuse box in the vehicle interior.



In the engine compartment

In the MINI COOPER and the MINI COOPER Convertible to the right of the battery. In the MINI COOPER S and the MINI COOPER S Convertible to the right of the air filter box.

Open the fuse box lid. To do so, press the clip fastener.



In the vehicle interior


On the left side of the footwell in the side trim panel.

Open the fuse box lid. To do so, press the fastener.

JUMP-STARTING


When your battery is discharged, you can use two jumper cables to start your vehicle with power from the battery in a second vehicle. Correspondingly you can help start another vehicle. Only use jumper cables with fully insulated handles on the terminal clamps.


Preparing for jump-starting

 Do not touch live wiring and cables on a running engine. There is a risk of fatal injury if you do this. Carefully observe the following instructions to avoid personal injury and/or damage to either vehicle or both vehicles. Make sure that there is no contact between the bodywork of the two vehicles to avoid a short circuit hazard. ◀

1. Check whether the battery of the support vehicle has 12 Volts and approximately the same capacity measured in Ah. These data are printed on the battery
2. Switch off the engine of the support vehicle
3. Switch off any electrical systems and components in both vehicles.

Connect the jumper cables

 Always adhere to this sequence when connecting the jumper cables; failure to observe this procedure can lead to sparking and pose an injury hazard. ◀



The illustration shows the auxiliary jump-starting terminal on the MINI COOPER S and the MINI COOPER S Convertible. In the MINI COOPER S and the MINI COOPER S Convertible, the auxiliary jump-starting terminal, arrow 1, acts as the positive battery terminal, refer to view of engine compartment on page 116. The cover is marked with a +.

1. Remove the cover of the battery or open the cover of the auxiliary jump-starting terminal:
 - ▷ MINI COOPER and MINI COOPER Convertible:
Remove the battery cover.
To do so, press the two clips simultaneously.
 - ▷ MINI COOPER S and MINI COOPER S Convertible:

JUMP-STARTING


- Flip open the cover of the auxiliary jump-starting terminal, arrow 1
2. Connect one terminal clamp of the plus/+ jumper cable to the positive battery terminal or to an auxiliary jump-starting terminal of the support vehicle
3. Connect the other terminal clamp of the plus/+ jumper cable to the positive battery terminal or to an auxiliary jump-starting terminal of the vehicle to be started

Engine or body ground in your MINI or MINI Convertible: arrow 2.

4. Connect one terminal clamp of the minus/- jumper cable to the negative battery terminal or to an engine or body ground of the support vehicle
5. Connect the second terminal clamp of the minus/- jumper cable to the negative terminal of the battery or to the engine or body ground of the vehicle to be started.


Performing the jump-start

1. Start the engine of the support vehicle and allow it to run at increased idle speed for several minutes
2. Start the engine of the other vehicle in the usual manner.
If the first start attempt is not successful, wait a few minutes before another attempt in order to allow the discharged battery to recharge
3. Allow the engines of both vehicles to run for several minutes.


 On the MINI or MINI Convertible: Before disconnecting the jumper cables, switch on the lighting, the rear window defroster and the highest blower speed to prevent a voltage surge from the regulator to the electrical systems and components. ◀


4. Then disconnect the jumper cables in the reverse order.

If necessary have the battery checked and completely charged at a MINI Dealer.

 Do not use spray starter fluids to start the engine. ◀


TOWING AND TOW-STARTING

 Observe all applicable laws and regulations for towing and tow-starting. ◀

 Do not transport any occupant other than the driver in a vehicle that is being towed. ◀

Using the towing eyelet

The screw-in towing eyelet is stored in the onboard tool kit, refer to page 128; be sure that it remains with the vehicle at all times. It can be attached at the front or rear of your vehicle.

 Use only the towing eyelet supplied with the vehicle and screw it in firmly until it stops. Use the towing eyelet for towing on paved roads only. Avoid subjecting the towing eyelet to lateral loads, e.g. do not lift the vehicle using the towing eyelet. Otherwise, the towing eyelet and the vehicle could be damaged. ◀

TOWING AND TOW-STARTING




Access to the threaded socket

The illustration shows by way of example the MINI COOPER and the MINI COOPER Convertible.

Pry out the cover in the front or rear bumper by inserting a screwdriver into the recess.

Being towed


 Make sure that the ignition key is in position 1; otherwise the steering lock could engage and prevent the vehicle from being steered. There is no power assist while the engine is off. Therefore, you will need to exert more force to brake and steer the vehicle. ◀

Turn on the hazard warning flashers, if required by national regulations. If the electrical system has failed, clearly identify the vehicle being towed, e.g. by placing a sign or a warning triangle in the rear window.

MINI or MINI Convertible with manual transmission:

Put the gearshift lever in idle position.

MINI or MINI Convertible featuring automatic transmission with Steptronic:

 Only tow vehicles featuring automatic transmission with Steptronic with a tow truck; otherwise the transmission can be damaged, refer to page 145. ◀


Overriding the selector lever lock, refer to page 59.

Towing methods

In some countries, it is not permitted to tow the vehicle with a tow bar or tow rope on public roads.


Familiarize yourself with the applicable towing regulations for the country in which you are driving.

With a tow bar:

 The towing vehicle must not be lighter than the vehicle being towed; otherwise, vehicle handling can no longer be controlled. ◀


The towing eyelets of both vehicles should be on the same side. If the tow bar can only be used in a diagonal position, please note the following:

- ▷ Clearance and maneuverability will be strictly limited in corners
- ▷ The inclination of the tow bar produces lateral force.


 Attach the tow bar to the towing eyelet only. Attaching it to other parts of the vehicle can result in damage. ◀

With a tow rope:

When the towing vehicle is driving off, make sure that the tow rope is taut.


 Use nylon ropes or straps for towing because they prevent sudden jerking movements. Attach the tow rope to the towing eyelet only. Attaching it to other parts of the vehicle can result in damage. ◀

TOWING AND TOW-STARTING




With a tow truck:

Have the MINI or MINI Convertible transported by a tow truck with a lift sling, or on a flatbed.

 Only tow vehicles featuring automatic transmission with Steptronic with the front wheels raised or on a special transport vehicle; otherwise the transmission can be damaged. Do not lift the vehicle by the towing eyelet, nor by parts of the body or chassis. Otherwise damage could result. ◀

Tow-starting

 Do not tow-start vehicles featuring automatic transmission with Steptronic. Jump-starting, refer to page [142](#). ◀

Avoid tow-starting the vehicle whenever possible. Jump-start the engine instead, refer to page [142](#). Vehicles with a catalytic converter should only be tow-started if the engine is cold. Vehicles with an automatic transmission cannot be tow-started.

1. Turn on the hazard warning flashers; comply with national regulations
2. Turn the ignition key to position 2
3. Engage the 3rd gear
4. Have the vehicle towed with the clutch completely depressed and then slowly release the clutch. After the engine has started, immediately depress the clutch again completely
5. Pull over at a suitable location, remove the tow bar or tow rope, and turn off the hazard warning flashers
6. Have the vehicle checked.



OVERVIEW

OVERVIEW

CONTROLS

CONTROLS

OPERATION, CARE, MAINTENANCE

OPERATION

OWNER SERVICE PROCEDURES

REPAIRS

TECHNICAL DATA

DATA


INDEX

INDEX

ENGINE DATA

		MINI COOPER, MINI COOPER Convertible	MINI COOPER S, MINI COOPER S Convertible	MINI COOPER S, MINI COOPER S Convertible with John Cooper Works Kit*
Displacement	cu in/cm ³	97.5/1,598	97.5/1,598	97.5/1,598
Number of cylinders		4	4	4
Maximum output at engine speed	hp/kW rpm	115/85 6,000	168/125 6,000	208/155 6,950
Maximum torque at engine speed	lb ft/Nm rpm	111/150 4,500	162/220 4,000	180/245 4,500

DIMENSIONS: MINI



All measurements in inches/millimeters. Smallest turning circle dia. 34 ft 10 in/10.66 m.
Values following a ; are differing values for MINI COOPER S.

HYUNDAICMA

OVERVIEW

CONTROLS


OPERATION

REPAIRS

DATA

INDEX

DIMENSIONS: MINI CONVERTIBLE



All measurements in inches/millimeters. Smallest turning circle dia. 34 ft 10 in/10.66 m.
Values following a ; are differing values for MINI COOPER S.

WEIGHTS: MINI

		MINI COOPER	MINI COOPER S
Curb weight, with all optional special equipment	with manual transmission	2,524/1,145	2,679/1,215
	automatic transmission with Steptronic	2,557/1,160	2,723/1,235
Approved gross vehicle weight	with manual transmission	3,340/1,515	3,494/1,585
	automatic transmission with Steptronic	3,373/1,530	3,538/1,605
Cargo and luggage load capacity	lbs/kg	816/370	816/370
Approved front axle load	lbs/kg	1,918/870	1,962/890
Approved rear axle load	lbs/kg	1,609/730	1,698/770
Approved roof load, with special MINI roof rack	lbs/kg	165/75	165/75
Luggage compartment volume with rear backrest folded down	cu ft/liters	5.3/150	5.3/150
	cu ft/liters	23.7/670	23.7/670

WEIGHTS: MINI CONVERTIBLE

		MINI COOPER Convertible	MINI COOPER S Convertible
Curb weight, with all optional special equipment with manual transmission	lbs/kg	2,700/1,225	2,844/1,290
automatic transmission with Steptronic	lbs/kg	2,734/1,240	2,888/1,310
Approved gross vehicle weight with manual transmission	lbs/kg	3,472/1,575	3,616/1,640
automatic transmission with Steptronic	lbs/kg	3,505/1,590	3,660/1,660
Cargo and luggage load capacity	lbs/kg	771/350	771/350
Approved front axle load	lbs/kg	1,918/870	1,962/890
Approved rear axle load	lbs/kg	1,697/770	1,763/800
Approved roof load, with special MINI roof rack	lbs/kg	–	–
Luggage compartment volume	cu ft/liters	4.2/120	4.2/120
with luggage compartment cover hooked in above	cu ft/liters	5.8/165	5.8/165
with rear backrest folded down	cu ft/liters	21.4/605	21.4/605

CAPACITIES

			Notes
Fuel tank Reserve	gal./liters gal./liters	approx. 13.2/50 approx. 2.1/8	Fuel quality, refer to page 101
Window washer system Headlamp washer system	quarts/liters quarts/liters	approx. 2.4/2.3 approx. 2.6/2.5	More details, refer to page 64
Cooling system including heater circuit	quarts/liters quarts/liters	5.6/5.3 MINI COOPER and MINI COOPER Convertible 6.3/6.0 MINI COOPER S and MINI COOPER S Convertible	More details, refer to page 118



OVERVIEW

CONTROLS

OPERATION, CARE, MAINTENANCE

OWNER SERVICE PROCEDURES

TECHNICAL DATA

INDEX

OVERVIEW

CONTROLS

OPERATION

REPAIRS

DATA

INDEX

EVERYTHING FROM A TO Z

- A**
- ABS Antilock Brake System [72](#)
 - indicator lamp [17, 18](#)
 - Accessories, refer to Your individual vehicle [6](#)
 - Activated-charcoal filter [84](#)
 - Adjusting interior temperature [80, 83](#)
 - Air circulation, refer to Recirculated air mode [80, 83](#)
 - Air conditioning system [79](#)
 - Air distribution
 - air conditioning system [80](#)
 - automatic climate control [83](#)
 - individual [84](#)
 - manual [80](#)
 - Air outlets, refer to Ventilation [81, 84](#)
 - Air pressure, refer to Tire inflation pressure [104](#)
 - Air volume
 - air conditioning system [80](#)
 - automatic climate control [83](#)
 - Airbags [76](#)
 - passenger airbag status lamp [77](#)
 - safe seating position [42](#)
 - warning lamp [18](#)
 - AKI, refer to Fuel quality [101](#)
 - All Season traction Control (ASC) [72](#)
 - indicator lamps [17, 18](#)
 - All-season tires, refer to Winter tires [113](#)
 - Antenna [123](#)
 - Antifreeze
 - coolant [118](#)
 - washer fluid [64](#)
 - Antilock Brake System (ABS) [72](#)
 - indicator lamp [17, 18](#)
 - Anti-theft system [24](#)
 - Approved axle load, refer to Weights [151, 152](#)
 - Approved engine oils [118](#)
 - Approved gross vehicle weight, refer to Weights [151, 152](#)
 - Armrest, refer to Center armrest [86](#)
 - ASC All Season traction Control [72](#)
 - indicator lamps [17, 18](#)
 - Assistant systems, refer to All Season traction Control (ASC) [72](#)
 - Dynamic Stability Control (DSC) [72](#)
 - AUTO program, refer to Automatic air distribution [83](#)
 - Automatic
 - air distribution [83](#)
 - air volume [83](#)
 - cruise control [65](#)
 - Automatic car washes [122](#)
 - Automatic climate control [82](#)
 - Automatic transmission with Steptronic
 - ignition [53](#)
 - indicator lamp [57](#)
 - interlock [53](#)
 - selector lever lock [56](#)
 - shiftlock [56](#)
 - towing [144](#)
 - tow-starting [145](#)
 - Aux-In socket [85](#)
 - Average consumption [71](#)
 - setting units [71](#)
 - Average speed [71](#)
 - setting units [71](#)
 - Axle loads, refer to Weights [151, 152](#)
- B**
- Backrests, refer to Adjusting seats [44](#)
 - Backup lamp
 - bulb replacement [131](#)
 - Bar, towing [144](#)
 - Base plate for telephone or mobile phone [86](#)
 - Battery [140](#)
 - charging [140](#)
 - disposal [140](#)
 - indicator lamp [16](#)
 - jump-starting [142](#)
 - power failure [140](#)
 - Battery care [69, 121](#)
 - Being towed [144](#)
 - Belts, refer to Safety belts [46](#)
 - Beverage holders [86](#)
 - Black ice, refer to Temperature warning [70](#)
 - Blower
 - air conditioning system [80](#)
 - automatic climate control [83](#)
 - Blower, refer to Air volume [80](#)
 - Blowers, refer to Draft-free ventilation [81, 84](#)
 - Bonnet [114](#)
 - indicator lamp [17](#)
 - Bottle holders, refer to Beverage holders [86](#)
 - Brake discs
 - brake system [99](#)
 - break-in procedures [98](#)
 - Brake fluid [120](#)
 - level [120](#)
 - warning lamp [16](#)
 - Brake lamps, bulb replacement [131](#)

EVERYTHING FROM A TO Z

- Brake pads [99](#)
 - break-in procedures [98](#)
 - warning lamp [18](#)
- Brake system [120](#)
 - brake fluid [120](#)
 - brake pads [99](#)
 - break-in procedures [98](#)
 - disc brakes [99](#)
 - warning lamp [17](#)
- Brake wear warning
 - brake pads [99](#)
 - warning lamp [18](#)
- Brakes [120](#)
 - ABS [72](#)
 - brake fluid [120](#)
 - brake pads [99](#)
 - break-in procedures [98](#)
 - CBC [72](#)
 - indicator/warning lamps [16, 17, 18](#)
 - parking brake [54](#)
- Breaking in [98](#)
- Bulb replacement, refer to Lamps and bulbs [129](#)
- Buttons on multifunction steering wheel [20](#)
- automatic transmission with Steptronic [58](#)
- C**
 - California Proposition 65 warning [7](#)
 - Capacities [153](#)
 - Car care, refer to Caring for your vehicle [122](#)
 - Car keys, refer to Keys [24](#)
 - Car radio, refer to separate Owner's Manual
 - Car telephone, refer to separate Owner's Manual
 - Car vacuum cleaner, connecting, refer to Cigarette lighter socket [87](#)
 - Car wash [122](#)
 - Car wash, refer to Washing your vehicle [122](#)
 - Car-care products [122](#)
 - Care of plastics [123](#)
 - Care of synthetic leather [123](#)
 - Care, vehicle [122](#)
 - Cargo area
 - opening from the outside [29](#)
 - opening with the remote control [26](#)
 - volume [151, 152](#)
 - Cargo area cover, refer to Luggage compartment cover [90](#)
 - Cargo area, refer to Luggage compartment in the MINI [90](#)
 - Carpet care [124](#)
 - Cassette operation, refer to Owner's Manual for Radio
 - Catalytic converter, refer to Hot exhaust system [100](#)
 - CBC Cornering Brake Control [72](#)
 - CD changer, refer to Owner's Manual for Radio
 - CD operation, refer to Owner's Manual for Radio
 - Center armrest [86](#)
 - Central locking system [24](#)
 - interior [28](#)
 - Changing bulbs [129](#)
 - Changing the wiper blades [128, 129](#)
 - Changing tires [135](#)
 - space-saver spare tire [133](#)
 - Charge-current indicator light [16](#)
 - Child seat, refer to Installing child-restraint systems [50](#)
 - Children, transporting [50](#)
 - Child-restraint fixing system, LATCH [52](#)
 - Child-restraint systems [50](#)
 - Chock, folding
 - space-saver spare tire [133](#)
 - Chrome parts, refer to Caring for your vehicle [123](#)
 - Chrome-plated parts, care [123](#)
 - Cigarette lighter [87](#)
 - Cigarette lighter socket [87](#)
 - Cigarette tray, refer to Ashtray [86](#)
 - Circulation of air, refer to Recirculated air mode [80, 83](#)
 - Cleaning the rear window [64](#)
 - Cleaning the vehicle, refer to Caring for your vehicle [122](#)
 - Clock [67](#)
 - 12-hour/24-hour mode [67](#)
 - changing the time [67](#)
 - Closing
 - from inside [28](#)
 - from outside [25](#)
 - Clothes hooks [100](#)
 - Clutch [53](#)
 - break-in procedures [98](#)
 - Cockpit [12](#)
 - Coding, tires [108](#)
 - Cold start, refer to Starting the engine [53](#)
 - Compact disk operation, refer to Owner's Manual for Radio
 - Compartments, refer to Storage compartments [85](#)
 - Computer, refer to Onboard computer [70](#)
 - Condensed water, refer to Air conditioning [80, 83](#)

EVERYTHING FROM A TO Z

- Configuring settings, refer to Vehicle Memory [49](#)
- Consumption, refer to
 - Average consumption [71](#)
 - Current fuel consumption [71](#)
- Contents [2](#)
- Control elements, refer to
 - Cockpit [12](#)
- Convenience operation
 - convertible top [37](#)
 - from outside [26](#), [27](#)
 - glass sunroof, electric [33](#)
 - windows [31](#)
- Convertible top [35](#)
 - care [124](#)
 - convenience operation [37](#)
 - electrical malfunction [38](#)
 - emergency closing [38](#)
 - malfunction [38](#)
- Coolant [118](#)
 - indicator lamp [16](#)
 - level [119](#)
 - temperature gauge [68](#)
- Coolant temperature [68](#)
- Cooling
 - air conditioning mode [83](#)
 - cooling function [80](#)
- Cooling function
 - air conditioning system [80](#)
 - automatic climate control [83](#)
- Cooling system, refer to
 - Capacities [153](#)
- Copyright [2](#)
- Cornering Brake Control (CBC) [72](#)
 - warning lamp [17](#)
- Correct tires [108](#)
- Cosmetic mirror, refer to
 - Illuminated vanity mirror [48](#)
- Cruise control [65](#)
 - buttons on the steering wheel [20](#)
 - indicator lamp [19](#)
- Cup holders, refer to Beverage holders [86](#)
- Curb weight, refer to Weights [151](#), [152](#)
- Current fuel consumption [71](#)
 - setting units [71](#)
- Cylinders, refer to Engine data [148](#)
- D**
- Daily odometer, refer to Trip odometer [67](#)
- Dashboard lighting, refer to Instrument lighting [62](#)
- Dashboard, refer to Cockpit [12](#)
- Data
 - capacities [153](#)
 - dimensions [149](#)
 - engine [148](#)
 - technical [148](#)
 - weights [151](#)
- Date of the Owner's Manual [7](#)
- Daytime running lamps [61](#)
- Defrost setting, refer to
 - Defrosting and demisting windows [81](#), [84](#)
- Defrosting and demisting windows
 - air conditioning system [81](#)
 - automatic climate control [84](#)
- Defrosting front windows, refer to Defrosting and demisting windows [81](#), [84](#)
- Defrosting windows [81](#), [84](#)
 - air conditioning system [80](#)
 - automatic climate control [83](#)
- Defrosting windshield, refer to
 - Defrosting and demisting windows [81](#), [84](#)
- Demisting windows [81](#), [84](#)
- Digital clock [67](#)
- Dimensions [149](#), [150](#)
- Dimming interior rearview mirror [98](#)
- Dipstick, engine oil [117](#)
- Directional turn signal, refer to Turn signal indicators [61](#)
- Disc brakes [99](#)
- Disengaging the locks, refer to Unlocking [26](#)
- Displacement, refer to Engine data [148](#)
- Display elements [13](#)
 - with navigation system or Cockpit Chrono Pack [14](#)
- Display lighting, refer to Instrument lighting [62](#)
- Disposal
 - coolant [118](#)
 - vehicle battery [140](#)
- Distance covered, refer to Odometer [67](#)
- Distance warning, refer to Park Distance Control (PDC) [78](#)
- Door keys [24](#)
- Door lock [27](#)
- Doors, locking and unlocking
 - acknowledgment signals [26](#), [27](#)
 - from inside [28](#)
 - from outside [26](#)
- DOT quality grades [108](#)
- Draft-free ventilation [81](#), [84](#)
- Drink holders, refer to Beverage holders [86](#)

EVERYTHING FROM A TO Z

Driving downhill [99](#)
Driving hints, refer to Driving notes [98](#)
Driving lamps, refer to Parking lamps/Low beams [60](#)
Driving notes [98](#)
Driving stability control systems [72](#)
Driving through water [100](#)
Dry air, refer to Cooling function [80, 83](#)
Drying air, refer to Cooling function [80, 83](#)
DSC Dynamic Stability Control [72](#)
indicator lamp [17](#)
Dynamic Stability Control (DSC) [72](#)
indicator lamp [17](#)

E
Easy entry to the rear [45](#)
EBD Electronic Brake Force Distribution [72](#)
Electric glass sunroof [33](#)
Electric power windows [31](#)
initializing [32](#)

Electrical malfunction
automatic transmission with Steptronic [58](#)
convertible top [38](#)
door lock [27](#)
driver's door [27](#)
fuel filler door [102, 103](#)
glass sunroof, electric [34](#)
tailgate [30](#)

Electronic Brake Force Distribution (EBD) [72](#)

Electronic Stability Program (ESP), refer to Dynamic Stability Control (DSC) [72](#)

Emergency operation, refer to Manual operation
convertible top [38](#)
driver's door [27](#)
fuel filler door [102, 103](#)
glass sunroof, electric [34](#)
tailgate [30](#)
transmission lock, automatic transmission with Steptronic [56](#)

Engine
break-in procedures [98](#)
data [148](#)
electronics [18](#)
indicator lamp [18](#)
overheated, refer to Coolant temperature gauge [68](#)
speed [69](#)
starting [53](#)
switching off [54](#)

Engine compartment
MINI COOPER and MINI COOPER Convertible [115](#)
MINI COOPER S and MINI COOPER S Convertible [116](#)

Engine coolant [118](#)

Engine data [148](#)

Engine oil [117](#)
adding [117](#)
dipstick [117](#)
indicator/warning lamp [16](#)
recommended oils [118](#)
specified oil grades [118](#)

Engine oil level [117](#)
indicator/warning lamp [16](#)

Engine oil level, checking [117](#)

Engine oil pressure, indicator/warning lamp [16](#)

Engine output, refer to Engine data [148](#)

Entry to the rear [45](#)

ESP Electronic Stability Program, refer to Dynamic Stability Control (DSC) [72](#)

Exhaust system, refer to Hot exhaust system [100](#)

Exterior mirrors [48](#)
adjusting [48](#)
automatic heating [48](#)
folding in and out [48](#)

External audio device [85](#)

Eyelet, for towing and tow-starting [143](#)

F

Failure of an electrical consumer [140](#)

Fastening safety belts, refer to Safety belts [46](#)

Filling canister, refer to MINI Mobility System [138](#)

Filling hose, refer to MINI Mobility System [138](#)

Filter, refer to
Microfilter [81](#)
Microfilter/Activated-charcoal filter [84](#)

EVERYTHING FROM A TO Z

Flat tire

- Flat Tire Monitor [74](#), [75](#)
 - MINI Mobility System [137](#)
 - Run-Flat Tires [75](#)
 - space-saver spare tire [133](#)
- Flat Tire Monitor [74](#)
- indicator lamp [17](#)
 - issuing a flat tire warning [75](#)
 - malfunction [75](#)
- Flat tire, refer to Changing tires [135](#)
- Flat tire, refer to Tire condition [109](#)
- Floor coverings, carpets [124](#)
- Floor mats [124](#)
- Fog lamps [62](#)
- indicator lamp [62](#)
- Foldable rear backrest [90](#), [91](#)
- Folding roof, refer to Convertible top with integrated sliding sunroof [35](#)
- Foot braking, refer to General driving notes [99](#)
- Fresh air nozzles, refer to Draft-free ventilation [81](#)
- Front airbags [76](#)
- Front turn signal indicators, bulb replacement [130](#)

Fuel [101](#)

- average consumption [71](#)
 - gauge [67](#), [68](#)
 - quality [101](#)
 - tank capacity [153](#)
- Fuel filler door [101](#)
- unlocking in the event of electrical malfunction [102](#), [103](#)
- Fuses [141](#)
- ## G
- Garage door opener, refer to Integrated universal remote control [88](#)
- Gas cap [101](#)
- Gas, refer to Average consumption [71](#)
- Gas, refer to Fuel quality [101](#)
- Gasoline gauge, refer to Fuel gauge [67](#), [68](#)
- Gasoline, refer to Fuel quality [101](#)
- Gear indicator, for automatic transmission with Steptronic [57](#)
- Gear shifts, automatic transmission with Steptronic [56](#)

Gearshift lever

- automatic transmission with Steptronic [56](#)
 - manual transmission [55](#)
- General driving notes [98](#)
- Glass sunroof, electric [33](#)
- convenience operation [27](#)
 - opening and closing in the event of an electrical malfunction [34](#)
 - remote control [26](#)
- Glove compartment [85](#)
- Gross weight, refer to Weights [151](#), [152](#)

H

- Handbrake, refer to Parking brake [54](#)
- Hazard warning flashers [12](#)
- Head airbags [76](#)
- Head restraints [44](#)
- Headlamp flasher [61](#)
- indicator lamp [19](#)
- Headlamp washer reservoir [64](#)
- capacity, refer to Capacities [153](#)
- Headlamp washer system cleaning headlamps [64](#)
- washer fluid [64](#)
- Headlamps
- bulb replacement [130](#)
 - care [123](#)
- Heated rear window
- air conditioning system [80](#)
 - automatic climate control [83](#)
- Heating [79](#)
- exterior mirrors [48](#)
 - mirrors [48](#)
 - rear window [80](#), [83](#)
 - seats [47](#)
 - windshield [80](#), [83](#)
- Heavy load, refer to Loading [94](#)
- Height adjustment seats [43](#)
- steering wheel [47](#)
- Height, refer to Dimensions [149](#), [150](#)
- High beams [61](#)
- bulb replacement [130](#)
 - headlamp flasher [61](#)
 - indicator lamp [19](#)
- High Performance Synthetic Oil, refer to Engine oil [118](#)
- recommended oils [118](#)
 - specified oils [118](#)
- Holders for beverages [86](#)
- Horn [12](#)
- Hot exhaust system [100](#)
- Hydraulic brake [120](#)
- Hydroplaning [99](#)

EVERYTHING FROM A TO Z

- I**
- Ice warning, refer to Outside temperature warning [70](#)
 - Ignition [53](#)
 - Ignition key [24](#)
 - Ignition key positions, refer to Ignition lock [53](#)
 - Ignition lock [53](#)
 - Illuminated vanity mirror [48](#)
 - Imitation leather [123](#)
 - Imprint [2](#)
 - Index [156](#)
 - Indicator and warning lamps, overview [16](#)
 - Indicator/warning lamp
 - airbags [77](#)
 - ASC [73](#)
 - brakes [120](#)
 - coolant temperature [68](#)
 - DSC [73](#)
 - fasten safety belts [46](#)
 - Flat Tire Monitor [75](#)
 - fog lamps [62](#)
 - reserve fuel capacity [67](#), [68](#)
 - Individual air distribution [84](#)
 - Individual settings, refer to Vehicle Memory [49](#)
 - Inflation pressure monitor, refer to Flat Tire Monitor [74](#)
 - Inflation pressure, refer to Tire inflation pressure [104](#)
 - Inspection [69](#)
 - Instrument cluster, refer to Display elements [13](#)
 - Instrument lighting [62](#)
 - Instrument panel, refer to Cockpit [12](#)
 - Integrated universal remote control [88](#)
 - Interior lamp, remote control [26](#)
 - Interior lamps [62](#)
 - Interior rearview mirror [48](#)
 - automatic dimming [98](#)
 - Interlock, refer to Steering locked [53](#)
 - Intermittent operation of the wipers [63](#)
 - Interval display, service [121](#)
- J**
- Jack [133](#), [137](#)
 - points [136](#)
 - Jack, refer to Tire change set
 - MINI Mobility System [137](#)
 - Run-Flat Tires [111](#)
 - space-saver spare tire [133](#)
 - Jacking points [136](#)
 - Jets, refer to Ventilation [81](#), [84](#)
 - Jets, refer to Windshield washer jets [64](#)
 - John Cooper Works Kit [148](#)
 - Jump-starting [142](#)
- K**
- Keys [24](#)
 - Kickdown [57](#)
 - Knock control [101](#)
- L**
- Lamp defect [129](#)
 - Lamp replacement, refer to Lamps and bulbs [129](#)
 - Lamps and bulbs [129](#)
 - Lamps, refer to Parking lamps/Low beams [60](#)
 - Lashing eyelets, refer to Securing the load [94](#)
 - LATCH child-restraint fixing system [52](#)
 - Leather care [124](#)
 - LEDs light-emitting diodes [132](#)
 - Length, refer to Dimensions [149](#), [150](#)
 - License plate lamp, bulb replacement [132](#)
 - Lifting handle, space-saver spare tire [133](#)
 - Light switch [60](#)
 - Light-alloy wheels, care [123](#)
 - Light-emitting diodes (LEDs) [132](#)
 - Lighter [87](#)
 - Lighting
 - lamps and bulbs [129](#)
 - Lighting of the instruments [62](#)
 - Lights on warning [61](#)
 - Load securing devices, refer to Securing the load [94](#)
 - Loading
 - securing cargo [94](#)
 - stowing cargo [94](#)
 - Loading the vehicle [92](#)
 - Loads, refer to Loading cargo [92](#)
 - Locking
 - from inside [28](#)
 - from outside [26](#)
 - Locking/unlocking the vehicle, acknowledgment signals [26](#), [27](#)
 - Low beams [60](#)
 - bulb replacement [130](#)
 - Lower back support, refer to Lumbar support [44](#)

EVERYTHING FROM A TO Z

Luggage compartment cover [90](#)
emergency operation, refer to Manual release [30](#)
expanding [90](#)
lid, refer to Tailgate [29](#)
opening from the outside [29](#)
opening with the remote control [26](#)
opening/closing, refer to Tailgate [29](#)
volume [151](#), [152](#)

Luggage compartment in the MINI [90](#)

Luggage compartment lid emergency operation, refer to Manual release [30](#)
opening with the remote control [26](#)

Luggage compartment lid, refer to Tailgate [29](#)

Luggage compartment net [94](#)

Luggage rack, refer to Roof-mounted luggage rack [95](#)

Lumbar support [44](#)

M

M+S tires, refer to Winter tires [113](#)

Maintenance system [121](#)

Maintenance, refer to Service and Warranty Information Booklet for US models, Warranty and Service Guide Booklet for Canadian models [121](#)

Malfunction

automatic transmission with Steptronic [58](#)
convertible top [38](#)
door lock [27](#)
fuel filler door [102](#), [103](#)
glass sunroof, electric [34](#)
tailgate [30](#)
tire [112](#)

Manual air distribution [80](#)

Manual operation

door lock [27](#)
driver's door [27](#)
fuel filler door [102](#), [103](#)
glass sunroof, electric [34](#)
power convertible top [38](#)
tailgate [30](#)
transmission lock, automatic transmission with Steptronic [56](#)

Manual transmission [55](#)

Master keys with remote control [24](#)

Maximum cooling [83](#)

Maximum speed, with winter tires [113](#)

MC operation, refer to Owner's Manual for Radio

Mechanical keys, refer to Master keys [24](#)

Memory, refer to Vehicle Memory [49](#)

Microfilter
air conditioning system [81](#)
automatic climate control [84](#)

MINI homepage [6](#)

MINI Maintenance System [121](#)

MINI manufacturer [6](#)

MINI Mobility System [137](#)
compressor [138](#)
liquid sealant [138](#)

Mirrors [48](#)

exterior [48](#)
heating [48](#)
interior rearview [48](#)

Mobile telephone, refer to separate Owner's Manual

Mobility System [137](#)

Modifications, technical, refer to For your own safety [7](#)

Multifunction steering wheel [20](#)

Multifunction switch
turn signal indicator/
headlamp flasher [61](#)
washer/wiper system [63](#)

N

Navigation system, refer to separate Owner's Manual

Neck restraints, refer to Head restraints [44](#)

New tires [112](#)

Non-smoker's equipment package, refer to Cigarette lighter socket [87](#)

Nylon rope, refer to Towing and tow-starting [144](#)

O

OBD interface socket [122](#)

Octane number, refer to Fuel quality [101](#)

Odometer [67](#)

Oil

additives, refer to Adding engine oil [118](#)
dipstick [117](#)

Oil change intervals, refer to Service and Warranty Information Booklet for US

EVERYTHING FROM A TO Z

models, Warranty and Service Guide Booklet for Canadian models

Oil consumption [117](#)

Oil level [117](#)
indicator lamp [16](#)

Oil pressure, indicator lamp [16](#)

Oil service [69](#)

Onboard computer [70](#)

Onboard tool kit [128](#)

MINI Mobility System [137](#)

Run-Flat Tires [128](#)

space-saver spare tire [133](#)

Opening and closing

from inside [28](#)

from outside [25](#)

via remote control [26](#)

via the door lock [27](#)

Outlets, refer to

Ventilation [79, 82](#)

Outside air [80](#)

air conditioning system [80](#)

Outside air mode, automatic climate control [83](#)

Outside temperature

display [70](#)

changing units [70](#)

in the onboard computer [70](#)

Outside temperature

warning [70](#)

Overriding the selector lever lock [59](#)

P

Paintwork care, refer to Vehicle paintwork [123](#)

Park Distance Control (PDC) [78](#)

Parking

the vehicle [100](#)

Parking aid, refer to Park Distance Control (PDC) [78](#)

Parking brake [54](#)

warning lamp [17](#)

Parking lamps [60](#)

bulb replacement [130](#)

Parking lamps/Low beams [60](#)

Parking lock, refer to

P Parking [56](#)

Parts and accessories, refer to

Your individual vehicle [6](#)

Pathway lighting [60](#)

PDC Park Distance Control [78](#)

Pinch protection system, glass sunroof, electric [34](#)

Plastic [123](#)

Pollen, refer to

Microfilter [81](#)

Microfilter/Activated-charcoal filter [84](#)

Power convertible top [35](#)

Power failure [140](#)

Power output, refer to Engine data [148](#)

Power supply, refer to Cigarette lighter socket [87](#)

Power windows [31](#)

Pressure, tires [104](#)
re-inflation using MINI Mobility System [138](#)

Protective function, electric glass sunroof [34](#)

Pumping in liquid sealant [138](#)

Q

Quality grades, refer to Uniform Tire Quality Grading [108](#)

R

Radiator, refer to Coolant [118](#)

Radio, refer to separate Owner's Manual

Rain sensor [63](#)

Range [70](#)

Reading lamps [63](#)

Rear backrest, foldable [90, 91](#)

Rear fog lamp [62](#)

bulb replacement [132](#)

indicator lamp [62](#)

Rear lamps, bulb

replacement [131](#)

Rear lamps, refer to Tail lamps [131](#)

Rear seats, adjusting head restraints [44](#)

Rear shelf, refer to Luggage compartment cover [90](#)

Rear turn signal indicators, bulb replacement [131](#)

Rear window wiper [64, 65](#)
replacement [129](#)

Rearview mirror [48](#)

Recirculated air mode

air conditioning system [80](#)

automatic climate control [83](#)

Reclining seat, refer to Backrest tilt [44](#)

Refueling [101](#)

fuel filler door [101](#)

Remaining distance for service [69](#)

Remaining distance, refer to Range [70](#)

Remote control [25, 26](#)
garage door opener [88](#)

malfunction [27](#)

Remote control key, refer to Master keys with remote control [24](#)

Replacement key [24](#)

EVERYTHING FROM A TO Z

- Replacement of tires
 - changing tires [133](#)
 - new wheels and tires [112](#)
- Reporting safety defects [9](#)
- Reserve indicator light, refer to
 - Fuel gauge [67](#), [68](#)
- Reservoir for washer fluid [64](#)
- Reservoir, washing systems [64](#)
- Restraint systems
 - for children [50](#)
 - refer to Safety belts [46](#)
- Retaining straps [94](#)
- Reverse
 - automatic transmission with Steptronic [56](#)
 - manual transmission [55](#)
- Rod antenna [123](#)
- Roller sun blind [34](#)
- Roof load, refer to
 - Weights [151](#), [152](#)
- Roof-mounted luggage rack [95](#)
- Rope, refer to Towing and Tow-starting [144](#)
- RSC Runflat System
 - Component, refer to Run-Flat Tires [111](#)
- Runflat System Component
 - RSC, refer to Run-Flat Tires [111](#)
- Run-Flat Tires [111](#)
 - puncture [110](#)
 - replacing [112](#)
 - tire inflation pressure [105](#)
 - winter tires [112](#)
- S**
- Safety belt height adjustment [46](#)
- Safety belts [46](#)
 - care [124](#)
 - height adjustment [46](#)
 - indicator lamp [17](#), [46](#)
 - reminder [46](#)
 - safe seating position [42](#)
- Safety lock buttons, doors, refer to Locking [28](#)
- Safety systems, refer to
 - Airbags [76](#)
 - All Season traction Control (ASC) [72](#)
 - Antilock Brake System (ABS) [72](#)
 - Brake system [72](#)
 - Dynamic Stability Control (DSC) [72](#)
- Safety tires, refer to Run-Flat Tires [111](#)
- Seat adjustment [43](#)
- Seat heating [47](#)
- Seat-belt tensioner, refer to Safety belts [47](#)
- Seats
 - heating [47](#)
 - safe seating position [42](#)
- Securing loads, refer to Loading cargo [92](#)
- Securing the load [94](#)
- Securing the vehicle
 - from inside [28](#)
 - from outside [26](#)
- Selector lever positions, automatic transmission with Steptronic [56](#)
- Selector lever shiftlock, refer to Shiftlock [56](#)
- Selector lever, automatic transmission with Steptronic [56](#)
- Service and Warranty Information Booklet for US models, Warranty and Service Guide Booklet for Canadian models [121](#)
- Service interval display [69](#), [121](#)
- Shift paddles [58](#)
- Shifting gears in the automatic transmission with Steptronic [58](#)
- Shiftlock, refer to Range selection [56](#)
- Side airbags [76](#)
- Side turn signal indicators, bulb replacement [131](#)
- Signal horn, refer to Horn [12](#)
- Sitting safely [42](#)
 - with airbags [42](#)
 - with head restraints [42](#)
 - with safety belt [42](#)
- Slipstream deflector, refer to Wind deflector [40](#)
- Smoker's equipment package, refer to Ashtray [86](#)
- Snow chains [113](#)
- Socket 12 V [87](#)
- Socket for
 - onboard diagnostics [122](#)
- Socket in the luggage compartment [87](#)
- Space-saver spare tire
 - changing tires [133](#)
 - inflation pressure [105](#)
- Spare key [24](#)
- Spare tire, refer to Space-saver spare tire [133](#)
- Special oils, refer to Specified engine oils [118](#)
- Special wash program [122](#)
- Specified oils [118](#)

EVERYTHING FROM A TO Z

- Speed [148](#)
 - with Run-Flat Tires [75](#)
 - with the space-saver spare tire [135](#)
 - with winter tires [113](#)
- Speedometer [13, 14](#)
- Speedometer, refer to Display elements [13, 14](#)
- Split rear backrest, refer to
 - Foldable rear backrest [90](#)
 - Through-loading system [91](#)
- Sport program, automatic transmission with Steptronic [57](#)
- Stability control, refer to
 - Driving stability control systems [72](#)
- Standing lamps [60](#)
 - bulb replacement [130](#)
- Starting aid, refer to Jump-starting [142](#)
- Starting problems
 - at very low temperatures [54](#)
 - jump-starting [142](#)
- Starting the engine [53](#)
- Starting, refer to Starting the engine [53](#)
- Start-off assistance, refer to ASC [72](#)
- Start-off assistance, refer to DSC [72](#)
- Steering lock [53](#)
- Steering wheel [12](#)
 - buttons on the steering wheel [20](#)
 - settings [47](#)
- Steering wheel lock [53](#)
- Steptronic, refer to Manual mode [57](#)
- Storage compartments [85](#)
- Storage space, refer to
 - Luggage compartment in the MINI [90](#)
 - Luggage compartment in the MINI Convertible [91](#)
- Storing the tires [113](#)
- Storing the vehicle [125](#)
- Sun blind, refer to Roller sun blind [34](#)
- Sun visors [48](#)
- Switches, refer to Cockpit [12](#)
- Switching off the engine [54](#)
- Switching the cooling function on and off manually [80, 83](#)
- Symbols [6](#)
- T**
- Tachometer [69](#)
- Tail lamps, bulb replacement [131](#)
- Tail lamps, refer to Rear lamps [131](#)
- Tailgate [29](#)
 - emergency operation [30](#)
 - indicator lamp [17](#)
 - opening from the outside [29](#)
 - releasing manually [30](#)
 - remote control [26](#)
- Tank capacity, refer to Fuel tank capacity [153](#)
- Tank gauge, refer to Fuel gauge [67, 68](#)
- Technical data [148](#)
- Technical modifications [7](#)
- Technical modifications, refer to For your own safety [7](#)
- Telephone call, refer to the Owner's Manual for the telephone
- Temperature
 - air conditioning system [80](#)
 - automatic climate control [83](#)
- Temperature display
 - ice warning [70](#)
 - outside temperature [70](#)
 - setting units [70](#)
- Temperature grades [109](#)
- Temperature warning [70](#)
- Tempomat, refer to Cruise control [65](#)
- Threaded hole for towing eyelet [144](#)
- Three-point safety belt [46](#)
- Through-loading system [90, 91](#)
- Tightening the lug bolts
 - keys [133, 137](#)
 - torque [136](#)
- Tightening torque, refer to
 - Tightening the lug bolts [136](#)
- Tire change set
 - MINI Mobility System [139](#)
 - Run-Flat Tires [111](#)
 - space-saver spare tire [133](#)
- Tire failure [133](#)
 - MINI Mobility System [137](#)
 - space-saver spare tire [133](#)
- Tire inflation pressure [104](#)
 - re-inflation [138](#)
- Tire pressure monitor, refer to Flat Tire Monitor [74](#)
- Tire pressure monitoring, Flat Tire Monitor [74](#)
- Tire puncture
 - Run-Flat Tires [75](#)

EVERYTHING FROM A TO Z

Tires

- age [108](#)
 - break-in procedures [98](#)
 - changing [135](#)
 - condition [109](#)
 - damage [110](#)
 - flat tire [111](#), [133](#)
 - inflation pressure [104](#)
 - replacement [112](#)
 - size, refer to New wheels and tires [112](#)
 - storage [113](#)
 - tread [109](#)
 - wear indicator, refer to Tire tread [109](#)
 - winter tires [113](#)
- Tires with emergency properties, refer to Run-Flat Tires [111](#)
- Tools, refer to Onboard tool kit [128](#)
- Torque
- engine [148](#)
 - lug bolts [136](#)
- Tow bar [144](#)
- Tow rope [144](#)
- Towing [143](#)
- with automatic transmission [144](#), [145](#)
- Towing eyelet [143](#)
- Tow-starting [145](#)

Track width, refer to

- Dimensions [149](#), [150](#)
- Traction grades [109](#)
- Transmission
- automatic transmission with Steptronic [56](#)
 - manual transmission [55](#)
- Transmission lock, refer to
- Range selection [56](#)
- Transmission malfunction, refer to Malfunction [58](#)
- Transporting children safely [50](#)
- Transporting securely, refer to
- Securing the load [94](#)
- Trash container, refer to
- Ashtray [86](#)
- Tread depth, refer to Tire tread [109](#)
- Treadwear grade [108](#)
- Trip odometer [67](#)
- Trunk, refer to Luggage compartment in the MINI Convertible [91](#)
- Turn signal indicators [61](#)
- indicator lamp [19](#)
- Turn signal indicators on the side, bulb replacement [131](#)
- Turning circle, refer to
- Dimensions [149](#), [150](#)

U

- Uniform Tire Quality Grading [108](#)
- Units
- average consumption [71](#)
 - average speed [71](#)
 - temperature [70](#)
- Universal garage door opener [88](#)
- Universal remote control [88](#)
- Unlocking
- bonnet [114](#)
 - from inside [28](#)
 - from outside [26](#)
- Used batteries, refer to
- Disposal [140](#)
- Using antifreeze [64](#), [118](#)

V

- Vacuum cleaner, connecting, refer to Cigarette lighter socket [87](#)
- Valve
- core [137](#)
 - dust cap [135](#)
 - remover [137](#)
 - spare [137](#)
- Valve remover, refer to
- Onboard tool kit [137](#)
- Valve stem and replacement valve, refer to Onboard tool kit [137](#)
- Vanity mirror, illuminated [48](#)
- Vehicle
- battery [140](#)
 - break-in procedures [98](#)
 - care [122](#)
 - dimensions [149](#)
 - loading cargo [92](#)
 - parking [100](#)
 - storage [125](#)
 - washing [122](#)
 - weight [151](#), [152](#)
- Vehicle battery [140](#)
- Vehicle identification number, refer to Engine compartment [115](#), [116](#)
- Vehicle illumination, refer to
- Lamps [60](#)
- Vehicle Memory [49](#)
- Ventilation, draft-free [81](#), [84](#)
- Ventilation, refer to
- Air conditioning system [81](#)
 - Automatic climate control [83](#)
- Ventilation, refer to Draft-free ventilation [81](#), [84](#)
- Volume
- luggage compartment [151](#), [152](#)

EVERYTHING FROM A TO Z

W

Warning and indicator lamps [16](#)
Washer fluid [64](#)
Washer fluid reservoir, capacity [153](#)
Washer fluid reservoir, refer to Washer/wiper system [64](#)
Washer systems [64](#)
Washer/wiper system [63](#)
Washing your vehicle [122](#)
Water on roadways, deep water [100](#)
Wear indicators in the tires, refer to Tire condition [110](#)
Weights [151](#), [152](#)
Wheel stud wrench
MINI Mobility System [137](#)
space-saver spare tire [133](#)
Wheel/tire combination [112](#)
Wheelbase, refer to
Dimensions [149](#), [150](#)
Wheels and tires [112](#)
Wheelslip control
All Season traction Control (ASC) [72](#)
Dynamic Stability Control (DSC) [72](#)
Width, refer to Dimensions [149](#)
Wind deflector [40](#)

Window washer reservoir [64](#)
capacity, refer to
Capacities [153](#)
Window washer system
washer fluid [64](#)
washer/wiper system [63](#)
Windows, convenience
operation [26](#), [27](#)
Windscreen wipers
replacement [128](#), [129](#)
Windshield heating
air conditioning system [80](#)
automatic climate control [83](#)
Windshield washer jets [64](#)
Windshield wiper blades
care [124](#)
replacement [128](#), [129](#)
Windshield wipers
intermittent operation [63](#)
Windshield wipers, refer to
Washer/wiper system [63](#)
Windshield, cleaning [64](#)
Winter tires [113](#)
changing [135](#)
condition [109](#)
Run-Flat Tires [112](#)
storage [113](#)
Wood paneling [124](#)
Work in the engine
compartment [114](#)

Wrench/screwdriver, refer to
Onboard tool kit [128](#)

X

Xenon lamps
bulb replacement [130](#)

Y

Your individual vehicle [6](#)

REFUELING

Fuel	
Quality	

Please enter your preferred fuel quality here.

Engine oil	
Preferred oil grade	

The oil volume between the two marks on the dipstick corresponds to approx. 1.1 US quarts/1 liter.



Tire inflation pressure	Summer		Winter	
	front	rear	front	rear
2 persons				
4 persons plus luggage				

To ensure that you always have convenient access to all essential information when you stop for fuel, we recommend that you take the time to fill out the adjoining chart by entering the data that applies to your vehicle.

MINI RECOMMENDS 



01 41 0 012 950 ue

DRIVE ME.