

**WARNING**

*Your common sense, good judgement and general alertness are crucial to safe and successful service work. Before attempting any work on your Volkswagen, be sure to read 00 Warnings and Cautions and the copyright page at the front of the manual. Review these warnings and cautions each time you prepare to work on your car. Please also read any warnings and cautions that accompany the procedures in the manual.*

**A****ABS**

see Antilock brakes (ABS)

**Accelerator pedal assembly**

20-38

**Air conditioning (A/C)**

blower motor 87-5  
 Climatic 87-3  
 Climatronic 87-8  
 components 87-3, 87-8  
 compressor 87-21  
 condenser 87-20  
 controls 87-4, 87-9  
 dashboard air outlets 70-9  
 dust and pollen filter 03-65, 87-3, 87-8, 87-10  
 evaporator 87-10  
 evaporator drain hose 87-11  
 expansion valve 87-1, 87-19  
 flap motors 87-3, 87-8  
 functions 87-2  
 housing 87-10  
 overview 02-30  
 pressure sensor 87-19  
 refrigerant oil 87-17  
 refrigerant system 87-16  
 sunlight photo sensor 87-9  
 vents 87-6, 87-7

**Air filter**

03-49

**Air outlets**

center dashboard 70-9

**Airbags**

69-1, 69-10  
 spiral spring 96-10  
 visual inspection 03-63

**Alarm system**

96-16

**Alignment**

44-3

**Alternator (generator)**

2.0L gasoline 27-12  
 2.5L 27-15  
 belt 03-38  
 diesel 27-9

**Amplifier**

91-5, 91-9  
 pin assignments 91-10

**Antenna**

91-5

**Antifreeze**

03-24

**Antilock brakes (ABS)**

electrical component 45-4  
 hydraulic components 45-5  
 variants 45-1  
 warning lights 45-3  
 wheel speed sensor 45-7  
 see also Electronic stabilization program (ESP)

**Antislip regulation (ASR)**

45-2

**Anti-theft**

96-15  
 radio 91-6

**A-pillar trim**

70-21

**Arm rest**

rear 72-8

**ASR (antislip regulation)**

45-2  
 see also Antilock brakes (ABS)

**ATF**

see Automatic transmission

**Automatic transmission**

applications 02-23  
 ATF servicing 37-5  
 ATF cooler 37-11  
 ATF pump drive 32-1  
 identification 03-8  
 electrical components 37-3  
 shift mechanism 37-8  
 specifications 37-2

**Auxiliary heater**

87-3, 87-8, 87-10, 87-11

**Axle**

40-9  
 boot, checking 03-61

**B****Back-up lights**

switch 96-5  
 switch function  
 automatic transmission 37-1  
 DSG 34b-3

**Badge, rear**

66-6

**Balance shaft**

02-10, 02-11, 15c-32, 17-12

**Battery**

27-3  
 charging 27-6  
 procedure following interruption of voltage supply 27-6  
 remote control batteries 57-11  
 removing and installing 27-7  
 tests 27-4  
 service 03-35

**Belts**

ribbed belt 03-38  
 tensioner 27-9, 27-12, 27-15  
 timing belt  
 checking 03-43  
 replacing  
 1.9L TDI 15a-6  
 2.0L TDI 15b-8  
 2.0L FSI gasoline 15c-6

**Bleeding brakes**

47-2

**Blower motor**

87-5

**Body**

engine hood lock carrier 50-1  
 fender 50-3  
 grille 66-5  
 overview 02-26  
 sound absorber panels 03-14  
 underbody trim 50-4  
 wheel housing liner 66-1  
 see also Trim

**B-pillar trim**

70-23

**Brake fluid**

bleeding 47-2  
 level 03-26  
 replacing 03-27

**Brake light**

94-12, 94-14  
 switch 23-8, 46-11

## 2 INDEX

### Brakes

- antilock 45-1
- bleeding 47-2
- booster 47-8
- disc 46-1, 46-3, 46-6
- fluid specification 47-3
- master cylinder 47-8
- overview 02-25
- pads 46-3, 46-6
  - checking 03-54
  - front 46-3
  - rear 46-6
- parking brake 46-9
- pedal 46-10
- rotor 46-1, 46-3, 46-6
- tandem pump 20-14, 47-7
- troubleshooting 47-1
- vacuum check-valve 47-7
- vacuum pump 47-6
- see also* Antilock brakes (ABS)
- see also* Caliper

### Bulkhead, plenum

- 50-4

### Bumpers

- front 63-1
- rear
  - sedan 63-4
  - wagon 63-6

### Bus systems

- components 97-3
- overview 9-3

## C

### Caliper

- bleeding 47-3
- front 46-3
- rear 46-6

### Camshaft

- 2.0L gasoline 02-14, 15c-24
- 2.5L 02-22
- adjustment
  - 2.0L gasoline
    - code BPY 15b-21
    - code CBFA, CCTA 15c-29
  - 2.5L 15d-9
- sensor
  - 1.9L TDI 23-4, 23-7
  - 2.0L gasoline
    - FSI 24-4, 24-5, 28-6
    - TSI 24-11, 24-13, 28-6
  - 2.5L 24-16, 28-7
- see also* Timing belt

### CAN-bus

- components 97-26
- overview 9-3

### Catalytic converter

- 02-9, 26-5, 26-10, 26-14, 26-17

### Cautions

- 00-2
- see also* beginning of each repair group

### CD changer

- 91-5

### Center console

- 70-4

### Central locking

- 57-10

### Climatic

- 87-3
- see also* Air conditioning (A/C)

### Climatronic

- 87-8
- see also* Air conditioning (A/C)

### Clutch

- assembly
  - DSG 30-10
  - manual 30-8
- hydraulics
  - bleeding 30-6
  - 5-speed 30-4
  - 6-speed 30-5
- pedal 30-2
- pedal position sensor 23-8, 30-3
- release bearing
  - 5-speed 30-4
  - 6-speed 30-5

### Coil, ignition

- 2.0L gasoline 28-6
- 2.5L 28-7

### Coil spring

- front 40-8
- rear 42-5

### Comfort system

- 9-4

### Common rail

- basics 23-13

### Component locations (electrical)

- 97-3

### Compression test

- 1.9L TDI 15a-2
- 2.0L TDI 15b-2
- 2.0L gasoline 15c-2
- 2.5L 15d-2

### Compressor

- 87-21
- see also* Air conditioning (A/C)

### Condenser

- 87-20

### Console, center

- 70-4

### Constant velocity (CV) joint

- see* CV joint

### Control arm

- 40-3

### Coolant

- see* Engine cooling system

### Coolant pump

- 1.9L TDI 19-8
- 2.0L TDI 19-10
- 2.0L gasoline
  - code BPY 19-12
  - code CBFA, CCTA 19-13
- 2.5L 19-17

### Courtesy light

- 94-11

### C-pillar trim

- sedan 70-24
- wagon 70-27

### Crankshaft

- seal 02-23

### Cruise control

- 27-2

### Cupholder

- rear arm rest 72-8

### CV joint

- 40-15, 40-16
- boot 03-61

### Cylinder head (1.9L TDI engine)

- 15a-3
- assembly 15a-4
- diagnosis 15a-2
- cover 15a-5
- valvetrain 15a-16

### Cylinder head (2.0L TDI engine)

- 15b-18
- assembly 15b-19
- cover 15b-3
- diagnosis 15b-2
- valvetrain 15b-20

### Cylinder head (2.0L gasoline engine)

- assembly
  - code BPY 15c-4
  - code CBFA, CCTA 15c-27
- cover cove BPY 15c-5
- diagnosis 15c-2
- valvetrain
  - code BPY 15c-20
  - code CBFA, CCTA 15c-29

### Cylinder head (2.5L engine)

- assembly 15d-4
- cover 15d-5
- diagnosis 15d-2
- valvetrain 15d-10

**WARNING**

*Your common sense, good judgement and general alertness are crucial to safe and successful service work. Before attempting any work on your Volkswagen, be sure to read 00 Warnings and Cautions and the copyright page at the front of the manual. Review these warnings and cautions each time you prepare to work on your car. Please also read any warnings and cautions that accompany the procedures in the manual.*

**D**

**Dashboard**

- air outlets 70-9
- center cover 70-15
- center trim 70-10
- footwell cover, left 70-16
- instrument cluster lower trim 70-17
- left side trim 70-11
- right side trim 70-14
- side covers 70-10
- switches 96-5

**Diagnostic link connector (DLC)**

- 24-2, OBD-1

**Diagnostic trouble code (DTC)**

- general OBD-1
- P-codes OBD-4
- U-codes OBD-35

**Diesel**

- fuel gelling 20-4
- ignition 28-2

**Dimensions**

- 02-3

**Direct Shift Gearbox (DSG)**

- 02-24
- clutch 30-10
- electrical components 34b-3
- oil cooler 34b-12
- oil, servicing 34b-4
- shift mechanism 34b-8
- specifications 34b-2

**Disc brakes**

- see Brakes

**DLC**

- see Data link connector (DLC)

**Door**

- front 57-2
- rear 57-7

**Door hinge, lubricating**

- 03-64

**Door lock**

- front 57-3
- rear 57-8

**Door panel**

- inner trim 70-19
- outer 57-5

**Door window**

- assembly
  - front 64-1
  - rear 64-2
- glass
  - front 64-2
  - rear 64-3
- rear quarter glass 64-5
- regulator 64-5

**D-pillar trim**

- 70-27

**Drive axle**

- 40-9
- boot, checking 03-61

**Drive belt**

- 03-38

**Drive plate**

- 32-1

**DSG (Direct Shift Gearbox)**

- see Direct Shift Gearbox (DSG)

**DTC table**

- see Diagnostic trouble code (DTC)

**Dual-mass flywheel**

- 30-7

**Dust and pollen filter**

- 03-65, 87-3, 87-8, 87-10

**E**

**E-box (electronics box)**

- cover 97-32
- fuses 97-34
- relays 97-42

**ECM (engine control module)**

- 23-23, 24-23

**EDL (electronic differential lock)**

- 45-1

**EGR (exhaust gas recirculation)**

- 26-9

**Electrical component designation**

- 15c-1

**Electrical component locations**

- 97-3

**Electrical system**

- fuses 97-32
- grounds 97-46
- load management 9-6
- overview 02-31, 9-1
- relays 97-42
- troubleshooting 9-7
- wiring
  - diagrams EWD-7
  - index EWD-1

**Electrolyte**

- 27-4

**Electro-mechanical steering**

- see Steering

**Electronic differential lock (EDL)**

- 45-1

**Electronic immobilizer**

- 90-3, 96-15

**Electronic power control (EPC)**

- 20-38

**Electronic stabilization program (ESP)**

- 45-2
- motion sensor -45-4, 45-8
- see also Antilock brakes (ABS)

**Electronics box (E-box)**

- see E-box

**Emergency flasher switch**

- 96-7

**Emergency**

- car opening 96-17
- sunroof closing 60-7

**Engine**

- 02-5
- applications 20-2
- balance shaft, 2.0L gasoline 02-10, 02-11
- compartment
  - components 97-16
  - views 03-13
- engine / transmission mount torques
  - see Engine mounts
- identification 03-6
- overview
  - 1.9L TDI 02-5
  - 2.0L TDI 02-8
  - 2.0L FSI gasoline 02-10
  - 2.0L TSI gasoline 02-15
  - 2.5L 02-21
- sound absorber panels 03-14

**Engine control module (ECM)**

- 23-23, 24-23

## 4 INDEX

### Engine coolant temperature (ECT) sensor

- 1.9L TDI 19-7, 23-4, 23-6, 23-7
- 2.0L TDI 19-9
- 2.0L gasoline
  - code BPY 19-11, 24-4, 24-5
  - code CBFA, CCTA 19-13, 24-11, 24-13
- 2.5L 19-16, 24-16, 24-17

### Engine cooling fan

19-21

### Engine cooling system

- anti-freeze concentration 03-24
- components
  - 1.9L TDI 19-7
  - 2.0L TDI 19-9
  - 2.0L gasoline
    - code BPY 19-11
    - code CBFA, CCTA 19-13
  - 2.5L 19-10, 19-15
- coolant level 03-24
- cooling fans 19-21
- draining, filling 19-5
- hoses
  - inspecting 03-25
  - overview code CBFA, CCTA 19-14
- pressure testing 19-4
- thermostat
  - 1.9L TDI 19-8
  - 2.0L TDI 19-10
  - 2.5L 19-10
    - testing 19-4
- radiator 19-21
- troubleshooting 19-3
- see also* Coolant pump

### Engine hood

- 55-1
- lock 55-3
- lock carrier service position 50-1

### Engine lubrication

- components
  - 1.9L TDI 17-6
  - 2.0L TDI 17-8
  - 2.0L gasoline
    - code BPY 17-10
    - code CBFA, CCTA 17-11
  - 2.5L 17-17
- oil change 03-18
- oil pan
  - 1.9L TDI 17-6
  - 2.0L TDI 17-8
  - 2.0L gasoline
    - code BPY 17-10
    - code CBFA, CCTA 17-11
  - 2.5L 17-16
- oil pressure warning system 17-2
- see also* Oil

### Engine management

- components
  - 1.9L TDI 23-4
  - 2.0L TDI 23-16
  - 2.0L gasoline
    - code BPY 24-4
    - code CBFA, CCTA 24-11
  - 2.5L 24-16
- diagnosis 26-2
- electronic power control (EPC) 20-18
- engine control module (ECM) 23-23, 24-23
- gasoline 24-2
- on board diagnostics OBD-1
- see also* Engine coolant temperature sensor
- see also* Engine speed (rpm) sensor
- see also* Fuel rail
- see also* Ignition
- see also* Intake manifold

### Engine mounts

- 1.9L TDI 15a-17
- 2.0L TDI 15b-18
- 2.0L gasoline 15c-19
- 2.5L 24-16

### Engine speed (rpm) sensor

- 1.9L TDI 23-4, 23-7
- 2.0L gasoline
  - FSI 24-4
  - TSI 24-11, 24-12
- 2.5L 24-16, 24-17

### EPC (electronic power control)

20-38

### ESP (electronic stabilization program)

- see* Electronic stabilization program (ESP)

### Evaporative emissions control (EVAP)

20-40

### Evaporator

- 87-10
- see also* Air conditioning (A/C)

### Exhaust gas recirculation (EGR)

- see* EGR (exhaust gas recirculation)

### Exhaust manifold

- 1.9L TDI 21-5, 26-9
- 2.0L TDI 21-7
- 2.0L gasoline 02-12, 21-11
- 2.5L 02-22

### Exhaust system

- components
  - 1.9L TDI 26-7
  - 2.0L TDI 26-12
  - 2.0L gasoline 26-14
  - 2.5L 26-17
- installation details 26-3

### Expansion valve

87-1, 87-19

## F

### Fan

- see* Blower motor
- see also* Engine cooling system

### Fender, front

50-3

### Flywheel, dual-mass

30-7

### Foglight

94-2, 94-9

### Footwell cover, left

70-16

### Front suspension

- ball joint 40-4
- checking 03-60
- coil spring 40-8
- CV joint 40-15, 40-16
- drive axle 40-9
- strut assembly 40-5
- subframe, stabilizer bar, control arm assembly 40-3
- triple roller joint, 40-17, 40-18
- wheel bearing 40-1

### Fuel filler flap

55-9

### Fuel filter

- diesel engine 03-30
- gasoline engine 03-33

### Fuel injection

- see* Engine management

### Fuel injector

- 1.9L TDI 23-10
- 2.0L TDI 23-20
- 2.0L gasoline
  - code BPY 24-9
  - code CBFA, CCTA 24-15
- 2.5L 24-20
- pump injector (diesel) 23-10

### Fuel level sensor

20-10

### Fuel pressure

- 20-13, 20-23, 20-33
- relieving high pressure 20-30

### Fuel pump

- see* Fuel system

### Fuel rail

- 2.0L TDI 23-15, 23-16
- 2.0L gasoline
  - code BPY 24-9
  - code CBFA, CCTA 24-15
- 2.5L 24-20

**WARNING**

*Your common sense, good judgement and general alertness are crucial to safe and successful service work. Before attempting any work on your Volkswagen, be sure to read 00 Warnings and Cautions and the copyright page at the front of the manual. Review these warnings and cautions each time you prepare to work on your car. Please also read any warnings and cautions that accompany the procedures in the manual.*

**Fuel system**

02-7, 02-14, 20-2  
bleeding 20-10  
delivery unit 20-9  
evaporative emissions control 20-40  
fuel cooler 20-16  
fuel level sensor 20-10  
fuel pump  
  check valve 20-35  
  current draw 20-12  
  electric 20-9  
  high pressure TDI 20-18, 20-18  
  high pressure gasoline 20-14  
  tandem 20-14  
priming 20-20  
problems 20-4  
safety 24-2  
tests 20-22, 20-33

**Fuel tank**

20-7, 20-8  
flap 55-9

**Fuses**

97-3

**G****Gear selector**

automatic transmission 37-8  
Direct Shift Gearbox (DSG) 34b-3  
manual transmission 34a-3

**Generator**

*see* Alternator (generator)

**Glass**

*see* Door window

**Glove compartment**

70-15

**Glow plugs**

28-2, 28-4  
relay 23-9

**Grab handle**

70-18

**Grille**

bumper 63-3  
radiator 66-5

**Grounds**

97-46

**H****Hand brake**

*see* Parking brake

**Hatch and lock (SportWagon)**

55-8

**Headlight**

94-4  
adjusting 03-66  
vehicle level sensor 40-3

**Headliner**

printed circuits 96-2

**Heating and ventilation**

dust and pollen filter 03-65, 87-3,  
87-8, 87-10  
heater core 87-12  
*see also* Air conditioning (A/C)  
*see also* Auxiliary heater

**HID headlight**

94-4

**Hood**

engine hood 55-1  
lock carrier 50-1

**Horn**

acoustic 96-15  
alarm 96-17

**I****Ignition coil**

2.0L gasoline 28-6  
2.5L 28-7

**Ignition system**

components  
  2.0L gasoline 28-6  
  2.5L 28-7  
disabling 28-2

**Immobilizer**

96-15

**Instrument cluster**

90-1  
dimmer 96-6  
lower trim 70-17  
recoding 90-5  
removing, installing 90-5

**Intake flap motor (2.0L)**

removing and installing 24-7

**Intake manifold**

1.9L TDI 23-3  
2.0L TDI 23-17  
2.0L gasoline 02-13  
  code BPY 24-7  
  code CBFA, CCTA 24-14  
2.5L 02-22, 24-18  
tightening mounting bolts 03-49

**Intercooler**

1.9L TDI 21-6  
2.0L TDI 21-9  
2.0L gasoline 21-17

**Interior lights**

96-2

**iPod adapter**

91-5

**J****Jacking vehicle**

03-11

**K****Key**

battery 57-11

**Knock sensor**

2.0L gasoline 28-6  
2.5L 28-7

**L****License plate**

bracket, front 63-2  
light 94-13

**Lid**

*see* Rear hatch  
*see also* Trunk

**Lifting vehicle**

03-11

**Lights, exterior**

controls 94-2  
convenience 94-2  
foglights 94-2, 94-9  
headlights 94-4  
rear lights 94-12  
side lights 94-11  
switch 96-5  
*see also* Headlight

**Lights, interior**

96-2

**LIN-bus**

components 97-28  
overview 9-3

## 6 INDEX

### Lock carrier

- front service position 50-1
- rear hatch, cover 70-29

## M

### Maintenance

- air filter 03-49
- battery 03-35
- body and interior 03-63
- brake fluid 03-26
- brake system 03-54
- cooling system 03-23
- drive axle boots 03-61
- dust and pollen filter 03-65
- engine oil 03-17
- exhaust system 03-62
- fuel filter 03-29
- maintenance schedules 03-70
- parking brake 46-9
- ribbed belt 03-38
- road test 03-69
- sound absorber panels 03-14
- spark plugs 03-45
- timing belt 03-43
- tires and wheels 03-56
- transmission fluid service 03-63
- underbody sealant 03-62
- under car maintenance 03-54
- windshield wipers and washers 03-65

### Manifold

- see* Exhaust manifold
- see also* Intake manifold

### Manual transmission

- applications 02-23
- engine / transmission mount torques
  - 1.9L TDI 15a-71
  - 2.0L TDI 15b-18
  - 2.0L gasoline code BPY 15c-19
- engine to transmission torques 34a-18
- gear selector 34a-6
- identification 03-8
- oil, servicing 34a-3
- removing and installing
  - 5-speed 34a-13
  - 6-speed 34a-17
- specifications 34a-2
- see also* Direct Shift Gearbox (DSG)

### Master cylinder

- brakes 47-8
- clutch 30-2, 30-4, 30-5

### Mirror

- interior 70-2
- outside 66-3

### Motion sensor (ESP)

- 45-4, 45-8

### Motronic

- 24-1

### Muffler

- 26-18

## N

### Navigation

- 91-4

## O

### OBD II

- OBD-2
- plug 24-2

### Oil

- 03-17, 17-2
- capacities 17-2
- filter 03-18, 03-22
  - 1.9L TDI 17-7
  - 2.0L TDI 17-9
  - 2.0L gasoline
    - code BPY 17-13
    - code CBFA, CCTA 17-14
  - 2.5L 17-18
- oil filter cap (2.5L) repairing 17-19
- pressure 17-2
- specifications 03-17
- see also* Engine lubrication

### On Board Diagnostics

- 03-68, OBD-1

### Oxygen sensor

- 26-6, 26-7, 26-10, 26-14, 26-17

## P

### Parking aid

- 94-3

### Parking brake

- 46-9

### Particulate filter

- 26-11

### Passenger occupant detection system (PODS)

- 69-10

### Photo sensor

- 87-9

### Plenum

- bulkhead 50-4
- plastic cover 66-5

### PODS (passenger occupant detection system)

- 69-10

### Pollen filter

- 03-65, 87-3, 87-8, 87-10

### Power steering

- see* Steering

### Power window

- see* Door window

### Pump injector (Diesel)

- 23-10

### Pumpe Düse

- 02-5, 23-1

## R

### Radiator

- 19-21

### Radiator grille

- 66-5

### Radio

- 91-2, 91-7
- antenna 91-5
- anti-theft 91-6
- satellite 91-4

### Rain sensor

- 70-2, 92-2

### Rear hatch and lock (SportWagon)

- 55-8
- trim 70-30

### Rear parcel shelf

- 70-24

### Rear suspension

- coil spring 42-5
- curb weight position 42-2
- overview 42-3
- shock absorber 42-5
- stabilizer bar 42-8
- wheel bearing 42-4

### Refrigerant

- see* Air conditioning (A/C)

### Relays

- 97-42

### Remote control (locking)

- 57-11

### Ribbed belt

- 03-38

### rpm sensor

- see* Engine speed (rpm) sensor

### Run-on mode

- 9-5

## S

### Safety, passenger

- 02-29

### Satellite radio

- 91-4

### Scan tool

- on-board diagnostics II OBD-2
- scan tool suppliers OBD-35

**WARNING**

*Your common sense, good judgement and general alertness are crucial to safe and successful service work. Before attempting any work on your Volkswagen, be sure to read 00 Warnings and Cautions and the copyright page at the front of the manual. Review these warnings and cautions each time you prepare to work on your car. Please also read any warnings and cautions that accompany the procedures in the manual.*

**Seatbelts**

child seat anchors 69-5  
front 69-6  
rear 69-8

**Seats**

front 72-1  
rear 72-5  
rear arm rest 72-8  
side upholstery (rear seat) 72-6

**Secondary air injection**

pump 24-16  
system 26-20

**Service position, engine hood lock carrier**

50-1

**Service reminder indicator, resetting**

03-70

**Shift-lock**

automatic transmission 37-3  
Direct Shift Gearbox (DSG) 34b-3

**Shock absorber**

42-5

**Sill panel trim**

70-17

**Siren**

see Horn, alarm

**Slave cylinder, clutch**

30-4, 30-5

**Sleep mode**

9-5

**Sound absorber panels**

03-14

**Sound system**

91-1  
amplifier 91-5, 91-9  
CD changer 91-5  
overview 91-3  
speakers 91-11

**Spark plugs**

03-45

**Speakers**

91-11

**Special tool suppliers**

OBD-35

**Specifications**

02-3

**Speedometer reading**

90-1

**Spoiler**

front 63-3  
rear 63-5, 63-7

**Spring, suspension**

front 40-8  
rear 42-5

**Stabilizer bar**

front 40-3  
rear 42-8

**Starter**

27-17

**Steering**

column  
components 48-3  
switches 96-8  
trim 70-11, 96-8  
components 48-3  
electro-mechanical 02-26, 48-3, 48-4  
lock 96-13  
overview 02-25  
rack 48-3, 48-4  
steering angle sensor 48-2, 11  
wheel 48-5

**Storage compartment**

70-4

**Strut, front suspension**

40-5

**Sunlight photo sensor**

87-9

**Sunroof**

components 60-2  
drain hoses 60-8  
drive motor 60-6  
emergency closing 60-7  
lubricating 03-64  
repairs 60-3

**Sun visor**

70-14

**Subframe**

front 40-3  
rear 42-3

**Suspension**

overview 02-15  
see Front suspension  
see also Rear suspension

**Switches**

dashboard 96-5  
door 96-13  
emergency flasher 96-7  
exterior lights 96-5  
ignition and steering lock 96-11  
instrument cluster dimmer 96-6  
steering column stalk 96-8

**T**

**Tailgate**

see Rear hatch

**Taillight**

94-2, 94-12

**Tandem pump**

20-14, 47-7

**TDI**

02-5

**Technical data**

1.9L TDI 02-6  
2.0L TDI 02-8  
2.0L FSI gasoline 02-10  
2.0L TSI gasoline 02-15  
2.5L 02-22

**Thermostat**

1.9L TDI 19-8  
2.0L TDI 19-10  
2.5L 19-10  
testing 19-4  
see also Engine cooling system

**Throttle valve**

24-10, 24-22

**Timing belt**

checking 03-43  
removing and installing  
1.9L TDI 15a-6  
2.0L TDI 15b-13  
2.0L gasoline 15b-6

**Timing chain (camshaft drive chain)**

2.0L gasoline 02-15, 15c-31  
2.5L 02-21  
chain guard cover 15c-6  
chain guard cover seal 15c-9

**Tiptronic**

02-23  
switch 34b-3, 37-3

**Tires**

03-56, 44-1  
pressure monitoring 44-5

**Toothed belt**

see Timing belt

**Tool suppliers**

OBD-35

**Torque converter**

32-1

## 8 INDEX

### Towing

03-9

### Transmission

applications and codes 02-23

identification 03-8

*see also* Automatic transmission

*see also* Direct Shift Gearbox (DSG)

*see also* Manual transmission

### Trim

center console 70-4

door inner trim 70-19

pillar and side trim 70-21

rear fender inner trim 70-18

rear hatch 70-30

sill panel trim 70-17

steering column trim 70-11

trunk trim 70-25

underbody 50-4

wagon 70-26

*see also* Body

*see also* Door panel

### Trip computer readings

90-1

### Triple roller joint

40-16, 40-17

### Trunk

lid 55-5

lock 55-6

trim 70-25

### Tumble flaps

02-13

### Turbocharger

21-2

1.9L TDI 21-5

2.0L TDI 21-7

2.0L gasoline 21-2

code BPY 21-10

code CBFA, CCTA 21-14

diagnosis 21-4

*see also* Intercooler

### Turn signal

front 94-8

rear 94-13

## V

### Vacuum pump

02-7, 02-20, 02-22, 47-6

### VAG 1551/1552 operating overview

#### flow chart

OBD-37

### Valvetrain

1.9L TDI 15a-18

2.0L TDI 15b-20

2.0L gasoline FSI 15c-20

2.5L 15s-10

### Value Edition Jetta

02-3

### Vehicle identification number (VIN)

01-1, 03-4

### Ventilation

dust and pollen filter 03-65, 87-3,

87-8, 87-10

*see also* Air conditioning (A/C)

*see also* Heating and ventilation

### Visor

70-14

### Voltage

9-8

## W

### Warnings

00-1

*see also* beginning of each repair group

### Wastegate

21-14, 23-5

### Water pump

1.9L TDI 19-8

2.0L TDI 19-10

2.0L gasoline

code BPY 19-12

code CBFA, CCTA 19-13

2.5L 19-17

### Water separator

03-32

### Weight, vehicle

02-3

### Wheel

03-56, 44-1

alignment 44-3

bearing

front 40-1

rear 42-4

housing inner trim (wagon) 70-26

housing liner 66-1

lock 03-56

speed sensor 45-7

steering 48-5

### Window

*see* Door window

### Wipers and washers

blades 03-66

washers 92-7

wipers 92-3

### Wiring

diagrams EWD-7

index EWD-1

### Working under vehicle

03-12

### Xenon headlight

94-4



[B] BentleyPublishers.com



